



2connet 2C-CB2833 Bill Counter User Manual

[Home](#) » [2connet](#) » 2connet 2C-CB2833 Bill Counter User Manual 

2connet 2C-CB2833 Bill Counter



Contents

- 1 Introduction
- 2 SAFETY INSTRUCTIONS
- 3 BOX CONTENTS & PRODUCT VIEW
- 4 SPECIFICATION
- 5 CONTROL PANEL
- 6 MODES & FUNCTION
- 7 OPERATION
- 8 THICKNESS SETTING
- 9 CLEANING AND MAINTENANCE
- 10 TROUBLE SHOOTING
- 11 SELF-EXAMINATION CODE
- 12 ERROR CODE
- 13 SOFTWARE VERSION
- 14 SETTING MENU
- 15 Documents / Resources
 - 15.1 References
- 16 Related Posts

Introduction

Thank you for purchasing our bill counter with value counting. This guide will provide you with safety information, instructions for optimal use, and proper care and maintenance for your product. Please read this manual carefully before operation.

SAFETY INSTRUCTIONS

When using this machine follow these basic safety precautions to reduce risk of fire, electric shock injury.

WARNING

1. Only use the power cord that comes with the machine. Using a different power cord may result in electric shock, fire, or cause serious damage to the machine. Plug the power cord into a proper grounded wall outlet.
2. Do not use the machine if the power cord is damaged. This may result in electric shock, fire, or other hazards.
3. Do not place the machine in an area where it may be exposed to water or other liquids.
4. To reduce the risk of electric shock, do not take apart the machine. When service or repair is needed, bring to a qualified service repair technician.
5. When unplugging the power plug, grip the plug to pull it out. Pulling the cord may result in electric shock, fire, or damage to the machine.
6. Do not place objects on the power cord and do not bend it excessively.
This may result in electric shock, fire, or other hazards.

CAUTION

1. Before dusting the machine with a brush, unplug the machine from the wall. Do not use liquid or aerosol cleaners on the machine.
2. Do not use the machine in areas with high temperature or high humidity.
This may result in the machine not working properly.
3. When not using the machine for long periods of time, unplug the power cord from the outlet.


BOX CONTENTS & PRODUCT VIEW

The retail box contains the following items:

- Money Counter
- Power Cord
- External Display
- User' s Guide
- Dust Cover
- Brush

1. Hopper with note guides
2. Control panel (display / buttons)
3. Stacker
4. Power socket
5. Power switch
6. Adjustment knob
7. RJ 232 port for external display
8. Power cord


- 9. User's guide
- 10. External display



SPECIFICATION

Counting Speed	900 notes / min
Hopper Capacity	130 notes
Stacker Capacity	130 notes
Power	110V / 60Hz
Power Consumption	80
Dimensions	290 250 175 mm
Net Weight	4.7 Kg

CONTROL PANEL



MODES & FUNCTION

Magnetic counterfeit detection (MG+)

If the magnetic sensor on the machine does not find the presence of magnetic components that are standard in authentic bills, the machine will stop counting to allow removal of the counterfeit bill and display the error code on the display.

Press MG to turn on/off magnetic counterfeit detection.

Ultraviolet counterfeit detection (UV-)

Counterfeit bills often use white or bleached paper, which will glow under ultraviolet light. When the UV sensor finds a counterfeit bill, the machine will stop counting to allow removal of the counterfeit bill and display the error code on the display. Press UV to turn on/off ultraviolet counterfeit detection.

Adding function (ADD)

The ADD mode displays the cumulative total of all bills counted. Press ADD to turn on/off adding function.

Batch function (BAT)

Press BAT to turn on/off batch function. The BAT mode counts bills in batches. The preset batch number is 100. Use the keypad to enter a batch number between 1 and 999.

Auto & Manual Mode (A/M)

After turning the machine on for the first time it will default to AUTO mode. In this mode the machine starts counting automatically. To operate in MANUAL mode, press the "A/M" button on the control panel. If the machine is set to operate in MANUAL mode, the "START" button should be pressed to begin each count. To go back to AUTO, press "A/M" button again.

SET Button

Sensitivity settings

CLEAR Button

Resets the count.

START Button

Starts the counting.

OPERATION

1. Attach power cord to back of the machine, plug into a outlet, and turn power switch on.

The unit will conduct an automatic self-diagnostic test to ensure accurate counts. After five seconds of the counting wheels the screen will display a "0". If there is a problem, the preset display will show an error code. (See ERROR CODE DISPLAYS – LOCATED ON PAGE)

2. Select bill counting settings.

Before counting, select counting settings that related to your counting needs. (See FUNCTION – LOCATED ON PAGE 5)

3. Place bills into the hopper to begin counting. Avoid counting wet, dirty or spoiled banknotes.

A) Check for foreign matter mixed with the bills for example paper chips, rubber bands, clips and dust.

B) Straighten the folds or corners of the bills before insertion.

C) Put the banknotes on the hopper as shown below.


D) Adjust the note guides according to the longest bill in the stack.



THICKNESS SETTING

Thickness setting must always be adjusted to achieve a proper and smooth feeding of banknotes. The thickness is adjust with the thickness adjustment knob found on the back of the machine.

- **A)** If the banknotes run too hard or too slow: Turn the adjustment knob clockwise to increase the gap between the feed rollers.
- **B)** If the machines stops frequently and displays Turn the adjustment knob slightly counter-clockwise to decrease the gap between the feed rollers.



CLEANING AND MAINTENANCE

Before doing any cleaning, turn the power switch off. It's very important to clean all the sensors in the machine with a soft brush and cloth to avoid any paper particles or dust from sticking to the light transmitter or the light-


receiver sensors after a period's of application.
It's necessary to clean the inside of the machine occasionally.

TROUBLE SHOOTING


Before asking for maintenance service please check the machine as follows:

- No power

The power line cord is
connected well?




The fuse is worn out?




- Power is on, but the unit is not working.


The hopper sensor is dirty, please clean with brush.



Connect the hopper sensor line well to the main board.




The belt is too loose or too tight, please adjust the belt.




- Wrong counting


Adjust the screw behind the banknote entrance.



Counting sensor is dirty, please clean it.




The obstruction sheet or the wheel is damaged, replace with a new one.




- Wrong detecting


The dimension detection sensor is broken, please replace it with a new one.



Adjust the MG sensor.



UV sensor is broken or dirty, please clean it or change with a new one.



SELF-EXAMINATION CODE


Self-checking error code	Trouble position	Solution
FE2	Left Counting Sensor	<ol style="list-style-type: none"> 1. Clean up the dust on the counting sensor; 2. Infrared signal self-learn 3. Connect the counting sensor line well to the main board.
FE3	Right Counting Sensor	<ol style="list-style-type: none"> 1. Clean up the dust on the counting sensor; 2. Infrared signal self-learn 3. Connect the counting sensor line well to the main board.
FE7	Dimension Detection Sensor	<ol style="list-style-type: none"> 1. Check if there are foreign objects stuck in the drive wheel of the banknote channel. 2. Connect the dimension detection sensor line well to the main board 3. The dimension detection sensor is broken, please replace it with a new one.
FE!	Hopper Sensor	<ol style="list-style-type: none"> 1. Foreign objects blocking the hopper sensor. 2. Connect the hopper sensor line well to the main board. 3. The main board is broken, please replace it with a new one.
FE6	Stacker Sensor	<ol style="list-style-type: none"> 1. Foreign objects blocking the stacker sensor. 2. Connect the stacker sensor line well to the main board. 3. The main board is broken, please replace it with a new one.
FEA	UV Sensor	<ol style="list-style-type: none"> 1. The main board is broken, please replace it with a new one.

ERROR CODE

Error	Trouble	Solution
E10	Bill UV sensor error	<ol style="list-style-type: none"> 1. UV sensor is broken or dirty, please clean it or change with a new one. 2. The main board is broken, please change with a new one.
E2	IR error	<ol style="list-style-type: none"> 1. Clean up the dust on the counting sensor; 2. Infrared signal self-learn 3. Connect the counting sensor line well to the main board. 4. The main board is broken, please change with a new one.
E4	Half notes error or incomplete notes error	<ol style="list-style-type: none"> 1. Clean up the dust on the counting sensor; 2. Infrared signal self-learn 3. Connect the counting sensor line well to the main board. 4. The main board is broken, please change with a new one.
E5	MG ink error	<ol style="list-style-type: none"> 1. Foreign objects on the surface of the magnetic sensor. 2. Connect the magnetic sensor line well to the main board. 3. Magnetic sensor is broken, please change with a new one. 4. The main board is broken, please change with a new one.
E8	Bill size recognize error or chain note error	<ol style="list-style-type: none"> 1. Straighten the folds or comers of the bills before insertion 2. Turn the adjustment knob to increase or decrease the gap between the feed rollers 3. The obstruction sheet or the wheel is damaged, replace with a new one.








SOFTWARE VERSION


Turn on the machine, display will show software version:



SETTING MENU


Hold press the “SET” button for 3 seconds, to enter the SET program. Press the “BAT” button to choose the different codes, then use the “ MG+” button or the “UV-” button to adjust the setting accordingly. Once adjust, place a finger on the hopper sensor to save and exit the sensitivity settings menu. Codes are listed below for reference.

Code	Detail	Setting	Adjustment	
C00	Voice Switch	1	O=off/1=on	
H-C01	Voice Volume	1	O=off / larger number =louder sound	
H-C07	Stop line	40	larger number =quicker	
-C08	Alarm last time	0	O=shut / 1=open	
H-C09	Hopper Sensor Sensitivity	150	larger number =higher sensitivity	
H-C10	Stacker Sensor Sensitivity	125	larger number =higher sensitivity	
-C24	Double Note sensitivity	20	larger number =higher sensitivity	

-C25	UV Sensor Sensitivity	120	larger number =higher sensitivity	
------	-----------------------	-----	--------------------------------------	--



Documents / Resources

	2connet 2C-CB2833 Bill Counter [pdf] User Manual 2C-CB2833 Bill Counter, 2C-CB2833, Bill Counter, Counter
---	--

References

Manuals+