



## 4RF Aprisa LTE Smart Secure and Hardened LTE Router User Guide

[Home](#) » [4RF](#) » 4RF Aprisa LTE Smart Secure and Hardened LTE Router User Guide 



*Aprisa* **LTE**



### Quick Start Guide

#### Contents

Follow these steps to operate your Aprisa LTE router:

1. Check the box contents
2. Install the Aprisa LTE and connect the protection earth
3. Set up and apply power to the Aprisa LTE
4. Connect to the Aprisa LTE
5. Configure the Aprisa LTE
6. Test the Aprisa LTE operation

Aprisa LTE Quick Start Guide 1.3.0 © 2021 4RF Limited. All rights reserved. This document is protected by copyright belonging to 4RF Limited and may not be reproduced or republished in whole or part in any form without the prior written permission of 4RF Limited. While every precaution has been taken in the preparation of this literature, 4RF Limited assumes no liability or errors and omissions, or from any damages resulting from the use of this information. The contents and any product specifications within it are subject to revision due to ongoing product improvements and may change without notice. Aprisa and the 4RF logo are trademarks of 4RF Limited. All other marks are the property of their respective owners.

LTE is a trademark of ETSI, used with permission for Aprisa products containing LTE functionality.

April 2021

Version 1.3.0

## Contents

- [1 Check the box contents](#)
- [2 Install the Aprisa LTE and connect the protection earth](#)
- [3 Set up and apply power to the Aprisa LTE](#)
- [4 Connect to the Aprisa LTE](#)
- [5 Configure the Aprisa LTE](#)
- [6 Test the Aprisa LTE operation](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

## Check the box contents

The box contains:


- One Aprisa LTE Router.
- One Aprisa LTE 1 meter power cable fitted with 4 pin Molex Micro-Fit 3.0 female connector and wire ended.
- One power connector locking plate and screw (secures the power connector to the Aprisa LTE).

## Install the Aprisa LTE and connect the protection earth

The Aprisa LTE has four threaded holes (M4) in the base and two holes (for M5 screws) through the enclosure for mounting. Mounting options include:

- DIN rail mounting with the Aprisa LTE DIN rail mounting bracket (optional accessory part number 'APLB-MBRK-DIN').
- Wall and rack shelf mounting.
- Outdoor enclosures.

The Aprisa LTE DIN rail mounting:




The Aprisa LTE has an earth connection point on the top left of the enclosure. Use the supplied M4 screw to earth the enclosure to protect the earth.



**Warning:** If the Aprisa LTE is operated in an environment where the ambient temperature exceeds 50°C, the Aprisa LTE must be installed within a restricted access location to prevent human contact with the enclosure heatsink.

Hereby, 4RF Limited declares that the Aprisa LTE router is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the internet address <https://www.4rf.com/library/en>.


|   |  |
|---|--|
|  | <p>BE BG CZ DK DE EE IE EL ES FR HR IT CY LV<br/>L AT PLPTROSI SK FI SE UK</p> |
|---|--|

## Set up and apply power to the Aprisa LTE

A valid SIM provided by your local wireless carrier e.g. Verizon, AT&T, EE, and Vodafone is required for connectivity.

The LTE can accommodate two standard Micro SIMs (12 x 15mm) which fit into the product rear under the SIM cards cover plate.

Contact your carrier for details about selecting a data plan and about the process for activating your SIM.



Install an activated SIM in the Aprisa LTE:


1. Ensure the power to the Aprisa LTE is turned off.
2. Unscrew the two screws on the SIM card's cover plate.
3. Fit the SIM to the 'SIM 1 Slot' slot notch-end first with metal contacts facing up.

Attach either separate antennas for LTE, GNSS, and Wi-Fi or a single combination antenna to the appropriate QMA connectors on the Aprisa LTE.



The Aprisa LTE is operated from a DC source of voltage between +9 VDC and +3VDC (negative earth) and consumes up to 15 watts. External power supplies are available from 4RF as accessories (see the Aprisa LTE User Manual).

The Aprisa LTE power connector is a Molex Micro-Fit 3.0 4 pin male connector. The power supply input connects to pin 1 +ve and pin 2 -ve. A 1 metre power cable fitted with a 4 pin Molex Micro-Fit 3.0 female connector and wire ended is supplied in the box with each Aprisa LTE.



The Molex Micro-Fit 3.0 4 pin connector clips into the Aprisa LTE socket. It also has a locking plate and screw (supplied with the Aprisa LTE) that enables the connector to be secured to the Aprisa LTE with a screw.

**Note:** The Aprisa LTE internal fuses will blow if the connected power supply is over-voltage or the polarity is reversed. If this happens, the fuse(s) will need to be replaced. Spare fuses can be ordered from 4RF (see the 'Spare Fuses' section of the Aprisa LTE User Manual).

Turn your power source on. The Aprisa LTE OK and AUX LEDs will flash orange while the router is booting up.

The Aprisa LTE OK LED will light green when the router is ready to operate.

For vehicle installation, the Aprisa LTE power connector pin 3 is used as an ignition sense line and should be connected to a source of +12 or +24 volts that comes on when the vehicle is running. No connection is required for stationary applications.

## Connect to the Aprisa LTE


The Aprisa LTE has a factory default IP address of 192.168.4.1 with a subnet mask of 255.255.255.0.

- If your PC is set for DHCP (obtains an IP address automatically) you do not need to manually set an IP address. Alternatively, if your PC requires a static IP address, set up a compatible IP address e.g. 192.168.4.100 with a subnet mask of 255.255.255.0.

- Connect your PC network port to one of the Aprisa LTE Ethernet ports.
- Open a browser and enter 192.168.4.1.

**Note:** The default Aprisa LTE application protocol is HTTP.

- Login to the Aprisa LTE with the default login of Username 'admin' and Password 'admin'.
- Change the IPv4 address, IPv4 netmask, and IPv4 gateway as required for settings compatible with your network.



**4RF SUPERVISOR**


**LOGIN**

Please sign in with your username and password.

Username

Password

*This system is for use by authorized users only*



**4RF SUPERVISOR**

Terminal Name  OK AUX TX RX SFP WIFI

Terminal Cellular Location **Interfaces/Networking** Services Security Maintenance Events

Summary Ethernet SFP Serial USB WIFI Logical Interfaces Static Routes DHCP and DNS


**LAN** WAN WAN6

**INTERFACES - LAN**

On this page you can configure the network interfaces. You can bridge several interfaces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also use VLAN notation INTERFACE.VLANNR (e.g.: eth0.1).

**COMMON CONFIGURATION**

General Setup **Advanced Settings** Physical Settings Firewall Settings

Status  Device: br-lan  
Uptime: 2h 47m 10s  
RX: 680.22 KB (5732 Pkts.)  
TX: 879.24 KB (4545 Pkts.)  
IPv4: 172.10.1.40/24  
IPv6: fd89:19d0:e5a9::1/60

Protocol Static address

IPv4 address

IPv4 netmask

IPv4 gateway

## Configure the Aprisa LTE

- Go to Supervisor > Services > Date & Time and set the time zone offset, and format.
- Verify that the Aprisa LTE active software and LTE module are correct for the provider.  
Go to SuperVisor > Cellular > Summary to view the currently supported bands.  
Go to SuperVisor > Cellular > General and select the specific band in use or leave the default 'Select All' option.
- Go to SuperVisor > Cellular > General to view the SIM status.
  - Set the SIM PIN.

**Note:** not all cellular operators use a pin to enable the SIM card so the SIM pin may not be required.

  - Set the Preferred Provider to match that of the SIM card.
- Go to SuperVisor > Cellular > General (optional)
  - Set the Packet Data Network (PDN) Profile Name (if required).
  - Set the active/backup Access Point Names (APNs) per your installed SIM(s).
  - Set the SIM slot.
  - The Aprisa LTE features an auto APN feature, so only change the Packet Data Network details if required.

**Note** that a corporate network requires both a private APN name and the Mode set to Enable.

  - Tick Roam to switch from the home network (i.e. the SIM network) to the roaming network when the Aprisa LTE is outside the range of its home network and connects to another available cellular network. When on the roaming network, charges may be applied per customer contract.

**MODEM**

|                   |  |
|-------------------|--|
| Manufacturer      | Sierra Wireless, Incorporated  |
| Model             | EM7565   |
| IMEI              | 353533100758989  |
| Max TX Rate(Mbps) | 150  |
| Max RX Rate(Mbps) | 600  |
| Supported Bands   | B1, B2, B3, B4, B5, B7, B8, B9, B12, B13, B18, B19, B20, B26, B28, B29, B30, B32, B41, B42, B43, B46, B48, B66 |
| Enabled Bands     | B1, B2, B3, B4, B5, B7, B8, B9, B12, B13, B18, B19, B20, B26, B28, B29, B30, B32, B41, B42, B43, B46, B48, B66 |

**SIM 1 SETTINGS**

Use SIM PIN ☐

SIM PIN

Preferred Provider None

SIM Status Not Locked

SIM PIN Retries Remaining 3

**PDN PROFILE SETTINGS**

| Profile Name                      | APN                                    | SIM   | Addr   | Mode   | Roam                                |
|-----------------------------------|--|---|--|--|-------------------------------------|
| <input type="text" value="pdn1"/> | <input type="text" value="internet1"/> | <span>SIM 1</span> <input type="button" value="v"/> | <span>IPv4</span> <input type="button" value="v"/> | <span>Enabled</span> <input type="button" value="v"/>  | <input checked="" type="checkbox"/> |
| <input type="text" value="pdn2"/> | <input type="text" value="internet2"/> | <span>SIM 1</span> <input type="button" value="v"/> | <span>IPv4</span> <input type="button" value="v"/> | <span>Disabled</span> <input type="button" value="v"/> | <input type="checkbox"/>            |
| <input type="text" value="pdn3"/> | <input type="text" value="internet3"/> | <span>SIM 1</span> <input type="button" value="v"/> | <span>IPv4</span> <input type="button" value="v"/> | <span>Disabled</span> <input type="button" value="v"/> | <input type="checkbox"/>            |
| <input type="text" value="pdn4"/> | <input type="text" value="internet4"/> | <span>SIM 1</span> <input type="button" value="v"/> | <span>IPv4</span> <input type="button" value="v"/> | <span>Disabled</span> <input type="button" value="v"/> | <input type="checkbox"/>            |

- If the Wi-Fi network module is installed on your LTE, and you want to enable this feature, go to SuperVisor > Interfaces/Networking > WiFi and click Edit.
  - Under the General Setup tab click Enable. If required, you can change the Wi-Fi WLAN Operating Parameters (mode and channel). Note that the mode 802.11b/g/n will provide the widest Wi-Fi compatibility while 802.11n/ac will provide the fastest Wi-Fi speeds.
  - On the same page, use the Interface Configuration tabs to set the Wi-Fi password ESSID and required security settings.



**INTERFACE CONFIGURATION**

**General Setup** **Wireless Security** **MAC-Filter** **Advanced Settings**

Mode

ESSID

Network

Hide ESSID ☐

## Test the Aprisa LTE operation

- Check the Aprisa LTE is operating by checking the SuperVisor > Monitoring > Cellular page.

| CELLULAR PARAMETERS         |        |
|-----------------------------|--------|
| Modem Temperature (Celsius) | 25     |
| Current RSSI (dBm)          | -86.5  |
| Current RSRP (dBm)          | -107.1 |
| Current RSRQ (dB)           | -3.6   |
| Current SNR (dB)            | 17     |
| Current SINR (dB)           | 17.6   |

Typical values are:



| RF Conditions | RSSI (dBm) | RSRP (dbm)  | RSRQ (db)  | SNR (db) | SINR (db) |
|---------------|------------|-------------|------------|----------|-----------|
| Excellent     | >= -65     | >= -80      | >= -10     | >= 20    | >= 20     |
| Good          | -65 to -75 | -80 to -90  | -10 to -15 | 13 to 20 | 13 to 20  |
| Fair          | -75 to -85 | -90 to -100 | -15 to -20 | 0 to 13  | 0 to 13   |
| Poor          | -85 to -95 | <= -100     | < -20      | <= 0     | <= 0      |



- On a PC that is connected to either Wi-Fi or wired Ethernet port, do a ping to well know internet address.
- Test IPv4 connectivity by pinging a well know IPv4 address e.g. 8.8.8.8 (google DNS server).
- Test IPv6 connectivity by pinging a well know IPv6 address e.g. 2001:4860:4860::8888 (google DNS server).
- Test DNS connectivity by pinging a well know DNS address e.g. 4rf.com.
- Try browsing the internet from the configuration PC.

For more information, please refer to the 'Aprisa LTE User Manual' available from the 4RF website [www.4rf.com/secure/](http://www.4rf.com/secure/) (login required).

For access contact your distributor, 4RF sales representative, or contact 4RF directly at [www.4rf.com/contact/sales](http://www.4rf.com/contact/sales).



## Documents / Resources

|   |  |
|---|--|
|  <p><b>Aprisa LTE</b> </p> <p>Quick Start Guide</p> <p>Contents</p> <p>1. Power On the Router</p> <p>2. Connect the Router to the Network</p> <p>3. Connect the Router to the Network</p> <p>4. Configure the Router</p> <p>5. Test the Router's Function</p> | <p><a href="#">4RF Aprisa LTE Smart Secure and Hardened LTE Router</a> [pdf] User Guide</p> <p>Aprisa LTE Smart Secure and Hardened LTE Router</p> |
|---|--|