



KM SVS 2000 Weight Controller Indicator User Manual

[Home](#) » [KM](#) » KM SVS 2000 Weight Controller Indicator User Manual 

Contents

- [1 KM SVS 2000 Weight Controller Indicator](#)
- [2 Mounting and Wiring](#)
 - [2.1 Mounting](#)
 - [2.2 Wiring](#)
- [3 Setup with Quick Config](#)
 - [3.1 Auto \(Live Load \) Calibration](#)
 - [3.2 Remote Tare or Totalize](#)
 - [3.3 Error Messages](#)
- [4 Keyboard Functions](#)
- [5 Hot Keys \(Run Mode operations\)](#)
 - [5.1 Run Mode](#)
 - [5.2 Toggling Between Modes](#)
 - [5.3 Function Mode](#)
 - [5.4 Function Mode Menu Tree](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)



KM SVS 2000 Weight Controller Indicator



Reference

KM 97-1129-01, SVS 2000

Installation and Operation Manual


Mounting and Wiring

Mounting


CAUTION

- Do not mount in direct sunlight.
- Use flex conduit between rigid conduit and SVS 2000 enclosure.
- Consider clearance needs for wiring and maintenance.
- Consider temperature at mounting location. See Manual Appendix A for specifications.

1. For Stainless Steel version, first remove electronics assembly.
2. Hold SVS 2000 in desired location and mark mounting hole positions.
3. Drill mounting holes.



See Manual Appendix E for additional wiring details



Detail — KM Half-Bridge Sensors

4. Mount SVS 2000 securely using customer-supplied hardware.
5. For Stainless Steel version, make entry holes in bottom of enclosure and re-install electronics assembly.


Wiring

Route AC power and setpoint cables separate from low-level signal cables.

1. Connect sensor wiring.
2. Connect relay output, digital output, analog output, serial output, and remote input wiring, as applicable.
3. Connect AC power.
4. Apply power and check display.
5. Seal openings in enclosure, using Sikaflex 1A or Dow Corning RTV 739 or 738 sealant.
6. Tighten set screws that secure wires to the terminal boards to 8 lbf/in. of torque.


WARNING

- Wiring must comply with national/local wiring requirements.
- Ground conductor must connect to Protective Earth (PE) terminal. Power wiring must include switch/circuit breaker for disconnecting power. It must be close to SVS 2000, in easy reach of operator, and marked as disconnect for unit.



Setup with Quick Config

1. See Figures 1 and 2. Determine whether application is direct support or bolt-on. Gather data to fill out table in applicable figure.
2. See Figure 3. Perform Quick Config. SVS 2000 leads you through menu tree. When Quick Config is complete, SVS 2000 automatically switches to Run Mode.



Direct Support Load Cell?

Units? lbs or kg

Rated Load per load cell?1

_____ lbs or kg Sensitivity?1

_____ mV/V


Number of supports for vessel2 _____

Current live load? _____ lbs or kg

Notes:

1. See load cell label or sensor manual.
2. Enter number of supports, not number of load cells. For example, in the suspended application shown above, there are
3. supports (3 rod assemblies), even if only 2 of the assemblies contain live load cells.

Figure 1. Direct Support (load cell) Application



KM Bolt-On Sensor?

Units? lbs or kg

Sensor type? 1 L-Cells or Microcells If Microcells: 1, 2

Installed on horizontal beams?

Installed on vertical legs?

Rosette Arrays?

Vertical Microcells?

Vessel working capacity? 1

_____ lbs or kg

Vessel working stress? 1

_____ psi or kg/mm²

Current material weight?

_____ lbs or kg


Notes:

1. See Application Data Form. Copy of form was returned with order. If you cannot locate it, contact KM.
2. Internal calculations for Microcells for
3. inch Microcells on carbon steel. Modify calibration after Quick Config if installing on stainless steel or aluminum or using 2-inch Microcells. See Manual Appendix C, Calculation of Manual Calibration Parameters, for details.

Figure 2. Bolt-On
(Microcell or L-Cell) Application

Auto (Live Load) Calibration

Quick Config configured the SVS 2000 based on system and sensor characteristics. When scheduling permits you to move material (at least 25% of vessel’s capacity), perform Auto calibration to obtain highest accuracy. Calibration by Adding Known Quantity of Material (starting on Run Mode display)



Note: For Calibration by Subtracting Known Quantity of Material, see Manual Chapter 6, Cal Menu.

Default Unit

Method #1 (starting on Run Mode display)

Action

9

4

ENTER

ENTER

ENTER

ENTER

Typical Display at End of Step

94 DEFAULT SYSTM

DEFAULT NVRAM?

ARE YOU SURE?

(beginning of Quick Config)

Method #2

1. Turn off AC power.
2. Press and hold Enter Key while turning on AC power.

Remote Tare or Totalize

Provide a 1 second contact closure on tare input terminals — see Manual Appendix E for wiring details. Configuration of remote input as tare or totalize is done in function 15, Ext Inpt Mode.

Error Messages

See Manual Appendix F, Error Messages.

Keyboard Functions

Func Key (Run Mode only) Go to function 10 in menu tree.

Arrow Keys

- Run Mode: Scroll through Run Mode displays.
Function Mode:
- Scroll through menu selections at given level.
- Scroll to parameter value.

Net Key

Go to net weight display in Run Mode.

Gross Key

Go to gross weight display in Run Mode.

Tare Key (Run Mode only)

Press for 1 second to tare vessel. SVS switches to net weight display.

Zero Key (Run Mode only)

- Gross display: Change calibration, setting gross weight to zero.
- Net display: Reset number of tares to zero.
- Total display: Reset total weight and number of totals to zero.
 - (minus) Key (Run Mode only) Press for 1 second to totalize vessel (add net weight to total weight). SVS switches to total weight display.
Enter Key
- Run Mode:
 - Gross display: Toggle between
- Numerical and bar graph format.—Net display: Briefly display
- Number of tares since tare reset.—Total display: Briefly display number of totals since totalizer reset.
- Function Mode:
 - Access submenus.
 - Save parameter value in memory.

Numeric Keys

- Run Mode: Enter function number for desired menu (press Enter Key after number is entered).
- Function Mode: Input
parameter value.

Hot Keys (Run Mode operations)

Switch from Run to Function Mode
Press Func Key.

Switch from Run Mode to particular Function Mode Menu

Press 2-digit function number and Enter Key.

Switch from Function to Run Mode

Press Gross or Net Key.

Scroll through Run Mode Displays (gross, net, total, and relay status)

Press Up or Down Arrow Key.

Switch to Gross Weight

Press Gross Key.

Switch to Net Weight

Press Net Key.

Toggle between Gross Weight

Numerical and Bar Graph Displays

Press Enter Key while on gross display.

Zero Gross Weight

Press Zero Key while on gross display. When SVS requests verification, press Enter Key. Press any other key to abort.

Tare (local)

Press Tare Key for 1 second, until SVS flashes Tare Implemented and switches to net display.

Display Number of Tares

Press Enter Key while on net display.

SVS flashes number of tares.

Zero Number of Tares

Press Zero Key while on net display.

Totalize (local)

Press '-' Key for 1 second, until SVS flashes Net Totalized and switches to total display.

Display Number of Totals

Press Enter Key while on total display.

SVS flashes number of totals.

Zero Total Weight and # of Totals

Press Zero Key while on total display. When SVS requests verification, press Enter Key. Press any other key to abort.

Display Serial Address

Press '-' Key and then '1' Key.

Display Software Revision

Press '-' Key and then '2' Key.

Display ID Label

Press '-' Key and then '3' Key.

Display Net Reference (\pm NR)

Press '-' Key and then '4' Key.





Figure 3. Quick Config Menu Tree and Keyboard Use

Run and Function Modes


- Run Mode — Monitoring
Display gross weight, net weight, total weight, and relay status.
- Function Mode — Menu Tree
Access menu tree to allow user to view and modify setup parameters.

When Quick Config is complete, SVS 2000 automatically switches to Run Mode.

Run Mode




Toggleing Between Modes



Function Mode

(see next pages for complete menu tree and descriptions)



Note: Use of Arrow Keys and Enter Key to navigate in submenus is similar.

Function Mode Menu Tree

Display Menu

- Display Menu
- Disp Format (xxxxxx, xxxxx.x, xxxx.xx, xxx.xxx, xx.xxxx, xxxxxxo, xxxxxxoo)
- Disp Countby (1, 2, 5, 10, 20, 50, 100, 200, 500, 1000, 5000, 10000)
- Disp Units (lbs, kg, CWT, tns, gal, Ltr, bbl, bu, %, ft, m, mV, none)
- Bargraph Span
- Ext Inpt Mode (Tare, Total)

Cal Menu

- Auto Cal
 - Lo Span Cal
 - Hi Span Cal
 - Disp Val Correct
- Manual Cal
 - Scale Factor Wgt
 - Scale Factor Cts
 - Zero Counts
- Linearization
 - Linearize Set
 - Linearize Enable (Off, On)
- Zero Tolerance
- Cal Display (Cnt/mV, ScfWgt, ScfCnt, ZeroCnt, DispVCW, HiSpanW, LoSpanW, HiSpanC,

Setpoint Menu

- Slct Relay #1
Relay1 Value
Relay1 Deadband
Relay1 Hi/Lo (Hi, Lo)
Relay1 Track (Grs, Net, Tot, Flt)
Relay1 Fail-Safe (On, Off, NC)
Relay1 Preact
- Slct Relay #2 (similar to relay 1)
- Slct Digt1 #1 (similar to relay 1)
- Slct Digt1 #2 (similar to relay 1)
- Slct Digt1 #3 (similar to relay 1)
- Slct Digt1 #4 (similar to relay 1)
- Slct Digt1 #5 (similar to relay 1)
- Slct Digt1 #6 (similar to relay 1)
- Digt1 Status
Setpoint Test
Select Relay #1 (Off, On)
Select Relay #2 (Off, On)
Select Digt1 #1 (Off, On)
Select Digt1 #2 (Off, On)
Select Digt1 #3 (Off, On)
Select Digt1 #4 (Off, On)
Select Digt1 #5 (Off, On)
Select Digt1 #6 (Off, On)

I-Output Menu

- IOut Range (4-20mA, 0-20mA)
- IOut: 4/0mA
- IOut: 20mA
- IOut Track (Grs, Net)
- IOut Failsafe (Hi, Lo, NC)
- IOut Enable (On, Off)
- Current Adjst (0mA Point, 4mA Point, 20mA Point)
- Test Current (4/0mA, 6/2mA, 8/4mA, 10/6mA, 12/8mA, 14/10mA, 16/12mA, 18/14mA, 20/16mA, 18mA, 20mA)

Com Menu

- Serial Addres
- Serial Baud (1200, 2400, 4800, 9600, 19200)
- PLC Menu
 - A-B RIO Menu
 - DeviceNet Menu (release in 1999)
 - Profibus Menu (release in 1999)
 - Modbus Menu (release in 1999)

Sensor Menu

- Sensor Adj Ex (13V, 12V, 11V, 10V, 9V, 8V, 7V, 6V, 5V)
- Resolution (16bt, 17bt, 18bt, 19bt, 20bt, 21bt)
- Sensor Gain (1, 2, 4, 8, 16, 32, , 128)
- Sensor Disply (Raw Weight, Ftr Weight, Out Weight, Raw Counts, Ftr Counts, Sensout)

Filter Menu

- Averaging
- DSP Enable (On, Off)
- DSP Step
- DSP Qualify
- DSP Factor
- DSP Step Mon
- Tracking Menu
- Rate Threshld
- Sample Intrvl
- Zero Trak Win
- Drift Limit
- Mat Trak Enab (On, Off)
- Rate Monitor
- Service Menu
- User Access
- Keyboard Lock
- Keyboard Test
- Default Systm
- Diagnostics

Menu Descriptions

- Display Menu
- Disp Format — Move decimal point or add 'dummy' zeroes to display.
Use with Disp Countby to provide results consistent with system accuracy.
Note that changes affect many parameter values.
- Disp Countby — Set display to count by increments.
- Disp Units — Set engineering units for display.
- Bargraph Span — Set span
(100% value) for bar graph.
- Ext Inpt Mode — Configure
external input as remote tare
(default) or remote totalize.

Cal Menu

- Auto Cal —
 - Set Lo Span and Hi Span while
moving material into or out of
vessel. Must move at least 25% of
vessel's total capacity. Provides
highest accuracy.
 - Set known material weight with
Disp Val Correct to shift calibration.
- Manual Cal — Fine tune calibration using calculated values or re-enter previous calibration data.
- Linearization — Correct weight for vessel structures that respond non-linearly to load changes.
- Zero Tolerance — Set tolerance limit for pressing of Zero Key in Run
Mode (gross weight display) to prevent accidental zeroing of vessel with material.
- Cal Display — View calibration values.
- Setpoint Menu
Set up relays and digital outputs:
- Value — Energizing value.
- Deadband — Material added or removed before setpoint de-energizes.
- Hi/Lo — Energize above or below Value.
- Track — Energize based on gross,
net, or total weight, or system fault.
 - Failsafe — Setpoint failsafe condition (on, off, or no change)
 - Preact — Point (material added or removed) before Value is reached at which setpoint energizes.

I-Output Menu (with optional PCB)

Set up current output:

- IOut Range — 4-20 or 0-20 mA.
- 42 4/0mA — Low output value.
- 43 20mA — High output value.
- 44 Track — Output based on gross or net weight.
- 45 Failsafe — Output failsafe condition (on, off, or no change).
- Enable — Turn output on/off.

Com Menu (with optional PCBs)

Set serial address, baud rate, and PLC parameters for communication with other devices.

Sensor Menu

Set excitation and gain to match sensors. Set resolution. Display raw, filtered, and output data.

Filter Menu

Set up averaging and DSP filter to reduce effect of 'noise'.


Tracking Menu

Set up zero and material tracking to reduce effect of 'noise' and drift.

Service Menu

Set access and keyboard lock codes, perform diagnostics, and default system.

Documents / Resources

	<p>KM SVS 2000 Weight Controller Indicator [pdf] User Manual SVS 2000 Weight Controller Indicator, SVS 2000, Weight Controller Indicator, Controller Indicator, Indicator</p>
---	---

References

-  [Weight Sensors, Controllers & Data Management Devices | Kistler-Morse](#)