

LG BP350 Blu-Ray Disc Player with Streaming Services and Built-In Wi-Fi User Manual

Home » LG » LG BP350 Blu-Ray Disc Player with Streaming Services and Built-In Wi-Fi User Manual

LG BP350 Blu-Ray Disc Player with Streaming Services and Built-In Wi-Fi User Manual





CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DONOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

WARNING: Do not install this equipment in a confined space such as a book case or similar unit.

CAUTION: Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

CAUTION: No naked flame sources, such as lighted candles, should be placed on the apparatus.

CAUTION: Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.



CAUTION: This product employs a Laser System. To ensure proper use of this product, please read this owner's manual carefully and retain it for future reference. Shall the unit require maintenance, contact an authorised service centre.

Use of controls, adjustments or the performance of procedures other than those specified herein may result in hazardous radiation exposure.

To prevent direct exposure to laser beam, do not try to open the enclosure.

CAUTION concerning the Power Cord

The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.

CAUTION: The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.

NOTICE: For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product.

CAUTION: Only use the AC adapter supplied with this device. Do not use a power supply from another device or another manufacturer. Using any other power cable or power supply may cause damage to the device and void your warranty

For models using a battery

This device is equipped with a portable battery or accumulator.

CAUTION: Risk of fire or explosion if the battery is replaced by an incorrect type.

How to Safely remove the batteries or the battery pack from the equipment: To Remove the old batteries or battery pack, follow the assembly steps in reverse order.

To prevent contamination of the environment and bring on possible threat to human and/or animal health, the old batteries or the battery pack must be put in an appropriate container at designated collection points. Do not dispose of batteries or battery pack together with other waste. It is recommended that you use local, free reimbursement systems batteries or battery packs, (may not be available in your area). The batteries or the battery pack should not be exposed to excessive heat such as sunshine, fire or the like.

POWER: This unit operates on a mains supply of $200 - 240 \text{ V} \sim 50 / 60 \text{ Hz}$.

Wiring: This unit is supplied with a BS 1363 approved main plug. When replacing the fuse, always use a fuse of the same rating and approved to BS 1362. Never use this plug with the fuse cover omitted. To obtain a replacement fuse cover contact your dealer. If the type of plug supplied is not suitable for the mains sockets in your home, then the plug should be removed and a suitable type fitted. Please refer to the wiring instructions below:

Warning: A mains plug removed from the mains lead of this unit must be destroyed. A mains plug with bared wires is hazardous if inserted in a mains socket. Do not connect either wire to the earth pin, marked with the letter E or with the earth symbol 6 or colored green or green and yellow.

If any other plug is fitted, use same rating of fuse in the plug.

Important: The wires in this mains lead are coloured in accordance with the following codes:

- BLUE: NEUTRAL, BROWN: LIVE – As the colours of the wires in the mains lead of this unit may not correspond with the coloured marking identifying the terminals in your plug, proceed as follows: The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

Contents

- 1 Disposal of your old appliance
 - 1.1 Disposal of waste batteries/accumulators
- 2 Symbols
- 3 What's in the box?
- **4 Product Overview**
- **5 TV Connection**
- 6 Home Menu
- 7 Additional Information
- 8 Replacement of battery
- 9 OPEN SOURCE SOFTWARE NOTICE

INFORMATION

- 10 Technology with the human touch GUARANTEE
- 11 Documents / Resources
 - 11.1 References
- **12 Related Posts**

Disposal of your old appliance



1.


This crossed-out wheeled bin symbol indicates that waste electrical and electronic products (WEEE) should be disposed of separately from the municipal waste stream.

2. Old electrical products can contain hazardous substances so correct disposal of your old appliance will help

prevent potential negative consequences for the environment and human health. Your old appliance may contain reusable parts that could be used to repair other products, and other valuable materials that can be recycled to conserve limited resources.

3. You can take your appliance either to the shop where you purchased the product, or contact your local government waste office for details of your nearest authorised WEEE collection point. For the most up to date information for your country please see www.lg.com/global/recycling.

Disposal of waste batteries/accumulators



This symbol may be combined with chemical symbols for mercury (Hg), cadmium (Cd) orlead (Pb) if the battery contains more than 0.0005% of mercury, 0.002% of cadmium or 0.004% of lead.

- 2. All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 3. The correct disposal of your old batteries/accumulators will help to prevent potential negative consequences for the environment, animal and human health.
- 4. For more detailed information about disposal of your old batteries/ accumulators, please contact your city office, waste disposal service or the shop where you purchased the product.
 (http://www.lg.com/global/sustainability/environment/take-back-recycling/global-networkeurope)

Symbols


~	Refers to alternating current (AC).	
===	Refers to direct current (DC).	
	Refers to class II equipment.	
(1)	Refers to stand-by.	
I	Refers to "ON" (power).	
3	Refers to dangerous voltage.	

What's in the box?




Product Overview

Front Panel



- Disc Tray Open / Close
- Power On / Off
- USB Port: Connect a USB device.


Rear Panel



- DC IN 12 V = = 0 1 A: Connect to AC Adaptor.
- HDMI OUT (TO TV): Connect to TV.

TV Connection


1. Connect the HDMI jack on the player to the HDMI jack on the TV using a HDMI cable.



- 2. Set the input selector to HDMI on the TV.
- 3. Follow the instructions on the TV screen using remote control.

Home Menu


After initial setup, Home menu appears on the TV screen. Enjoy various functions on the player.



Additional Information

AC adapter	 Model: WA-12M12FK Manufacturer: Asian Power Devices Inc. Input: 100 -240 V~, 50 – 60 Hz 0.5 A Max. Output: 12 V = 0 1 A Model: AD2071200 Manufacturer: PI ELECTRONICS Input: 200 – 240 V~, 50 / 60 Hz 0.2 A Max 			
	• Output : 12 V = = 0 1 A			
Standby power consumption	0.5 W			
Dimensions (W x H x D)	Approx. 270 mm x 43 mm x 195 mm			
Bus Power Supply (USB)	5 V === 0 500 mA			
Design and specifications are subject to change without notice.				

Replacement of battery



OPEN SOURCE SOFTWARE NOTICE INFORMATION

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit http://opensource.lge.com.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com. This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

Technology with the human touch GUARANTEE

LG Electronics U.K. Ltd. will provide the following services in order to expedite this Guarantee.

- 1. All faulty components which fail due to defective manufacture will be replaced free of charge for a period of 12 months from the original date of purchase.
- 2. The dealer (or his service agent) who sold the product will be reimbursed for any labour provided in the repair of this LG equipment, for a period of 12 months from the original date of purchase. These claims must be made in accordance with the published scale of service charges and relevant claims procedure.

PLEASE NOTE:

- 1. The dealer may restrict the guarantee to the original purchaser.
- 2. The dealer is not obliged to carry out service under guarantee if unauthorised modifications are made to the apparatus, or if non standard components are used or if the serial number of the apparatus is removed, defaced, misused, or altered.

- 3. Any claims made under guarantee must be directed to the dealer from whom the equipment was originally purchased.
 - The dealer may, before carrying out service under guarantee, require a receipted account as evidence of the date of purchase.
- 4. We respectfully point out that your dealer is not obligated to replace batteries if they become exhausted or worn in use.
- 5. Aerial alignment and consumer control adjustments are not covered by this guarantee. This guarantee does not affect your statutory rights.
 - REQUIREMENTS TO MAINTAIN WARRANTY COVERAGE: RETAIN YOUR RECEIPT TO PROVE DATE
 OF PURCHASE. A COPY OF YOUR RECEIPT MUST BE SURRENDERED AT THE TIME GUARANTEE
 SERVICE IS PROVIDED.
 - Product Registration Card:
 It is helpful to complete at least your name, address, phone, model & serial numbers and return it. This will enable LG to assist you in the future should you lose your receipt, your units be stolen, or should modifications be necessary.
 - To obtain information or assistance: Call UK: 0344 847 5454 IE: 01 686 9454

MODEL NO.*	SERIAL NO.*	DATE OF PURCHASE.*

In all cases of difficulty – consult your LG dealer from whom the product was purchased LGEUK Website : www.lg.com/uk

(Service website : www.lg.com/uk/support)



Documents / Resources



LG BP350 Blu-Ray Disc Player with Streaming Services and Built-In Wi-Fi [pdf] User Manu al

BP350, Blu-Ray Disc Player with Streaming Services and Built-In Wi-Fi

References

- <u>Q LG Open Source</u>
- Use LG Electronics & Home Appliances | Shop Now | LG USA
- © Consumer & Home Electronics from LG | LG UK
- Get Product Help & Support | LG U.K. Support

