

LG ON9 Mini Hi-Fi Audio System Owner's Manual

Home » LG » LG ON9 Mini Hi-Fi Audio System Owner's Manual

LG ON9 Mini Hi-Fi Audio System Owner's Manual




Contents

- 1 What's In The Box
- 2 Top panel
- 3 Front panel / Rear panel
- **4 Additional Information**
- **5 Safety**
- 6 Disposal of your old appliance
- **7 Declaration of Conformity**
- 8 Symbols
- **9 GUARANTEE**
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts

What's In The Box



Top panel



1. (Standby)

Turns the power on or off

- 2. USB REC / DEMO
 - 1. Records to USB.
 - 2. Stops recording.
 - 3. In power off status, if you press USB REC / DEMO , show demo mode.

3. USB 1 Port

You can play sound files by connecting the USB device.

- 4. Display window
- 5. USB 2 Port

You can play sound files by connecting the USB device.

6. F (Function)

Selects the function and input source

7. LIGHTING

Selects the lighting mode.

8. 🕀 TWIN

Connects two units for TWIN mode in WIRELESS PARTY LINK.

- 9. KI/NN (Skip/Search)
 - Skips backward or forward.
 - · Searches for a section within a track/file.
 - · Selects the radio stations.
 - · Scans DAB+ stations by pressing and holding.

M(Play/Pause)

- Starts or pauses playback. Selects stereo/mono.
- Bluetooth connection lock (BT LOCK): Select the Bluetooth function by pressing F repeatedly. And long press to limit Bluetooth connection to only BT and LG TV.

□(Stop) / RDS

- Stops playback or cancels DELETE function.
- · Radio Data System

VOL (Volume) -/+

Adjusts speaker volume.

MIC (Microphone) / GUITAR -/+

Adjusts Microphone volume or Guitar volume.

10. (Auto Music Play)

Plays the audio currently playing by tagging the mobile (with "LG XBOOM" App) to this unit. (Android Only)

11. VOICE CANCELLER

You can reduce the vocal tones during music playback from various input sources.



Opens and closes the disc tray

12. CLUB, DRUM, USER (DJ PAD)

Selects CLUB, DRUM or USER sound effect to mix. (If you want to use USER, you have to register a source with "LG XBOOM" app. (Android Only))

- 1, 2, 3 (DJ PAD) Press a desired sound pad.
- 13. MIC (Microphone) ECHO

Selects ECHO mode.

VOCAL EFFECTS

Selects various vocal effects mode.

KEY CHANGER (b/#) Changes the key to suit your vocal range.

- 14. Remote sensor
- 15. SPECIAL EQ / BASS BLAST (or BASS BLAST+)
 - · Chooses special equalizer.
 - Press and hold to select BASS (or BASS+) effect directly

SEARCH Moves to folder or file in selection mode.


OK Selects a folder when searching a file.


USER EQ Selects the equalizer created by your own.

Multi jog

- · Searches a folder or a file.
- Turns clockwise or counterclockwise to control the USER EQ level.
- · Chooses special equalizer.

Front panel / Rear panel





- 1. Disc tray
- 2. Lighting
- 3. Remote sensor
- 4. OPTICAL IN: Connect an optical device.
- 5. GUITAR IN: Connect a guitar.
- 6. MIC (Microphone) IN: Connect a microphone.
- 7. DAB+/FM ANTENNA
- 8. AC IN socket

Make sure to properly align and connect the optical cable; improper alignment may cause damage to the jack.


Controller App



Download the LG XBOOM App to your device.

LG Sound Sync

For more information, download the online owner's manual. http://www.lg.com



Additional Information

Specifications

Power Requirements	Refer to the main label on the unit.
Power Consumption	Refer to the main label on the unit.
	Networked standby : 0.5 W (If all network ports are activated.)
Dimensions (W x H x D	Approx. 330.0 mm x 1,056.0 mm x 368.0 mm
Bus Power Supply (USB)	5 V === 500 mA

Design and specifications are subject to change without notice.

Caution

- Connect the power cord to wall outlet directly if possible. Or when you use an extension cable, it is highly
 recommended to use an extension cable of 110 V / 15 A or 230 V / 15 A, otherwise the unit may not operate
 properly because of the lack of power supply.
- Do not overload the extension cord with excessive electrical load.


Note

- Do not look directly at the light emitting part when the LIGHTING is turned on.
- If the illumination brightness is glaring, switch on the room lights or turn off the LIGHTING of the unit.

How to disconnect the wireless network connection or the wireless device

Turn off the unit by pressing the power button for more than 5 seconds

Replacement of battery



Safety





This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

WARNING: Do not install this equipment in a confined space such as a book case or similar unit.

CAUTION: Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

CAUTION: No naked flame sources, such as lighted candles, should be placed on the apparatus.



CAUTION: This product employs a Laser System. To ensure proper use of this product, please read this owner's manual carefully and retain it for future reference. Shall the unit require maintenance, contact an authorised service centre. Use of controls, adjustments or the performance of procedures other than those specified herein may result in hazardous radiation exposure. To prevent direct exposure to laser beam, do not try to open the enclosure.

CAUTION: Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a builtin installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.

CAUTION concerning the Power Cord The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.

CAUTION: The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.

NOTICE: For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product.

For models using a battery

This device is equipped with a portable battery or accumulator

CAUTION: Risk of fire or explosion if the battery is replaced by an incorrect type.

How to Safely remove the batteries or the battery pack from the equipment: To Remove the old batteries or battery pack, follow the assembly steps in reverse order. To prevent contamination of the environment and bring on possible threat to human and/or animal health, the old batteries or the battery pack must be put in an appropriate container at designated collection points. Do not dispose of batteries or battery pack together with other waste. It is recommended that you use local, free reimbursement systems batteries or battery packs, (may not be available in your area). The batteries or the battery pack should not be exposed to excessive heat such as sunshine, fire or the like

POWER: This unit operates on a mains supply of $200 - 240 \text{ V} \sim 50 / 60 \text{ Hz}$

Wiring: This unit is supplied with a BS 1363 approved main plug. When replacing the fuse, always use a fuse of the same rating and approved to BS 1362. Never use this plug with the fuse cover omitted. To obtain a replacement fuse cover contact your dealer. If the type of plug supplied is not suitable for the mains sockets in your home, then the plug should be removed and a suitable type fitted. Please refer to the wiring instructions below:

Warning: A mains plug removed from the mains lead of this unit must be destroyed. A mains plug with bared wires is hazardous if inserted in a mains socket. Do not connect either wire to the earth pin, marked with the letter E or with the earth symbol 6 or coloured green or green and yellow. If any other plug is fitted, use same rating of fuse in the plug.

Important: The wires in this mains lead are coloured in accordance with the following codes:

BLUE: **NEUTRAL**, **BROWN**: LIVE – As the colours of the wires in the mains lead of this unit may not correspond with the coloured marking identifying the terminals in your plug, proceed as follows: The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

Disposal of your old appliance

- 1. This crossed-out wheeled bin symbol indicates that waste electrical and electronic products (WEEE) should be disposed of separately from the municipal waste stream.
- 2. Old electrical products can contain hazardous substances so correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health. Your old appliance may contain reusable parts that could be used to repair other products, and other valuable materials that can be recycled to conserve limited resources.
- 3. You can take your appliance either to the shop where you purchased the product, or contact your local government waste office for details of your nearest authorised WEEE collection point. For the most up to date information for your country please see www.lg.com/global/recycling.

- 1. This symbol may be combined with chemical symbols for mercury (Hg), cadmium (Cd) or lead (Pb) if the battery contains more than 0.0005% of mercury, 0.002% of cadmium or 0.004% of lead.
- 2. All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 3. The correct disposal of your old batteries/accumulators will help to prevent potential negative consequences for the environment, animal and human health.
- 4. For more detailed information about disposal of your old batteries/ accumulators, please contact your city office, waste disposal service or the shop where you purchased the product.
 (http://www.lg.com/global/sustainability/ environment/take-back-recycling/global-networkeurope)

Declaration of Conformity

UK CA Hereby, LG Electronics declares that the radio equipment type MINI HI-FI AUDIO is in compliance with the relevant statutory requirements. The full text of the UK declaration of conformity is available at the following internet address: http://www.lg.com/global/support/cedoc/cedoc/#

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body

- Frequency range Output power (Max.)
- 2402 to 2480 MHz 10 dBm

Declaration of Conformity

C € Hereby, LG Electronics declares that the radio equipment type MINI HI-FI AUDIO is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

http://www.lg.com/global/support/cedoc/cedoc#

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

- Frequency range Output power (Max.)
- 2402 to 2480 MHz 10 dBm

Symbols

~	Refers to alternating current (AC)
===	Refers to direct current (DC
	Refers to class II equipment
(1)	Refers to stand-by.
	Refers to "ON" (power)
4	Refers to dangerous voltage

GUARANTEE

LG Electronics U.K. Ltd. will provide the following services in order to expedite this Guarantee.

- 1. All faulty components which fail due to defective manufacture will be replaced free of charge for a period of 12 months from the original date of purchase.
- 2. The dealer (or his service agent) who sold the product will be reimbursed for any labour provided in the repair of this LG equipment, for a period of 12 months from the original date of purchase. These claims must be made in accordance with the published scale of service charges and relevant claims procedure.

PLEASE NOTE:

- A. The dealer may restrict the guarantee to the original purchaser.
- B. The dealer is not obliged to carry out service under guarantee if unauthorised modifications are made to the apparatus, or if non standard components are used or if the serial number of the apparatus is removed, defaced, misused, or altered.
- C. Any claims made under guarantee must be directed to the dealer from whom the equipment was originally purchased. The dealer may, before carrying out service under guarantee, require a receipted account as evidence of the date of purchase.
- D. We respectfully point out that your dealer is not obligated to replace batteries if they become exhausted or worn in use.
- E. Aerial alignment and consumer control adjustments are not covered by this guarantee.

This guarantee does not affect your statutory rights.

- REQUIREMENTS TO MAINTAIN WARRANTY COVERAGE: RETAIN YOUR RECEIPT TO PROVE DATE OF PURCHASE. A COPY OF YOUR RECEIPT MUST BE SURRENDERED AT THE TIME GUARANTEE SERVICE IS PROVIDED.
- Product Registration Card:
 It is helpful to complete at least your name, address, phone, model & serial numbers and return it. This will enable LG to assist you in the future should you lose your receipt, your units stolen, or should modifications be

necessary.

To obtain information or assistance: Call UK: 0344 847 5454 IE: 01 686 9454

MODEL NO.* SERIAL NO.* DATE OF PURCHASE.*

In all cases of difficulty - consult your LG dealer from whom the product was purchased

LGEUK Website : www.lg.com/uk

(Service website : www.lg.com/uk/support)

To view the instructions of advanced features, visit http://www.lg.com and then download Owner's Manual. Some of the content in this manual may differ from your unit.



Documents / Resources



LG ON9 Mini Hi-Fi Audio System [pdf] Owner's Manual ON9, Mini Hi-Fi Audio System, Audio System

References

- **(b)** LG Electronics & Home Appliances | Shop Now | LG USA
- Global Take-Back Policy | Take-Back & Recycling | LG Global
- © Consumer & Home Electronics from LG | LG UK

Manuals+,