



ACKSYS DTUS0414 Modbus Firmware Ethernet And Wi-Fi Port Servers User Guide

[Home](#) » [Acksys](#) » ACKSYS DTUS0414 Modbus Firmware Ethernet And Wi-Fi Port Servers User Guide 

Contents

- [1 ACKSYS DTUS0414 Modbus Firmware Ethernet And Wi-Fi Port Servers](#)
- [2 Product Specifications](#)
- [3 Product Usage Instructions](#)
- [4 MODBUS / SERIAL OVERVIEW](#)
- [5 USING THE FIRMWARE IN SLAVE MODE](#)
- [6 COMMANDS REFERENCE LIST](#)
- [7 SETTING OR DISPLAYING THE GENERAL PARAMETERS](#)
- [8 Syntax in MASTER mode](#)
- [9 FAQs](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)



ACKSYS DTUS0414 Modbus Firmware Ethernet And Wi-Fi Port Servers



Product Specifications

- Product Name: MODBUS TCP Firmware User's Guide for Ethernet and Wi-Fi Port Servers
- Manufacturer: ACKSYS
- Address: ZA Val Joyeux 10, rue des Entrepreneurs, 78450 VILLEPREUX FRANCE
- Contact:
 - Telephone: +33 (0)1 30 56 46 46
 - Fax: +33 (0)1 30 56 12 95
 - Web: www.acksys.fr
 - Email Support: support@acksys.fr
 - Email Sales: sales@acksys.fr

Product Usage Instructions

When to Use the MODBUS Firmware

This embedded software allows any port server (wired or wireless) made by ACKSYS to be used as a gateway between a MODBUS TCP network and a MODBUS serial network. The MODBUS Gateway may operate in two modes:

1. Serial Master Mode (Client mode) when connected to one master MODBUS serial peripheral.
2. Serial Slave Mode (Server mode) when connected to slave MODBUS serial peripherals.

MODBUS / Serial Overview

MODBUS: Master/Slave communication protocol where one device (Master) controls serial activity by polling slave devices. Supports one master device and up to 247 slave devices with assigned addresses.

Transmission Media: Initially for serial asynchronous media like RS232, RS422, or RS485. MODBUS TCP firmware handles this on its serial port but can encapsulate frames in TCP/IP for Ethernet or radio transmission.

Modes of Transmission

ASCII Framing: Framing in ASCII mode uses the colon character to indicate the beginning of the frame and carriage return/line feed to delineate the end of the frame.

COPYRIGHT (©) ACKSYS 2009

This document contains information protected by Copyright. The present document may not be wholly or partially reproduced, transcribed, stored in any computer or other system whatsoever, or translated into any language or computer language whatsoever without prior written consent from ACKSYS Communications & Systems – ZA Val Joyeux – 10, rue des Entrepreneurs – 78450 VILLEPREUX – FRANCE.

REGISTERED TRADEMARKS

- ACKSYS is a registered trademark of ACKSYS.

NOTICE

- ACKSYS ® gives no guarantee as to the content of the present document and takes no responsibility for the profitability or the suitability of the equipment for the requirements of the user.
- ACKSYS ® will in no case be held responsible for any errors that may be contained in this document, nor for any damage, no matter how substantial, occasioned by the provision, operation or use of the equipment.
- ACKSYS ® reserves the right to revise this document periodically or change its contents without notice.

WHEN TO USE THE MODBUS FIRMWARE ?

This embedded software allows any port server (wired or wireless) made by ACKSYS to be used as a gateway between a MODBUS TCP network and a MODBUS serial network. The MODBUS Gateway may operate in two distinct modes, depending on the type of equipment connected to the serial line:

- With one master MODBUS serial peripheral, the port server operates in SERIAL MASTER MODE mode (also named "Client" mode).
- With slave MODBUS serial peripherals, the port server operates in SERIAL SLAVE MODE mode (also named "Server" mode).

MODBUS/TCP is a variant of the MODBUS family of simple, vendor-neutral communication protocols intended for supervision and control of automation equipment. Specifically, it covers the use of MODBUS messaging in an 'Intranet' or 'Internet' environment using the TCP/IP protocol. The most common use of the protocol at this time is for Ethernet attachment of PLC's, I/O modules, and 'gateways' to other simple field buses or I/O networks.

The MODBUS Applications Programming Interface for Network Communications, (MBAP), was developed by Modicon to allow traditional serial MODBUS communications to occur over a TCP/IP network. It basically defines a "wrapper" around the MODBUS protocol to accommodate routing data packets between two network nodes. The same master/slave messaging protocol is used, however the network aspect allows multiple master devices to access data from the same or different slave devices connected to the network. Using the Client/Server approach, a MODBUS/TCP slave device represents the server side of the communications model, accepting and responding to queries from one or more network client master applications.

MODBUS / SERIAL OVERVIEW

MODBUS

MODBUS is a Master/Slave communication protocol, whereby one device, (the Master), controls all serial activity by selectively polling one or more slave devices. The protocol provides for one master device and up to 247 slave devices on a common line. Each device is assigned an address to distinguish it from all other connected devices. Only the master initiates a transaction. Transactions are either a query/response type, (only a single slave is address), or a broadcast/no response type, (all slaves are addressed). A transaction comprises a single query and single response frame or a single broadcast frame.

Transmission media

MODBUS was initially devised to work on serial asynchronous media like RS232, RS422 or RS485. This is the kind of media that the MODBUS TCP firmware handles on its serial port. However the MODBUS frames can be transmitted through other media like Ethernet or radio; in this case the MODBUS frame must be encapsulated in the frame of the specific media. On its network port, the MODBUS TCP firmware encapsulates MODBUS frames in

TCP/IP frames to handle the specific addressing of devices on this medium. The following descriptions apply to the serial asynchronous media.

Modes of transmission

The mode of transmission is the structure of the individual units of information within a message, and the numbering system used to transmit the data. Two modes of transmission are available for use in a serial MODBUS system. Both modes provide the same capabilities for communicating with PLC slaves; the mode is selected depending on the equipment used as a MODBUS Master. One mode must be used per MODBUS system; mixing of modes is not allowed.

The modes are ASCII (American Standard Code for Information Interchange), and RTU, (Remote Terminal Unit.) The characteristics of the two transmission modes are defined below:

ASCII Framing

Framing in ASCII transmission mode is accomplished by the use of the unique colon, (:), character to indicate the beginning of frame and carriage return/line feed, (CRLF), to delineate end of frame. The line feed character also serves as a synchronizing character which indicates that the transmitting station is ready to receive an immediate reply.

BEGIN FRAME	ADDRESS	FUNCTION	DATA	ERROR CHECK	EOF	READY TO RECEIVE
:	2-CHAR 16-BITS	2-CHAR 16-BITS	N X 4-CHAR N X 16-BITS	2-CHAR 16-BITS	CR	LF

RTU Framing


Frame synchronization can be maintained in RTU transmission mode only by simulating a synchronous message. The receiving device monitors the elapsed time between receipts of characters. If three and one-half character times elapse without a new incoming character, then the frame received is considered terminated: the receiving device checks the CRC (last two characters received) to determine frame validity, and assumes that the next byte received will be an address. A frame is also considered completed when 256 characters have been received.

Note: for practical purposes, the three and one-half character time is usually rounded up to four characters time.

T1,T2,T3,T4	ADDRESS	FUNCTION	DATA	CHECK	T1,T2,T3,T4
	8-BITS	8-BITS	N X 8-BITS	16-BITS	

USING THE FIRMWARE IN SLAVE MODE

The SLAVE mode, also called “Server” mode, is used when the Modbus Slave devices are located on the serial link of the Port server. The Master is then a Modbus TCP device, located on the network side of the Port server. The port server acts as a gateway between the networked Modbus TCP master device and serial Modbus slave devices.



The port server gateway converts and transfers requests from the TCP clients towards the serial line, then wait for an answer and sends it back to the client. As the serial line may support several bussed slave Modbus peripherals, these ones are distinguished on the serial link by their own unique Modbus address. Therefore, on TCP side, the client application identifies each serial peripheral by its Modbus address and the IP address of the port server gateway.

Nevertheless, if the TCP client has not the possibility to specify the Modbus address of the slave device, the latter may be forced by the port server gateway, allowing the client to identify the slave device only by its IP address. In this case, the slave device must be unique on the serial link.

With firmware versions 2.0.0.0 and above, up to five simultaneously opened connections are allowed. Upon reception of a sixth connection request, the oldest unused connection is automatically closed. The port server gateway handles only one transaction at a time. It can memorize one additional request from the network, which will be sent to the serial line after completion of the current transaction (answer from the serial peripheral or time out). The delay allocated to the serial peripheral's answer, called "Time Out" delay, is defined in the administration menu discussed later in this documentation (command "stout").

If the slave device fails to respond to a Modbus request, at expiration of the time out the gateway merely cancels the transaction: no answer is returned to the TCP client, so it can likewise fall in time out. Therefore, the TCP client time out value must be slightly higher than the gateway time out configured by command "stout". Optionally, and if handled by the TCP client, the gateway can return Modbus exception 11 (0xB) in case of response failure from a slave device. This exception, defined by Modbus TCP specifications, is specific to gateways, and may be activated using command "exception".

An access control option may be activated to forbid device accessibility to unauthorized clients: use command "authip" to define a list of authorized IP addresses. In Slave mode, the port server gateway listens by default Modbus TCP registered port 502. Nevertheless, another port can be configured, for compatibility with some non-standard applications, by the mean of command "mdbport".

(Slave devices on the Port server serial link)

The following parameters must be checked in Slave mode. All these parameters can also be changed with the browser interface (Network serial port servers administration software).

- Network parameters (IP address, IP gateway, netmask, DHCP...)
- On WiFi models, WiFi parameters (SSID, channel, infrastructure/ad-hoc, keys...)

- Serial parameters (baud rate, electrical interface...)

please note: the “slave” and “master” submodes of the RS422 interface are NOT related to the “slave” and “master” roles in MODBUS. Please refer to the “set serial interface” command for details.

- Parameters specific to the Modbus Slave mode:

- Firmware

download and/or activate the MODBUS firmware (see product user’s guide or quick start guide).

- Device Mode

command: set serial mode slave

- Modbus Mode

Either command: set serial mode rtu Or command: set serial mode ascii

- Response time out

command: set serial stout nnnn

- Seldom used parameters:

- These parameters should be changed only in special cases. See the command list for details.

- command: set net slaveid nn

- command: set net exception on / off

- command: set net authip [IP Address]

- command: set net mdbport nnnn

- command: set net metric nn

- Debugging parameter


command: set serial nocheck on / off

This command allows to suppress integrity control of serial frames received from a slave device. When activated, frame length and CRC control are disabled, and data is returned “as is” to the TCP client, without any error warning. Serial nocheck should only be used for debugging purposes.

More parameters are available. See the product user’s guide or the quick start guide.

USING THE FIRMWARE IN MASTER MODE USING THE FIRMWARE IN MASTER MODE

In this mode, also called “Client” mode, the MODBUS master equipment is connected on the serial link, and the MODBUS port server gateway acts as a proxy for the networked slaves, capturing requests from the master, sending them to the networked slaves when appropriate, waiting for answers and retransmitting them to the serial master. If other slave MODBUS peripherals are present on the serial bus, they are not accessible from the network. Every request issued by the master toward slave TCP devices must be acknowledged by an answer in a predefined delay, configurable through the administration menu (command “tcpto”).



The Master on the serial line doesn't know the network address of the slave devices that it interrogates: those are identified on the serial side by an unique MODBUS address. A translation table in the administration menu establishes the correspondence between the MODBUS serial addresses and the corresponding IP addresses.

In the case of a distant server managing itself several slave serial devices, these last are also identified by their own MODBUS address. The configuration table of the port server gateway offers the possibility to establish a correspondence between the MODBUS address known by the master equipment on the port server serial link, and the distant slave address used on the remote Server serial link. For example, serial MODBUS address range 1 to 8, scanned by the Master, may be assigned to addresses 31 to 38 ('unit identifier' field of the MODBUS TCP frame) on the remote slave serial link.

The port server gateway can manage simultaneously up to 5 active connections, each of these connections capable to give access to up to 247 slave devices (on the same IP address). If the number of servers to interrogate (different IP addresses) is greater than 5, the oldest connection is closed when the master gives out the sixth connection request.

In Master mode, the port server gateway requests connections to remote server on the TCP registered port 502. It is however possible to define a different TCP port for connection to non-standard equipments.
MASTER mode configuration summary

(Modbus Master device is on the port server serial link)

The following parameters must be checked in Master mode. All these parameters can also be changed with the browser interface (Network serial port servers administration software).

- Network parameters (IP address, IP gateway, netmask, DHCP...)
- On WiFi models, WiFi parameters (SSID, channel, infrastructure/ad-hoc, keys...)
- Serial parameters (baud rate, electrical interface...)

please note: the "slave" and "master" submodes of the RS422 interface are NOT related to the "slave" and "master" roles in MODBUS. Please refer to the "set serial interface" command for details.

- Parameters specific to the Modbus Master mode:

- Firmware

download and/or activate the MODBUS firmware (see product user's guide or quick start guide).

- Device Mode

command: set serial mode master (because your serial device is a master)

- Modbus Mode

Either command: set serial mode rtu Or command: set serial mode ascii

- Serial / Network address assignment command: set net slaveid [...]
- Response time out

command: set net tcpto nnnn

- Seldom used parameters:

- These parameters should be changed only in special cases. See the command list for details.
- command: set net mdbport nnnn
- command: set net metric nn

COMMANDS REFERENCE LIST

Displaying the configuration parameters is allowed if the “showperm” parameter is set to “allow”. If set to “deny”, the configuration parameters can only be displayed by the administrator after logging in. Some parameters can only be displayed for your information but cannot be changed.

Conventions used in these tables

- bold text must be typed as is.
- italicized text denotes a parameter which must be replaced by the proper value.
- italicized bold text denotes warnings or limitations.

Tables

- general parameters
- network parameters
- wireless parameters
- serial parameters
- parameters available only for the “WLg” products range
- notes

SETTING OR DISPLAYING THE GENERAL PARAMETERS

Command			Default value	Notes	Description
login	<i>username</i>				start the administrator identification sequence. Ask password.
set	default				restore factory defaults, except the MAC address, the save count, the current firmware and the next firmware to run.
save					save the current configuration to the permanent configuration memory which is used after reboot and remains when the device is powered off.
reset					close the administration session and reboot the device, to ignore parameters changed but not saved, or to reload saved parameters. The following parameters do not need a reset to take effect: location, showperm, netconfigperm, serial interface.
show	version				display firmware name and version
quit					close administration session (TELNET only).
set	login	<i>Username</i>	root		change/display administrator username. 8 bytes max. Upper and lower cases.
set	password	<i>Password</i>	root		change/display administrator password. 8 bytes max. Upper and lower cases.
set	location	<i>Location</i>	"Unknown location"		change/display <i>location</i> description of the device server. 30 bytes max. Upper and lower cases.
set	showperm	<i>perm</i>	allow		change/display the right to display configuration information without entering the administrator password. <i>perm</i> : one of allow / deny
set	netconfigperm	<i>perm</i>	allow		change/display the right to use the administration system from the network. <i>perm</i> : one of allow / deny
set	upgradeperm	<i>perm</i>	allow		change/display the right to upgrade the firmware. <i>perm</i> : one of allow / deny If this flag is set to " allow ", upgrade is allowed. (through serial port or Wifi interface) else upgrade is not allowed. These commands are not available for devices providing several firmwares simultaneously.
set	prog enable	<i>seg</i>	MODBUS firmware located in seg /4		execute after next reset the current firmware located in segment <i>seg</i> .
show	prog list				display information about all firmwares.
show	prog info	<i>seg</i>			display information about firmware located in segment <i>seg</i> , in computer readable format.
show	prog data	<i>seg</i>			display information about firmware located in segment <i>seg</i> , in computer readable format.

SETTING OR DISPLAYING THE NETWORK PARAMETERS

Command			Default value	Notes	Description
show	net ethernet		Factory defined		display Ethernet MAC address. 6 hex digits separated by columns.
set	net dhcp	<i>state</i>	off		turn on / off or display the DHCP client use. When dhcp is on, the manually specified IP address is not used.
set	net dhcp clientid	<i>ident</i>	empty (MAC address sent as string)		replace the default client ID (MAC address as a string) by the custom string <i>ident</i> . 15 bytes max, upper and lower cases allowed.
set	net dhcp clientid				delete the custom client ID and use the default client ID.
show	net dhcp clientid				display custom client ID.
set	net dhcp hname	<i>hostname</i>	empty (not sent)		provide the DHCP server with the supplementary Host Name option, with value <i>hostname</i> . 19 bytes max, no spaces allowed, upper and lower cases allowed.
show	net dhcp hname				Value assigned to DHCP option 12, if any.
set	net ip	<i>aaa.bbb.ccc.ddd</i>	192.168.1.253		change/display IP address in dotted decimal notation.
show	net ip				
set	net mask	<i>aaa.bbb.ccc.ddd</i>	255.255.255.0		change/display local subnet mask
show	net mask				
set	net gateway	<i>aaa.bbb.ccc.ddd</i>	0.0.0.0		change/display the gateway IP address.
show	net gateway				
set	net metric	<i>mmm</i>	64 ("WLG")		change/display the number of gateway hops. mmm is 1 to 255
show	net metric		10 (others)		
show	net configport		23		administration port
set	net authip	<i>n aaa.bbb.ccc.ddd</i>	Table cleared. (access control disabled)		<i>n</i> : table entry index, from 1 to 8 . <i>aaa.bbb.ccc.ddd</i> : IP address of a host allowed to act as a Modbus master toward this device. IP address 0.0.0.0 clears the entry.
show	net authip				
set	net mdbport	<i>nnnn</i>	502		In SLAVE mode, <i>nnnn</i> define the local TCP port server the gateway will listen to in place of registered port 502 .
show	net mdbport				In MASTER mode, <i>nnnn</i> define the remote TCP port server gateway will use in place of registered port 502 to establish a connection with a server.
set	net tcpto	<i>nnnn</i>	800		Supported in MASTER mode only. <i>nnnn</i> gives the time imparted for a transaction to complete, in ms (max 65535 ms). This is the maximum time during which the port server gateway will wait for an answer from the distant peripheral.
show	net tcpto				
set	net exception	<i>state</i>	off		Turn on / off handling of exception 11 (0xB) when slave device fails to respond.
show	net exception				

Syntax in SLAVE mode

Command			Default value	Notes	Description
set	net slaveid	<i>sa</i>	0		<i>sa</i> : MODBUS serial address (local)
show	net slaveid				This command may be used only if no more than one MODBUS slave device is connected over the serial link. It allows to impose the MODBUS serial address for every incoming TCP request: in this case, the corresponding field of the modbus TCP frame (unit ID) is purely and simply ignored, and the slave device is identified by the client only through its IP address. For example, if the address of the modbus serial device connected to the port server serial link is 5, the command set net slaveid 5 will assure that any requests from a TCP client connected to the port server will be transferred to the device with the correct address, independently of the unit ID specified by the TCP frame. Programming the fixed serial address to zero will disable this functionality, so that the serial address passed to MODBUS serial devices is the unit ID specified by the TCP frame.

Syntax in MASTER mode

Syntax in MASTER mode

Command			Default value	Notes	Description
set	net slaveid	<i>fs ls fr m xx.xx.xx.xx</i>	0 0 0 0 0.0.0		<p><i>fs</i> : first MODBUS serial address (local) <i>ls</i> : last MODBUS serial address (local) <i>fr</i> : first MODBUS TCP ID field (remote serial address) <i>m</i> : Mode : 0 = last byte of IP address fixed 1 = last byte of IP address variable <i>xx.xx.xx.xx</i> : Remote device IP address</p> <p>This command defines the correspondence between MODBUS local serial addresses (<i>fs</i> to <i>ls</i>) and remote IP addresses (<i>xx.xx.xx.xx</i>), as well as remote address (<i>fr</i>) conveyed by the ID field of MODBUS TCP frames. Up to eight ranges can be defined.</p> <p>The <i>m</i> parameter (mode), when set to 0, indicates that the destination IP address is fixed for the whole range concerned; in this case, remote devices are identified by their serial address, calculated from parameter <i>fr</i>. If <i>mode</i> is set to 1, the last byte of the IP address will change according to the offset from the first local address. In this case, if the unit identifier field of TCP frames is not used, parameter <i>fr</i> can be set to 0 (TCP unit identifier will be set to 0xFF in this case).</p> <p>Observation : any slaveid command line with an <i>fs</i> parameter included in a range already defined will invalidate and replace the oldest. <i>fs</i> = 0 clears the whole table.</p> <p>Examples :</p> <pre>set net slaveid 1 8 1 0 192.168.0.30 set net slaveid 9 16 0 1 192.168.20.0 set net slaveid 17 24 31 1 192.168.50.0</pre> <p>The first line defines redirection of local serial addresses 1 to 8 to the single IP address 192.168.0.30 (mode = 0), without conversion: Local slave #1 directed to IP 192.168.0.30 ID field = 1 Local slave #4 directed to IP 192.168.0.30 ID field = 4 Local slave #8 directed to IP 192.168.0.30 ID field = 8 The second line defines redirection of local serial addresses 9 to 16 to respective IP addresses 192.168.20.0 to 192.168.20.7 (mode = 1). Parameter <i>fr</i> set to zero means TCP ID field set to 0xFF : Local slave #9 directed to IP 192.168.20.0 ID field = 0xFF Local slave #12 directed to IP 192.168.20.3 ID field = 0xFF Local slave #16 directed to IP 192.168.20.7 ID field = 0xFF The third line defines redirection of local serial addresses 17 to 24 to respective IP addresses 192.168.50.0 to 192.168.50.7, with respective TCP ID fields 31 to 38 : Local slave #17 directed to IP 192.168.50.0 ID field = 31 Local slave #19 directed to IP 192.168.50.2 ID field = 33 Local slave #24 directed to IP 192.168.50.7 ID field = 38</p>
show	net slaveid				
Command			Default value	Notes	Description
set	net ssid	<i>ssid</i>	acksys		change/display the SSID of the device. SSID is a case sensitive characters string (32 characters max). Empty character string is not allowed.
show	net ssid				
set	net mode	<i>mode</i>	Ad-hoc ("WLG") Infra (others)		configure/display the WIFI mode. One of ad-hoc or infra . ad-hoc : configure the device in AD-HOC mode . Infra : configure the device in infrastructure mode.
show	net mode				
set	net channel	<i>channel</i>	6		In ad-hoc mode, configures the radio channel used for communication with the other device. <i>channel</i> is in the range 0 to 13. In infrastructure mode this parameter is ignored.
show	net channel				
set	net wepkey	<i>keynum key</i>	no default value		define up to 4 WEP keys. <i>keynum</i> is the key number. Range 1 to 4. <i>key</i> is the hexadecimal key value. 10 digits (64 bits key) or 26 digits (128 bits key). The last 6 digits are generated by the firmware Example : set 64 bits WEP key : set net wepkey 1 1F2564AE12 set 128 bits WEP key : set net wepkey 1 123654875ADFEC236542541A26 Note : to enter a 128 bits WEP key, you must before enable 128 bits key mode. See command "set net usekey 1 128" below.
set	net wepkey	<i>keynum 0</i>			delete wepkey <i>keynum</i>
show	net wepkey				display all 4 WEP keys (the last 6 digits are displayed as zeroes).
set	net usekey	<i>[keynum] [128]</i>			define the WEP key to use. If the <i>keynum</i> parameter is left empty, device won't use any WEP key, else device uses WEP key <i>keynum</i> . Example : Activate 64 bits WEP key set net usekey 1 Activate 128 bits WEP key set net usekey 1 128 Disable WEP key using set net usekey
show	net usekey				
set	net auth	<i>mode</i>	open		set the authentication mode. <i>mode</i> is one of open , share open : the device is authenticated by its MAC address. share : the device is authenticated by its WEP Key. This command is not valid for WL-COMETH I.
show	net auth				
Command			Default value	Notes	Description
set	net unencrypted	<i>mode</i>	Ignore (WLG-range) Accept (other products)		configure if the device accept or ignore the unencrypted WIFI packet. <i>mode</i> is one of ignore or accept ignore : The device ignores all WIFI packet unencrypted accept : The device accepts all WIFI packet unencrypted This command is not valid for WL-COMETH I.
show	net unencrypted				
set	net txrate	<i>txrate</i>	automatic		set the WIFI transmit rate. <i>txrate</i> is one of 1, 2, 5.5, 11, automatic. 1, 2, 5.5 or 11: device will always use the given transmit rate. automatic : device will automatically choose the appropriate transmit rate.
show	net txrate				
show	net wlan				Display WIFI parameters: channel, txrate, authentication mode, RF signal quality. authentication mode is not displayed for WL COMETH I. "WLG" products also display available access points around.

SETTING OR DISPLAYING THE SERIAL PARAMETERS

Command			Default value	Notes	Description
set	serial interface	<i>mode [option]</i>	rs232		<p><i>mode</i> : one of rs232/rs422/4wires/rs485/2wires</p> <p><i>option</i> : master or slave for rs422 / 4wires mode, noecho or echo for rs485 / 2wires mode</p> <ul style="list-style-type: none"> On some products, only "rs232" is meaningful. Other choices will result in communication errors. See the serial port specifications of the appropriate port server user manual. Keywords "rs422" and "4wires" are synonyms. Their meaning is identical. Keywords "rs485" and "2wires" are synonyms. Their meaning is identical. <p>rs232 : setting for rs232 serial interface equipment</p> <p>rs422 master or 4wires master : setting for master equipment in multidrop, configuration or for both equipments in point to point configuration</p> <p>rs422 slave or 4wires slave : setting for slave in multidrop configuration.</p> <p>rs485 noecho or 2wires noecho : setting for all devices in multidrop or point to point.</p> <p>rs485 echo or 2wires echo : setting for all equipments in multidrop or point to point configuration. In this mode, transmitted characters on RS485 line are echoed on Lan line.</p>
set	serial dtr	<i>mode</i>	high		<p>DTR management. <i>mode</i> is one of modem/high/low.</p> <p>modem means the signal is used as if a modem was connected to the port (DTR → the port server is on line, RTS → the port server wants to send data). Flow means the signal is used for input flow control.</p> <p>high and low mean the signal is permanently set in this state.</p>
set	serial rts	<i>mode</i>	high		<p>RTS management. <i>mode</i> is one of modem/high/low/flow.</p> <p>modem means the signal is used as if a modem was connected to the port (DTR → the device is on line, RTS → the device wants to send data).</p> <p>high and low mean the signal is permanently set in this state.</p> <p>Flow means the signal is used for input flow control.</p>
set	serial dsr	<i>mode</i>	ignore		<p>DSR management. <i>mode</i> is one of ignore/modem</p> <p>Ignore means that the signal is locally ignored.</p> <p>modem means the signal is used as if a modem was connected to the port (DTR → the port server is on line, RTS → the port server wants to send data).</p>
set	serial cts	<i>mode</i>	ignore		<p>CTS management. <i>mode</i> is one of ignore/modem/ flow</p> <p>ignore means that the signal is locally ignored.</p> <p>modem means the signal is used as if a modem was connected to the port (DTR → the port server is on line, RTS → the port server wants to send data).</p> <p>flow means the signal is used for output flow control.</p>
set	serial dcd	<i>mode</i>	ignore		<p>DCD management. <i>mode</i> is one of ignore / modem</p> <p>ignore means that the signal is locally ignored.</p> <p>modem means the signal is used as if a modem was connected to the port (DTR → the port server is on line, RTS → the port server wants to send data).</p>
Command			Default value	Notes	Description
set	serial ring	<i>mode</i>	ignore		<p>RING management :</p> <p><i>mode</i> : always ignore</p>
set	serial baudrate	<i>speed</i>	9600		<p><i>speed</i> : any baud rate from 10 bauds to 230400 bauds (up to 1'000'000 on RS422/RS485 "WLg" products)</p>
set	serial format	<i>nbits parity nstops</i>	8 n 1		<p><i>nbits</i> is 7 or 8 bits, <i>parity</i> is one of e, o, n, m, s (meaning even, odd, none, mark or space), <i>nstops</i> is 1 or 2 stop bits. (<i>nbits</i>=6 bits is also supported on the "WLg" range)</p>
show	serial format				
set	serial xonxoff	<i>mode</i>	ignore		<p>software flow control :</p> <p><i>mode</i> is one of use or ignore. Mixed (i.e. software and hardware) flow control can be set.</p>
show	serial xonxoff				
set	serial mode	<i>role</i>	slave rtu		<p><i>role</i> is one of master/slave or one of ascii/rtu. Warning, set serial mode command must be called twice, one time to set the master/slave parameter, another time to set the ascii/rtu parameter.</p> <p>master indicates that a MODBUS master is on the serial link; thus the port server gateway will function in MASTER mode.</p> <p>slave indicates that no MODBUS master is on the serial link; thus the port server gateway will function in SLAVE mode.</p> <p>ascii indicates a modbus ascii frame format.</p> <p>rtu indicates a modbus rtu frame format.</p> <p>Changing the mode (MASTER to SLAVE or SLAVE to MASTER) clears all entries of <i>authip</i> and <i>slaveid</i> tables.</p>
show	serial mode				
set	serial rtsdelays	<i>before after</i>	0 0		<p>Added delay surrounding a frame sent on the serial link in ms (max 255 ms). Use this when RTS is in MODEM mode, to add a delay of <i>before</i> ms between the rise of RTS and the start of frame, and a delay of <i>after</i> ms between the end of frame and the fall of RTS.</p>
show	serial rtsdelays				
set	serial stout	<i>nnnn</i>	600		<p>max delay between the end of the MODBUS request and the end of the answer frame on serial link, in ms (max 65535 ms).</p>
show	serial stout				
set	serial tdsr	<i>delay</i>	5		<p>acceptable delay between DTR rise and corresponding DSR rise at the beginning of a data session, when DSR is in modem mode. DTR→DSR in tenth of second. 0 to 255.</p>
show	serial tdsr				
set	serial toff	<i>duration</i>	5		<p>when DTR is in modem mode, and the TCP connection is closed or lost, DTR will stay low for at least <i>duration</i>, expressed in tenths of second. 0 to 255</p>
show	serial toff				
Command			Default value	Notes	Description
set	serial silence	<i>duration</i>	0		<p>This command enables to change/display the end of message (EOM) algorithm used in RTU mode. Normally, EOM is detected by a silent interval of at least 4 characters.</p> <p>With the help of this command, the EOM minimum silent interval may be set to the value specified by parameter <i>duration</i>, given in ms (max 65535 ms).</p> <p>For example, with command "set serial silence 20", a Modbus serial frame will be considered terminated only after a silence equal to or greater than 20 ms. In other words, it also means that gaps up to 20 ms in length between two characters of the same frame are allowed.</p> <p>WARNING: Using this command may lengthen the global Modbus cycle (time between request and answer), and so requires a really good understanding of Modbus time out settings. If changed, the silence duration must be taken into account when calculating time out used either by the supervisor and the gateways.</p> <p>This command is available only with wired port server (and WL-COMETH I) firmware versions 2.10.0.0 and higher, and with wireless port server firmware version 3.6.0.0 and higher.</p>
show	serial silence		(the standard '4 chars' time is used)		
set	serial nocheck	<i>state</i>	off		<p>When serial nocheck is set to on, integrity control of serial frames (length, CRC, unit #) received from slave devices is disabled, data is forwarded directly to TCP. In this mode, the TCP client is NOT alerted of potential errors. Serial nocheck should only be set to on for debugging purposes.</p>
show	serial nocheck				

SETTING OR DISPLAYING PARAMETERS FOR THE “WLG” RANGE OF DEVICES

Command		Default value	Notes	Description
set	wlan			Run the wizard asking for the WiFi parameters
show	wlan			Display the WiFi parameters.
set	wlan {options....}			Change specific WiFi parameters (you can specify one or more of the following parameters) :
	<i>state</i>	on		<i>state</i> = on or off .Turns radio card on or off
	<i>topology</i>	adhoc		<i>topology</i> = one of infra or adhoc
	<i>ssid string</i>	acksys		change the ssid of the device. <i>string</i> is a case sensitive characters string.
	<i>band</i>	bg		change the radio protocol: <i>band</i> = one of only only bg ah (standard 802.11 protocols)
	<i>superag</i>	sagoff		<i>superag</i> = one of sagoff sagon sagdyn sagstatic Super AG mode is an atheros card feature.
	<i>region</i>	eu		<i>region</i> = one of il us hk ca au fr eu jp sg kr (standardized code of the world region).
	<i>chan channels</i>	auto		List of channels checked for access points. Available values depend on the region and the band. auto allows to scan all the channels allowed in the region.
	<i>antennas</i>	diversity		<i>antennas</i> = one of diversity main aux If your product has only one antenna, choose diversity or main. If your product has 2 antennas you can choose diversity to use both antennas or specify which antenna you want to use (main or aux).
	<i>tx rate</i>	best		you can enforce a specific standard bit rate. “ best ” selects the best rate available for the given band and reception quality.
	<i>tx power</i>	high		you can change the radio output power <i>tx power</i> = one of high medium low
	<i>roaming</i>	0 (off)		set the reception level under the bridge will search another access point. The reception level can be specified in units of dBm with negative values, or in percentage with positive values.
				example: set wlan infra ssid myssid ah low
				this command will be change to infrastructure mode with ssid “myssid” and radio protocol 802.11a/h and a low transmit power.
Command		Default value	Notes	Description
set	wkey			Run the wizard asking for the WiFi security parameters
show	wkey			Display the WiFi security parameters.
set	wkey {option}			Change specific WiFi security parameters (you can specify one or more of the following parameters) :
	<i>method</i>	off		<i>method</i> = off (no security or WEP key), personal (uses WPA protocol with a pre-shared key) or enterprise (not implemented)
	<i>protocol</i>	wpa		<i>protocol</i> = wpa or wpa2
	<i>cipher</i>	tkip		<i>cipher</i> = tkip or aes . Usually TKIP is used together with WPA and AES is used together with WPA2.
	<i>password str</i>	unspecified		change the pre-shared key to <i>str</i> .
ping	<i>ip-adress</i>			Sends ICMP ECHO-REQUEST four times to the specified destination. The answer (or timeout indication) will be displayed a few seconds after the prompt.
stat				Displays various indications for technical support purpose.
rxfifo	<i>state</i>	on		reserved for factory tests. DO NOT CHANGE.

NOTES

1. This group of commands allows to retrieve or set globally the ACKSYS device server configuration.
2. Security note: sensitive data, like login and password information, are conveyed in clear text by the following commands. You must take any step to protect these data from disclosure. As a basic protective step, the commands themselves can only be used by a logged-in operator.
3. Usage note: Some data conveyed by these commands should be kept unique to a device. This applies especially to the IP and MAC addresses in the ‘common’ parameters. You should either avoid to change this unique data or to restore them after using the ‘set’ commands.
4. Usage note: Some parameters take effect immediately, as specified elsewhere. Beware that the parameters you change do not affect the device at the moment you set them. For example, if you change the DHCP Client Id, this will take effect at the next lease expiration, which could happen soon.
5. Use this group of commands to improve buffering of outgoing network data.
6. Usage note: When in RFC2217 mode, and for the purpose of these commands, any change in the control signals and the line state trigger the same actions as an arrival of 7 or 8 characters. This behavior of control signals and line state could change in the future.
7. Usage note: For the purpose of these commands, “send to the client application” means that the data is queued for transmission as soon as possible. The reception at the client side may be delayed by network contention,

client not acknowledging data fast enough, packet lost, etc.

8. Usage note: When a delay is specified as a number of characters duration, it is converted at run-time into a count of milliseconds (based on the character size and baud rate), and rounded up to the next millisecond.
9. Character strings can be naked or quoted. If naked, they start at the first non-space character, they finish at end of line, and can include any "authorized character". If quoted, they start at the first character after the opening double quote, they finish either at end of line or at the first encountered double quote, and can include any "authorized character" except the double quote itself. The authorized characters are: A to Z, a to z, 0 to 9, *, ?, ", -, underscore, ., :, space.

FAQs

What is MODBUS TCP used for?

MODBUS TCP is used as a gateway between MODBUS TCP and MODBUS serial networks, allowing communication between different types of equipment.

How many slave devices can be connected in a MODBUS network?

A MODBUS network supports up to 247 slave devices along with one master device.

Can MODBUS frames be transmitted through Ethernet?

Yes, MODBUS frames can be transmitted through Ethernet by encapsulating them in TCP/IP frames for addressing devices on this medium.

ZA Val Joyeux

10, rue des Entrepreneurs 78450 VILLEPREUX FRANCE

Telephone: +33 (0)1 30 56 46 46


Fax: +33 (0)1 30 56 12 95

Web: www.acksys.fr

Hotline: support@acksys.fr

Sales: sales@acksys.fr

Documents / Resources

 MODBUS FIRMWARE USER'S GUIDE TABLE OF CONTENTS 1. INTRODUCTION 2. MODBUS FIRMWARE 3. MODBUS FIRMWARE 4. MODBUS FIRMWARE 5. MODBUS FIRMWARE	ACKSYS DTUS0414 Modbus Firmware Ethernet And Wi-Fi Port Servers [pdf] User Guide DTUS0414 Modbus Firmware Ethernet And Wi-Fi Port Servers, DTUS0414, Modbus Firmware Ethernet And Wi-Fi Port Servers, Firmware Ethernet And Wi-Fi Port Servers, Wi-Fi Port Servers
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [A Solutions de communication WiFi et cellulaires ACKSYS](#)
- [A Solutions de communication WiFi et cellulaires ACKSYS](#)
- [User Manual](#)