

Actel SmartDesign MSS Cortex M3 Configuration User Guide

Home » Actel » Actel SmartDesign MSS Cortex M3 Configuration User Guide



SmartDesign MSS
Cortex[™] -M3 Configuration
User Guide

Contents

- 1 Introduction
- **2 Configuration Options**
- **3 Port Description**
- 4 Documents /

Resources

- 4.1 References
- **5 Related Posts**

Introduction

The SmartFusion Microcontroller Subsystem (MSS) contains an ARM Cortex-M3 microcontroller, a lowpower processor that features low gate count, low and predictable interrupt latency, and low-cost debug. It is intended for deeply embedded applications that require fast interrupt response features.

This document describes the ports that are available on the Cortex-M3 core in the SmartDesign MSS Configurator.

For more information about the specific implementation of the Cortex-M3 in the Actel SmartFusion device, please refer to the **Actel SmartFusion Microcontroller Subsystem User's Guide**.

Configuration Options

There are no configuration options for the Cortex-M3 core in the SmartDesign MSS Configurator.




Figure 1: Cortex-M3 in SmartFusion

Port Description

Port Name	Direction	PAD?	Description
RXEV	In	No	Causes the Cortex-M3 to wake up from a WFE (wait for event) instruction. The event input, RXEV, is registered even when not waiting for an event, and so affects the next WFE.
TXEV	Out	No	Event transmitted as a result of a Cortex-M3 SEV (send event) instruction. This is a single-cycle pulse equal to 1 FCLK period.
SLEEP	Out	No	This signal is asserted when the Cortex-M3 is in sleep now or sleep-on-exit mode, and indicates that the clock to the processor can be stopped.
DEEPSLEEP	Out	No	This signal is asserted when the Cortex-M3 is in sleep now or sleep-on-exit mode when the SLEEPDEEP bit of the System Control Register is set.

Note:

Non-PAD ports must be promoted manually to the top level from the MSS configurator canvas to be available as the next level of hierarchy.

Actel is the leader in low-power and mixed-signal FPGAs and offers the most comprehensive portfolio of system and power management solutions. Power Matters. Learn more at http://www.actel.com.

Actel Corporation 2061 Stierlin Court Mountain View, CA

94043-4655 USA Phone 650.318.4200

Fax 650.318.4600

Actel Hong Kong

United Kingdom

Actel Europe Ltd.

Room 2107, China Resources Building

River Court, Meadows Business Park

Station Approach, Blackwater

Camberley Surrey GU17 9AB

Phone +44 (0) 1276 609 300

Fax +44 (0) 1276 607 540

26 Harbour Road

Wanchai, Hong Kong

Phone +852 2185 6460

Fax +852 2185 6488

www.actel.com.cn

Actel Japan

EXOS Ebisu Building 4F 1-24-14 Ebisu Shibuya-ku Tokyo 150, Japan Phone +81.03.3445.7671

Fax +81.03.3445.7668

http://jp.actel.com

© 2009 Actel Corporation. All rights reserved. Actel and the Actel logo are trademarks of Actel Corporation. All other brand or product names are the property of their respective owners.



Documents / Resources



Actel SmartDesign MSS Cortex M3 Configuration [pdf] User Guide

SmartDesign MSS Cortex M3 Configuration, SmartDesign MSS, Cortex M3 Configuration, M3 Configuration

References

- FPGAs and PLDs | Microchip Technology
- © actel.com.cn

Manuals+,