Home » Acurite » ACURITE 06022 Display 5-in-1 Weather Sensor Instruction Manual

ACURITE 06022 Display 5-in-1 Weather Sensor Instruction Manual



Contents

- 1 Instruction Manual
- 2 Display for 5-in-1 Weather Sensor
 - 2.1 model 06022
 - 2.2 Package Contents
 - 2.3 Features & Benefits
 - 2.3.1 Display
 - 2.4 BACK OF DISPLAY
 - **2.5 SETUP**
 - 2.5.1 Display Setup
 - 2.5.2 Set the Time, Date & Units
 - 2.5.3 Display Backlight Settings
 - 2.5.4 Placement for Maximum Accuracy
 - 2.5.5 Important Placement Guidelines
 - 2.6 OPERATION
 - 2.6.1 Using the Professional Weather Center
 - 2.6.2 Weather Select
 - 2.6.3 Barometric Pressure
 - 2.6.4 Rainfall Tracking
 - 2.6.5 Weather Ticker™
 - 2.6.6 Troubleshooting
 - 2.6.7 Care & Maintenance
 - 2.6.8 Calibration
 - 2.6.9 Specifications
 - 2.6.10 FCC Information
 - 2.6.11 Customer Support
 - 2.6.12 Limited 1-Year Warranty
- 3 Documents / Resources
 - 3.1 References
- **4 Related Posts**

Instruction Manual

Display for 5-in-1 Weather Sensor

model 06022



Package Contents

- 1. Display with Tabletop Stand
- 2. Power Adapter
- 3. Instruction Manual

This product requires an AcuRite 5-in-1 Weather Sensor (sold separately) to be operational.

IMPORTANT

PRODUCT MUST BE REGISTERED TO RECEIVE WARRANTY SERVICE

PRODUCT REGISTRATION

Register online to receive 1 year warranty protection www.AcuRite.com

Questions? Contact Customer Support at (877) 221-1252 or visit www.AcuRite.com.

SAVE THIS MANUAL FOR FUTURE REFERENCE.

Features & Benefits

Display



- 1. Previous 2 Wind Directions
- 2. Current Wind Speed
- 3. Current Wind Direction
- 4. Current Indoor Temperature

Arrow icon indicates direction temperature is trending.

- 5. Display Low Battery Indicator
- 6. Peak Wind Speed

Highest speed from the last 60 minutes.

7. Current Indoor Humidity

Arrow icon indicates direction humidity is trending.

8. Wind Speed Alert Indicator

Activates when wind speed is over 50 mph.

9. Clock

10. Rainfall Alert Indicator

Indicates rainfall of more than 1" (25 mm) of rain in 2 hours or less.

11. AUTO DIM Indicator

Indicates display is in auto-dimming brightness mode (see page 6).

12. Current Rainfall Total

Accumulates data during rainfall.

13. 12 to 24 Hour Weather Forecast

Self-Calibrating Forecasting pulls data from your 5-in-1 sensor to generate your personal forecast.

14. Storm Alert Indicator

Activates when barometric pressure drops.

15. Month/Year/All-Time Rainfall

16. Current Barometric Pressure

Arrow icon indicates direction pressure is trending.

17. RAINFALL Button

Press to change the RAINFALL data being displayed (Month, Year, All-Time).

For setup preferences.

19. SET Button

For setup preferences.

20. SELECT Button

Press to change the WEATHER SELECT category data being displayed.

21. Weather Ticker™

22. Heat Index/ Wind Chill Alert Indicator

Activates when heat index rises over 90°F (32°C) or when wind chill drops below -17°F (-27°C).

23. Learning Mode Icon

Disappears after weather forecast self-calibration is complete.

24. WEATHER SELECT

Displays heat index, dew point, wind chill, feels like, days with rain this month, and days since last recorded rainfall.

25. Date

26. Current Outdoor Humidity

Arrow icon indicates direction humidity is trending.

27. Average Wind Speed

Average wind speed over the past 2 minutes.

28. 5-in-1 Sensor Signal Strength

29. Sensor Low Battery Indicator

30. Current Outdoor Temperature

Arrow icon indicates direction temperature is trending.



BACK OF DISPLAY

1. Integrated Hang Hole

For easy wall mounting.



For dimmer control while using power adapter. Activates momentary backlight while on battery power.

3. Plug-in for Power Adapter

4. Removable Tabletop Stand

5. CLEAR ALL/RESET Button

Press and HOLD for 10 seconds for full reset to factory defaults.

6. A-B-C Switch

ID code that must match 5-in-1 sensor's A-B-C switch to ensure units synchronize.

7. Power Adapter

8. Battery Compartment Cover

(not shown)

SETUP

Display Setup

AcuRite recommends high quality alkaline batteries for the best product performance. Heavy duty or rechargeable batteries are not recommended.

(1) Set the A-B-C Switch


The A-B-C switch is located inside the battery compartment. It can be set to A, B or C. However, you must select the same letter choices for both the sensor and the display in order for the units to synchronize.

(2) Plug Power Adapter into Electrical Outlet

(3) Install or Replace Batteries

(optional)

Insert 6 x AA alkaline batteries into the battery compartment, as shown. Follow the polarity (+/-) diagram in the battery compartment.



a) Install Backup Batteries

(optional)

6 AA Batteries

b) Plug in Power Adapter

IMPORTANT: Batteries are a backup power source to preserve records in the event of a power outage. Power adapter is the recommended primary power source to enjoy the full functionality of this product.



PLEASE DISPOSE OF OLD OR DEFECTIVE BATTERIES IN AN ENVIRONMENTALLY SAFE WAY AND IN ACCORDANCE WITH YOUR LOCAL LAWS AND REGULATIONS.

BATTERY SAFETY: Clean the battery contacts and also those of the device prior to battery installation. Remove batteries from equipment which is not to be used for an extended period of time. Follow the polarity (+/-) diagram in the battery compartment. Promptly remove dead batteries

from the device. Dispose of used batteries properly. Only batteries of the same or equivalent type as recommended are to be used. DO NOT incinerate used batteries. DO NOT dispose of batteries in fire, as batteries may explode or leak. DO NOT mix old and new batteries or types of batteries (alkaline/standard). DO NOT use rechargeable batteries. DO NOT recharge non-rechargeable batteries. DO NOT short-circuit the supply terminals.

Set the Time, Date & Units

Press the "SET" button, located on the front of the display, to enter SET MODE. Once in set mode, the preference you are currently setting will blink on the display.

To adjust the currently selected (flashing) item, press and release the "\(\infty\)" or "\(\neg \)" buttons (press and HOLD to fast adjust).

To save your adjustments, press and release the "SET" button again to adjust the next preference. The preference set order is as follows:

TOP DISPLAY:

CLOCK HOUR
CLOCK MINUTE
CALENDAR MONTH
CALENDAR DATE
CALENDAR YEAR
TEMPERATURE UNITS (°F or °C)
WIND SPEED UNITS (MPH, km/h, Knots)
RAINFALL UNITS (in or mm)
PRESSURE UNITS (inHg or hPa)

TICKER DISPLAY:

LANGUAGE (English, French, Spanish)
WEATHER TICKER SPEED (SLOW, MEDIUM, FAST)

You will automatically exit SET MODE if no buttons are pressed for 20 seconds. Enter SET MODE at any time by pressing the "SET" button.

Display Backlight Settings

This weather station's color display features three different lighting settings: High (100%) brightness, Medium (60%) brightness and Low (30%) brightness.

Using battery power alone, the backlight is available momentarily for 10 seconds by pressing the " button."

When display is powered with the power adapter, backlight remains on at 100% brightness. Press "button once to dim to 60% brightness; press again to dim to 30%, press a 3rd time to enter "AUTO DIM" mode. "AUTO DIM" will appear below the clock.

AUTO DIM MODE: Automatically adjusts display brightness based on time of day & year.		
MARCH 11- NOVEMBER 4	6:00 a.m. – 9:00 p.m. = 100% brightness	
	9:01 p.m. – 5:59 a.m.= 30% brightness	
NOVEMBER 5 – MARCH 10	7:30 a.m. – 7:00 p.m.= 100% brightness	
	7:01 p.m. – 7:29 a.m. = 30% brightness	

Placement for Maximum Accuracy

AcuRite sensors are sensitive to surrounding environmental conditions. Proper placement of both the display and the sensor are critical to the accuracy and performance of this product.



Display Placement

Place the display in a dry area free of dirt and dust. To ensure accurate temperature measurement, place out of direct sunlight and away from heat sources or vents. Display stands upright for tabletop use or is wall-mountable.

Important Placement Guidelines

Display and sensor must be within 330 feet (100 m) of each other.

Maximize Wireless Range

Place units away from large metallic items, thick walls, metal surfaces, or other objects that may limit wireless communication.

Prevent Wireless Interference

Place both units at least 3 (.9 m) away from electronic devices (TV, computer, microwave, radio, etc.).

OPERATION


Using the Professional Weather Center

Learning Mode

Self-Calibrating Forecasting use a unique algorithm to analyze changes in pressure over a time period (called Learning Mode) to determine your altitude. After 14 days, the Learning Mode icon disappears from the display screen. At this point, the self-calibrated pressure is tuned in to your location and the unit is ready for superior weather prediction.

Weather Forecast

AcuRite's patented Self-Calibrating Forecasting provides your personal forecast of weather conditions for the next 12 to 24 hours by collecting data from the sensor in your backyard. It generates a forecast with pinpoint accuracy – personalized for your exact location.



View the complete list of icons at www.AcuRite.com/acurite-icons

Weather Select

Weather Select displays data including wind chill, dew point, heat index, feels like, days with rain this month, and days since last recorded rainfall. To change the "Weather Select" category shown, press the "SELECT" button on the front of the display.

Barometric Pressure

Subtle variations in barometric pressure greatly affect the weather. This weather center displays the current pressure with an arrow icon to indicate the direction the pressure is trending (FALLING, STEADY, or RISING).

Rainfall Tracking

This weather station features enhanced tracking of historical rainfall data. Rain accumulation data is recorded for today, over all-time, by year, by month, and by rainfall event.

Press the "RAINFALL" button to review rainfall records. The icon is shown on the display while historical data is being viewed.

Records are shown in the following order:

PREVIOUS RAINFALL #1*
PREVIOUS RAINFALL #2*
PREVIOUS RAINFALL #3*
CURRENT MONTH TOTAL RAINFALL
PREVIOUS MONTH TOTAL RAINFALL
2 MONTHS AGO TOTAL RAINFALL
CURRENT YEAR TOTAL RAINFALL
PREVIOUS YEAR TOTAL RAINFALL

ALL-TIME TOTAL RAINFALL (date shown is start date of the all-time total; the date the display was powered on)

^{*}Previous rainfall is the amount of rain recorded from 12:00am to 11:59pm on the date shown.





TOTAL RAINFALL FOR DATE SHOWN

TOTAL RAINFALL FOR MONTH SHOWN







CURRENT YEAR TOTAL RAINFALL

PREVIOUS YEAR TOTAL RAINFALL

ALL-TIME TOTAL RAINFALL

Weather Ticker™

The Weather Ticker automatically flashes your real-time weather information and alerts as text in the lower part of the display screen.

The possible WEATHER TICKER messages are as follows:

HEAT INDEX-XX WINDCHILL-XX DEW POINT-XX

IT FEELS LIKE XX OUTSIDE

7 DAY HIGH TEMP. XX- MM/DD

7 DAY LOW TEMP. XX- MM/DD

30 DAY HIGH TEMP. XX- MM/DD

30 DAY LOW TEMP. XX- MM/DD

ALL TIME HIGH TEMP. XXX...RECORDED MM/DD/YY

ALL TIME LOW TEMP. XXX...RECORDED MM/DD/YY

24 HOUR TEMP. CHANGE +XX

ALL TIME HIGH WIND XX MPH...RECORDED MM/DD/YY

7 DAY AVERAGE WIND XX MPH

TODAY'S AVERAGE WIND XX MPH

MOON- NEW

MOON- WAXING CRESCENT

MOON- FIRST QUARTER

MOON- WAXING GIBBOUS

MOON- FULL

MOON- WANING GIBBOUS

MOON- LAST QUARTER

MOON- WANING CRESCENT

INDOOR HUMIDITY OK

INDOOR HUMIDITY HIGH

INDOOR HUMIDITY LOW
NEW LOW TEMP. RECORD XX
NEW HIGH TEMP. RECORD XX
NEW WIND RECORD TODAY XX
CURRENT RAINFALL X.XX/HR.
RAIN EVENT STARTED XX HRS. AGO
SENSOR BATTERIES LOW
DISPLAY BATTERIES LOW
SENSOR SIGNAL LOST...CHECK BATTERIES AND PLACEMENT
CAUTION- HEAT INDEX IS XXX
CAUTION- WIND CHILL IS XXX

CALIBRATION

Troubleshooting

Problem	Possible Solution
Inaccurate tem perature or hu midity	 Make sure both the display and 5-in-1 sensor are placed away from any heat sources or v ents (see page 7). Make sure both units are positioned away from moisture sources (see page 7). Make sure 5-in-1 sensor is mounted at least 5 ft off of the ground. Calibrate indoor and outdoor temperature and humidity (see page 11).
No rainfall	 Check to ensure the rain gauge stabilizer (plastic tab) has been removed from the bottom of the sensor. Clear debris, such as leaves, out of the rain collector funnel and debris screen. Calibrate the rain gauge (see sensor manual).
Inaccurate win d readings	 What is wind reading being compared to? Pro weather stations are typically mounted at 3 0 ft high or more. Make sure to compare data using a sensor positioned at the same mounting height. Check location of the sensor. Ensure it's mounted a minimum of 5 ft in the air with no obst ructions around it (within several feet). Ensure wind cups are spinning freely. If they hesitate or stop try lubricating with graphite powder or spray lubricant.
Display screen not working	 Check that the power adapter is plugged into the display and an electrical outlet. Reset the display by pressing and holding the CLEAR ALL/RESET button for 10 seconds, located in the battery compartment of the display. Date and time will need to be entered af ter a reset.

If your AcuRite product does not operate properly after trying the troubleshooting steps, visit www.AcuRite.com or call (877) 221-1252 for assistance.

Display Care

Clean with a soft, damp cloth. Do not use caustic cleaners or abrasives. Keep away from dust, dirt and moisture. Clean ventilation ports regularly with a gentle puff of air.

Calibration

The indoor / outdoor temperature and humidity readings, and barometric pressure can be calibrated on the display to improve accuracy. Calibration can improve accuracy when sensor placement or environmental factors impact the data accuracy.

- 1. To access calibration mode, press AND HOLD the "♠", "SET", and "♥" buttons simultaneously for at least 5 seconds.
- 2. To adjust the currently selected (flashing) item, press and release the "\" or "\" buttons to calibrate the data value higher or lower from the actual reading.
- 3. To save your adjustments, press and release the "SET" button to adjust the next preference. The " C" icon will remain illuminated next to calibrated values.

The preference set order is as follows:
OUTDOOR TEMPERATURE
OUTDOOR HUMIDITY
INDOOR TEMPERATURE
INDOOR HUMIDITY
BAROMETRIC PRESSURE (must be set to MANUAL mode to calibrate)*

*To change from AUTO to MANUAL pressure mode and vice versa, press AND HOLD the "SET" button for at least 10 seconds. The display indicates the current pressure mode selected, "AUTO" or "MANUAL".

After 10 seconds of inactivity, the display will save the adjustments and exit calibration mode. Note: Calibrations will be erased if the display is reset or if batteries are removed and the power adapter is unplugged.

Specifications

DISPLAY'S BUILT-IN TEMPERATURE SENSOR RAN GE	32ºF to 122ºF; 0ºC to 50ºC
DISPLAY'S BUILT-IN HUMIDITY SENSOR RANGE	1% to 99% RH
WIND SPEED	0 to 99 mph; 0 to 159 km/h
WIND DIRECTION INDICATORS	16 points
RAINFALL	0.01 inches (0.25 mm) and up
WIRELESS RANGE	330ft / 100m depending on home construction materials
OPERATING FREQUENCY	433 MHz
POWER	5V, 250mA adapter 6 x AA alkaline batteries (optional)
DATA REPORTING	Wind Speed: 18 second updates; Direction: 36 seconds Outdoor temperature & humidity: 36 second updates Indoor temperature & humidity: 60 second updates PC Connect CSV Data Logging: 12 minute intervals PC Connect to Online Portal/App: 18 seconds

FCC Information

This device complies with part 15 of FCC rules. Operation is subject to the following two conditions:

- 1- This device may NOT cause harmful interference, and
- 2- This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

Customer Support

AcuRite customer support is committed to providing you with best-in-class service. **For assistance**, please have the model number of this product available and contact us in any of the following ways:



Visit us at www.AcuRite.com

- ► Installation Videos
- ► Register your Product
- ► Instruction Manuals
- ► Support User Forum
- ► Replacement Parts
- ► Submit Feedback & Ideas

IMPORTANT

PRODUCT MUST BE REGISTERED TO RECEIVE WARRANTY SERVICE

PRODUCT REGISTRATION

Register online to receive 1 year warranty protection www.AcuRite.com

Limited 1-Year Warranty

AcuRite is a wholly owned subsidiary of Chaney Instrument Company. For purchases of AcuRite products, AcuRite provides the benefits and services set forth herein. For purchases of Chaney products, Chaney provides the benefits and services set forth herein.

We warrant that all products we manufacture under this warranty are of good material and workmanship and, when properly installed and operated, will be free of defects for a period of one year from the date of purchase.

Any product which, under normal use and service, is proven to breach the warranty contained herein within ONE YEAR from date of sale will, upon examination by us, and at our sole option, be repaired or replaced by us. Transportation costs and charges for returned goods shall be paid for by the purchaser. We hereby disclaim all responsibility for such transportation costs and charges. This warranty will not be breached, and we will give no credit for products which have received normal wear and tear not affecting the functionality of the product, been damaged (including by acts of nature), tampered, abused, improperly installed, or repaired or altered by others than our authorized representatives.

Remedy for breach of this warranty is limited to repair or replacement of the defective item(s). If we determine that repair or replacement is not feasible, we may, at our option, refund the amount of the original purchase price.

THE ABOVE-DESCRIBED WARRANTY IS THE SOLE WARRANTY FOR THE PRODUCTS AND IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. ALL OTHER WARRANTIES OTHER THAN THE EXPRESS WARRANTY SET FORTH HEREIN ARE HEREBY EXPRESSLY DISCLAIMED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTY OF MERCHANTABILITY AND THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

We expressly disclaim all liability for special, consequential, or incidental damages, whether arising in tort or by contract from any breach of this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

We further disclaim liability from personal injury relating to our products to the extent permitted by law. By acceptance of any of our products, the purchaser assumes all liability for the consequences arising from their use

or misuse. No person, firm or corporation is authorized to bind us to any other obligation or liability in connection with the sale of our products. Furthermore, no person, firm or corporation is authorized to modify or waive the terms of this warranty unless done in writing and signed by a duly authorized agent of ours.

In no case shall our liability for any claim relating to our products, your purchase or your use thereof, exceed the original purchase price paid for the product.

Applicability of Policy

This Return, Refund, and Warranty Policy applies only to purchases made in the United States and Canada. For purchases made in a country other than the United States or Canada, please consult the policies applicable to the country in which you made your purchase.

Additionally, this Policy applies only to the original purchaser of our products. We cannot and do not offer any return, refund, or warranty services if you buy products used or from resale sites such as eBay or Craigslist.

Governing Law

This Return, Refund, and Warranty Policy is governed by the laws of the United States and the State of Wisconsin. Any dispute relating to this Policy shall be brought exclusively in the federal or State courts having jurisdiction in Walworth County, Wisconsin; and purchaser consents to jurisdiction within the State of Wisconsin.







Kitchen Thermometers & Timers

Clocks

It's More than Accurate, it's ACU RITE.

AcuRite offers an extensive assortment of precision instruments, designed to provide you with information you can depend on to Plan your day with confidence™.

www.AcuRite.com

©Chaney Instrument Co. All rights reserved. AcuRite is a registered trademark of the Chaney Instrument Co., Lake Geneva, WI 53147. All other trademarks and copyrights are the property of their respective owners. AcuRite

uses patented technology.

Visit www.AcuRite.com/patents for details.

Printed in China
06022M INST 061716

Documents / Resources



ACURITE 06022 Display 5-in-1 Weather Sensor [pdf] Instruction Manual 06022 Display 5-in-1 Weather Sensor, 06022, Display 5-in-1 Weather Sensor, Weather Sensor, Sensor

References

- AcuRite Weather Monitoring | #1 Weather Station Brand in North America
- Lon Definitions and Terminology | AcuRite
- Patented Technology | AcuRite
- **Manual-Hub.com Free PDF manuals!**
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.