



# AEi COMMUNICATIONS VX-3X08-BU Series Single or Dual-Line SIP Base and WiFi Cordless Extension Phones User Guide

[Home](#) » [AEi COMMUNICATIONS](#) » [AEi COMMUNICATIONS VX-3X08-BU Series Single or Dual-Line SIP Base and WiFi Cordless Extension Phones User Guide](#) 

## Contents

- [1 AEi COMMUNICATIONS VX-3X08-BU Series Single or Dual-Line SIP Base and WiFi Cordless Extension Phones](#)
- [2 Product Description](#)
- [3 Web Configuration](#)
- [4 Speed Dial](#)
- [5 Quick commands](#)
- [6 Operations](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)



**AEi COMMUNICATIONS VX-3X08-BU Series Single or Dual-Line SIP Base and WiFi Cordless Extension Phones**



### Product Information

The VX-3X08-BU(S), VX-3108-BU(S), and VX-3208-BU(S) are full-feature telephones that provide voice communication. These phones come with various features and accessories to enhance the user experience.

### Package Contents

- VX-3108-BU(S) or VX-3208-BU(S) Wi-Fi Handset phone
- Charging Stand
- Battery
- AC/DC Adaptor
- User Guide (This document)

### Product Description

The phone has a front view with the following components:

- Name Display screen
- SELECT SERVICES key
- Right / Left key
- LINE 1 / LINE 2 / LINE END key
- Alphanumerical keys
- Function keys

The phone also includes additional features such as HOLD, MUTE, VOLUME control, MESSAGE, GUEST SERVICES, and EMERGENCY keys. These keys provide various functionalities like call management, volume adjustment, accessing voice messages, contacting guest services, and making emergency calls. The phone comes with a charging stand that has a USB Charger port for connecting to mobile equipment charging cable.

## Battery Installation

To install the battery, follow the steps below:

1. Refer to the illustration provided in the user manual.
2. Insert the handset and battery as shown in the illustration.

## Web Configuration

To set up the VX-3×08 handset from web configuration manually, follow the steps below:

1. Boot the handset to the AP mode by removing the phone battery, pressing and holding the red button, and then reinstalling the battery.
2. The VX-3208 handset will start up and display its AP mode SSID, Password, and AP IP address.
3. Use your laptop to connect to the VX-3208 AP.
4. Open a web browser and go to <http://192.168.4.1:8000>.
5. Enter the username/password as admin/1234 to log in.

## System Information

After logging in, the system information will be displayed as follows:

### WIFI

Setup the Wi-Fi SSID, Password, and IP type.

- WIFI SSID: The WIFI SSID
- WIFI PASSWORD: The WIFI Password
- WIFI IP Type: The default is DHCP.

### VoIP

Setup the SIP account for VoIP communication.

- Switch: Check Enable to enable SIP registration or Disable to disable the SIP account temporarily.
- Display Name: The name of the phone or the location of the phone on the remote party.
- User Name: User name of the SIP account, also known as user ID or extension number.
- Authentication Name: SIP authentication name.
- Password: Password of the SIP account.
- Register Domain: FQDN, SIP domain name, or IP address of the SIP server.
- Register IP: IP address of the SIP Server. If the listening port is different from 5060, add the port at the end of the address.
- Register Backup Domain: IP address of the secondary SIP server.

## Overview

This phone is a full-feature telephone that provides voice communication. Read this user guide carefully to learn how to operate this product and take advantage of its features.

## Package Contents

When unpacking the device, ensure all the following items are present and undamaged. If anything appears to be missing or broken, contact your dealer for a replacement.

- 1. VX-3108-BU(S) or VX-3208-BU(S) Wi-Fi Handset phone
- 2. Charging Stand
- 3. Battery
- 4. AC/DC Adaptor
- 5. User Guide (This document)

Product Description

The following contains important information to help you familiarize with the functions of the phone.


Front View




Name	Description
Display screen	Display calls and status information.
SELECT SERVICES key	Press to enter scrollable guest services
Right / Left key	Press to select guest service.
LINE 1 / LINE 2 / LINE	Line key(S) to make a call or answer a call.
END key	Press to end the phone call.
Alphanumerical keys	Press these keys to enter phone numbers.
Function keys	

Name	Description
HOLD (2 line only)	Press to put an active call on hold.
MUTE (single line only)	Press to mute MIC.
<i>i</i>	Press to access dialing instructions.
VOLUME	Press to increase or decrease the volume of the ringer tone, handset, or the volume of the current call.
MESSAGE	Press to listen to voice messages.
GUEST SERVICES	Press to contact guest services.
EMERGENCY	Press to make an emergency call.

### Charging stand rear view




### Charging stand-side view



Name	Description
USB Charger port	Connects to mobile equipment charging cable.


### Battery Installation



The following illustration shows how to install the handset and battery.



## Web Configuration

### Web Login

To set up the VX-3208 handset from web configuration manually, boot the handset to the AP mode. Please remove the phone battery, press and hold the red  button, and then reinstall the battery. The VX-3208 handset will start up and display its AP mode SSID, Password, and AP IP address. Please use your laptop to connect the VX-3208 AP and then connect the phone at <http://192.168.4.1:8000> via a web browser by using username/password as admin/1234.



After logging in, the system information shows as below.

System Status	
<a href="#">Status</a>	FW Version : FW:v0.0.2 FS:00.0.03
<a href="#">WIFI</a>	WIFI SSID : FAE-rk
<a href="#">VoIP</a>	Provision IP: 192.168.1.100
<a href="#">Speed Dial</a>	Provision File: .cfg
<a href="#">System</a>	Upgrade IP: tftp://192.168.168.128:69
	Upgrade FILE: vx300.vb asui.vi

### WIFI

Set up the Wi-Fi SSID, Password and IP type.

WIFI Setup	
WIFI SSID :	<input type="text" value="FAE"/>
WIFI PASSWORD :	<input type="text" value="1234567890"/>
WIFI IP Type:	<input type="text" value="DHCP"/>
<input type="button" value="Submit"/>	

### WIFI SSID

The WIFI SSID

### WIFI PASSWORD

The WIFI Password

### WIFI IP Type

The default is DHCP.

### VoIP

Setup the SIP account

VoIP Setup		
<a href="#">Status</a> <a href="#">WIFI</a> <a href="#">VoIP</a> <a href="#">Speed Dial</a> <a href="#">System</a>	Switch :	<input type="text" value="Enable"/>
	Display name :	<input type="text" value="1361"/>
	User name :	<input type="text" value="1361"/>
	Authentication Name :	<input type="text" value="1361"/>
	Password :	<input type="text" value="1361"/>
	Register Domain :	<input type="text" value="192.168.168.249"/>
	Register IP :	<input type="text" value="192.168.168.249:5060"/>
	Register Backup Domain :	<input type="text"/>
	Register Backup IP :	<input type="text"/>
	First Codec :	<input type="text" value="G.711 U"/>
	Second Codec :	<input type="text" value="G.711 A"/>
	Frame Size :	<input type="text" value="20 ms"/>
	2833 Payload :	<input type="text" value="101"/>
	SIP Local Port :	<input type="text" value="5060"/>
	RTP Port :	<input type="text" value="42000"/>
	Expires :	<input type="text" value="300"/>
	MWI :	<input type="text" value="Disable"/>
	DNS SRV :	<input type="text" value="Disable"/>
	Keep Alive :	<input type="text" value="Disable"/>
	DTMF Type :	<input type="text" value="RFC 2833"/>
Caller ID :	<input type="text" value="Disable"/>	
<input type="button" value="Submit"/>		

### Switch

Check “Enable” to enable SIP registration or “Disable” to disable the SIP account temporarily.

### Display Name

Display Name is the name of the phone or the location of the phone on the remote party.

### User name

User name of the SIP account, also known as user ID or extension number.

**Authentication Name**

Authentication Name is for SIP authentication.

**Password**

The password of the SIP account

**Register Domain**

FQDN, SIP domain name or IP address of the SIP server

For example, voip.aeicomunications.com or 172.8.12.11

**Register IP**

IP address of the SIP Server

If the listening port of the SIP Server is different from 5060, please add the port to at end of the address. Ex  
172.8.12.11:5061

**Register Backup Domain**

IP address of the secondary SIP server

For example, 172.8.12.12

**Register Backup IP**

IP address of the secondary SIP Server

For example, 172.8.12.12

**Codec Priority**

Select the 2 codec priority.

**Frame Size**

- Frame size for G711u and G711a.
- G711 ranges from 20ms and 40ms.
- 2833 Payload: (Default, 101)
- DTMF RFC2833 Payload Type, ranging from 96 ~ 127

**SIP Local Port: (Default, 5060)**

SIP Local port

**RTP Port Base: (Default, 42000)**

The port of RTP starts

**Expire: (Default, 600)**

SIP registration expiration time (seconds); select from 60, 120, 300 and 600

**MWI: (Default, Disable)**

Enable to subscribe message waiting for information.

**DNSSRV: (Default, Disable)**

Enable DNSSRV query

**Keep Alive: (Default, Disable)**

Send keep alive package to keep the SIP registration from being blocked




### DTMF Type: (Default, RFC 2833)

DTMF for transmitting digits, \* and #; select from RFC2833, SIP Info and In Band

### Caller ID: (Default, Disable)

Display the caller id of an incoming call

### Speed Dial



- SPEED DIAL 1 ~ 7: 7 scrollable service keys.
- SPEED DIAL 8 ~ 10: the physical hard service keys from left to right respectively.

### System

Provision Server:	192.168.1.100
Provision File:	1234
Upgrade Protocol:	TFTP ▼
Upgrade Server:	192.168.1.100
Firmware:	vx300.vb
Partition:	vx300.vi
<input type="button" value="Submit"/>	
Reboot :	<input type="button" value="Reboot"/>
Default :	<input type="button" value="Default"/>

### Server

The IP address information of the server, for example, 192.168.1.54. The phone will retrieve the .cfg file.

### Provision File

The name (room number) of the provision file in the root folder of the server.

- Ex.1234: 1234.cfg

- Empty MAC.cfg
- Upgrade Protocol: (Default, TFTP)  
Select the firmware upgrade protocol, TFTP or HTTP.
- Firmware  
The file name of the firmware in the root folder of the server
- Partition  
The file name of the UI package in the root folder of the server
- Reboot  
Click “Reboot” to restart the phone.
- Default  
Click “Default” to reset the phone to factory default

## Quick commands

### Enable AP mode

Remove the battery. Press and hold the red  button, and then reinstall the battery

### Set the TFTP Provision Server IP

Ex. 192.168.5.2 6861\*192\*168\*5\*2# Green-key (Line 1)

Update phone setting (provisioning) via room number: Ex. Room number 888 6862\*888# Green-key (Line 1)

### Update phone setting (provisioning) via MAC

6862\*# Green-key (Line 1)


### Engineering setup menu

6863\*

### Reboot Init Sync

To sync the phone settings (WIFI SSID, WIFI password, provision server) from other configured phones

**Step 1:** Configure the 1st phone from the web interface: WIFI setting, provision server, and make sure the 1st phone is able to connect to the WIFI AP and download a configuration file.

**Step 2:** Remove the battery of 1st phone, press and hold the red  button, and then reinstall the battery. The 1st phone will boot to AP mode and display the AP mode SSID, Password, and IP address.

**Step3:** Press \*\*6863\*# and select Init Sync on the 2nd phone. The 2nd phone will auto-connect to the 1st phone and sync the WIFI SSID, WIFI password, and provision server from the 1st phone.

**Step4:** Reboot the 2nd phone. The 2nd phone will connect to the WIFI AP and download the provision file.

- SystemInfo  
To display the MAC information and WIFI status.
- ProvisionInfo  
To display the provision information.
- SIPInfo  
To display the SIP account information.
- Factory Rest  
To reset the phone to factory default.
- Firmware Upgrade  
To upgrade the phone firmware.

- Parturition Upgrade  
To upgrade the phone User Interface.
- Pair Mode  
To connect the VX handset to other AEI Wi-Fi master phones.
- Debug Mode  
To enable debug mode when the phone cannot register to PABX

## Operations

### Answering a Call

An incoming call is indicated by a ringing tone and a flashing indicator at the top of the handset. You can answer the call by doing the followings: Press the LINE (LINE1/LINE2) key on the handset to answer the call.

### Making a Call


Press the LINE key will see all dialing descriptions for this phone set. You can make the call by doing one of the following:

- Enter the telephone number with the alphanumerical keypad.
- After entering the number you want to call, press the # key to force dialing or wait for 4 seconds before the number is dialed automatically.
- Using the service function keys on the handset



- Use the pre-assigned service function to configure the most commonly dialed numbers.

To call a number using speed service dialing, follow the steps below:

- Press the SELECT SERVICES key and use the right/left key to select the service.
- Press the SELECT SERVICES key again to precede the service dial.
- Charging the Handset Battery
- Install the battery  into the handset.
- Place the handset onto the base unit and the base unit will start to charge the handset automatically.
- This icon will show on your display during charging progress.

### Checking Voice Messages

If the message waiting indicator at the top of the handset lights up in red, it indicates that there are one or more new messages in the voicemail box. Press the MESSAGE key on the phone to retrieve voice messages. (An external ITSP or PBX must support the voice message feature. And you need to set a voice message code before using the voice mail feature.)


## Support

For further technological support, please email to [support@aeicommunication.com](mailto:support@aeicommunication.com).

## Record of Revision

Date	ver.	Description
2022/6/14	1.0	First issue
2022/9/14	1.1	Update for firmware v0.04

## Documents / Resources

	<p><a href="#">AEi COMMUNICATIONS VX-3X08-BU Series Single or Dual-Line SIP Base and WiFi Cordless Extension Phones</a> [pdf] User Guide</p> <p>VX-3108-BU S, VX-3208-BU S, VX-3X08-BU, VX-3X08-BU Series, Single or Dual-Line SIP Base and WiFi Cordless Extension Phones, VX-3X08-BU Series Single or Dual-Line SIP Base and WiFi Cordless Extension Phones</p>
---	---

## References

- [Web Server's Default Page](#)