



Aeotec Door/ Window Sensor Gen5 ZW120-C Manual

[Home](#) » [Aeotec](#) » Aeotec Door/ Window Sensor Gen5 ZW120-C Manual



Contents [[hide](#)]

1 [Aeotec](#)

2 [Door/ Window Sensor Gen5](#)

[2.1 SKU: ZW120-C](#)

[2.2 Quickstart](#)

[2.3 Important safety information](#)

[2.4 What is Z-Wave?](#)

[2.5 Product Description](#)

[2.6 Prepare for Installation / Reset](#)

[2.6.1 Reset to factory default](#)

[2.6.2 Safety Warning for Mains Powered Devices](#)

[2.7 Inclusion/Exclusion](#)

[2.7.1 Inclusion](#)

[2.7.2 Exclusion](#)

[2.8 Communication to a Sleeping device \(Wakeup\)](#)

[2.9 Quick trouble shooting](#)

[2.10 Association – one device controls an other device](#)

[2.10.1 Association Groups:](#)

[2.11 Configuration Parameters](#)

[2.11.1 Parameter 1: Which value of the Sensor Binary Report will be sent when the door is Opened/Closed.](#)

[2.11.2 Parameter 111: Set the interval time of battery report.](#)

[2.11.3 Parameter 121: To configure which sensor report will be sent when the Sensor is triggered On/Off.](#)

[2.11.4 Parameter 2: Enable/disable wake up 10 minutes when re-power on the Sensor.](#)

[2.11.5 Parameter 255: Reset the Sensor.](#)

[2.11.6 Parameter 3: Which value of the Basic Set will be sent when the door is Opened/Closed.](#)

[2.11.7 Parameter 39: Set the low battery value.](#)

[2.12 Technical Data](#)

[2.13 Controlled Command Classes](#)

[2.14 Explanation of Z-Wave specific terms](#)

[2.15 Related Posts](#)

Aeotec

Door/ Window Sensor Gen5

SKU: ZW120-C



Quickstart

This is a

Alarm Sensor

for

U.S. / Canada / Mexico.

To run this device please connect it to your mains power supply.

To add this device to your network execute the following action:

Turn the primary controller of Z-Wave network into inclusion mode, short press the products Action Button that you can find in the back of the product.

Please refer to the

[Manufacturers Manual](#) for more information.

Important safety information

Please read this manual carefully. Failure to follow the recommendations in this manual may be dangerous or may violate the law.

The manufacturer, importer, distributor and seller shall not be liable for any loss or damage resulting from failure to comply with the instructions in this manual or any other material.

Use this equipment only for its intended purpose. Follow the disposal instructions.

Do not dispose of electronic equipment or batteries in a fire or near open heat sources.

What is Z-Wave?

Z-Wave is the international wireless protocol for communication in the Smart Home. This device is suited for use in the region mentioned in the Quickstart section.

Z-Wave ensures a reliable communication by reconfirming every message (**two-way communication**) and every mains powered node can act as a repeater for other nodes (**meshed network**) in case the receiver is not in direct wireless range of the transmitter.



This device and every other certified Z-Wave device can be **used together with any other certified Z-Wave device regardless of brand and origin** as long as both are suited for the same frequency range.

If a device supports **secure communication** it will communicate with other devices secure as long as this device provides the same or a higher level of security. Otherwise it will automatically turn into a lower level of security to maintain backward compatibility.

For more information about Z-Wave technology, devices, white papers etc. please refer to www.z-wave.info.

Product Description

Aeon Labs Door/ Window Sensor Gen5 is a smart Z-Wave sensor that can detect the status of door/window's open/close in real time. Its a security Z-Wave device that supports security encryption. Also it supports the Over the Air Firmware Updating that allows you wirelessly update its firmware if needs. It can be included and operated

in any Z-Wave network with other Z-Wave certified devices from manufacturers and/or other applications.

Prepare for Installation / Reset

Please read the user manual before installing the product.

In order to include (add) a Z-Wave device to a network it **must be in factory default state**. Please make sure to reset the device into factory default. You can do this by performing an Exclusion operation as described below in the manual. Every Z-Wave controller is able to perform this operation however it is recommended to use the primary controller of the previous network to make sure the very device is excluded properly from this network.

Reset to factory default

This device also allows to be reset without any involvement of a Z-Wave controller. This procedure should only be used when the primary controller is inoperable.

Press the Action Button once that you can find in back of the product for 20 seconds and then release. This procedure should only be used when the primary controller is inoperable.

Safety Warning for Mains Powered Devices

ATTENTION: only authorized technicians under consideration of the country-specific installation guidelines/norms may do works with mains power. Prior to the assembly of the product, the voltage network has to be switched off and ensured against re-switching.

Inclusion/Exclusion

On factory default the device does not belong to any Z-Wave network. The device needs to be **added to an existing wireless network** to communicate with the devices of this network. This process is called **Inclusion**.

Devices can also be removed from a network. This process is called **Exclusion**. Both processes are initiated by the primary controller of the Z-Wave network. This controller is turned into exclusion respective inclusion mode. Inclusion and Exclusion is then performed doing a special manual action right on the device.

Inclusion

Turn the primary controller of Z-Wave network into inclusion mode, short press the products Action Button that you can find in the back of the product.

Exclusion

Turn the primary controller of Z-Wave network into exclusion mode, short press the products Action Button that you can find in back of the product.

Communication to a Sleeping device (Wakeup)

This device is battery operated and turned into deep sleep state most of the time to save battery life time. Communication with the device is limited. In order to communicate with the device, a static controller **C** is needed in the network. This controller will maintain a mailbox for the battery operated devices and store commands that can not be received during deep sleep state. Without such a controller, communication may become impossible and/or the battery life time is significantly decreased.

This device will wakeup regularly and announce the wakeup

state by sending out a so called Wakeup Notification. The controller can then empty the mailbox. Therefore, the device needs to be configured with the desired wakeup interval and the node ID of the controller. If the device was included by a static controller this controller will usually perform all necessary configurations. The wakeup interval is a tradeoff between maximal battery life time and the desired responses of the device. To wakeup the device please perform the following action:

Press the Action Button once, which will trigger sending out the Wake up notification command, press and hold the Action Button for 3 seconds, which will toggle on/off the Sensor be waked up for 10 minutes.

Quick trouble shooting

Here are a few hints for network installation if things dont work as expected.

1. Make sure a device is in factory reset state before including. In doubt exclude before include.
2. If inclusion still fails, check if both devices use the same frequency.
3. Remove all dead devices from associations. Otherwise you will see severe delays.
4. Never use sleeping battery devices without a central controller.
5. Dont poll FLIRS devices.
6. Make sure to have enough mains powered device to benefit from the meshing

Association – one device controls an other device

Z-Wave devices control other Z-Wave devices. The relationship between one device controlling another device is called association. In order to control a different device, the controlling device needs to maintain a list of devices that will receive controlling commands. These lists are called association groups and they are always related to certain events (e.g. button pressed, sensor triggers, ...). In case the event happens all devices stored in the respective association group will receive the same wireless command wireless command, typically a 'Basic Set' Command.

Association Groups:

Group NumberMaximum NodesDescription

1	5	Group 1 is assigned to the Lifeline association group and every device has 5 nodes to associate. The sensor binary report, basic set or notification report command can be sent in this group when the Sensor is triggered.
---	---	---

Configuration Parameters

Z-Wave products are supposed to work out of the box after inclusion, however certain configuration can adapt the function better to user needs or unlock further enhanced features.

IMPORTANT: Controllers may only allow configuring signed values. In order to set values in the range 128 ... 255 the value sent in the application shall be the desired value minus 256. For example: To set a parameter to 200 it may be needed to set a value of 200 minus 256 = minus 56. In case of a two byte value the same logic applies: Values greater than 32768 may needed to be given as negative values too.

Parameter 1: Which value of the Sensor Binary Report will be sent when the door is Opened/Closed.

To set which value of the Sensor Binary Report will be sent when the door is Opened/Closed.

Size: 1 Byte, Default Value: 1

SettingDescription

0	Sensor Binary Report =0xFF when the door is Closed, Sensor Binary Report= 0x00 when the door is opened.
1	Sensor Binary Report= 0x00 when the door is closed, Sensor Binary Report=0xFF when the door is opened.

Parameter 111: Set the interval time of battery report.

Set the interval time of battery report. Note: 1, if the value is less than 10, the time unit is second. If the value is more than 10, the time unit is 4 minutes, which means if the value is more than 10 and less than 240, the interval time is 4 minutes. If the value is more than 240 and less than 480, the interval is 8 minutes. 2, if the current battery report falls below the low battery value (configurable parameter 39), it will send battery report=0xFF.

Size: 4 Byte, Default Value: 0

SettingDescription

0 – 2147483647	The range of interval can be set to 0 to 2147483647.
----------------	--

Parameter 121: To configure which sensor report will be sent when the Sensor is triggered On/Off.

To configure which sensor report will be sent when the Sensor is triggered On/Off.

Size: 4 Byte, Default Value: 256

SettingDescription

16	Basic Set CC is selected.
256	Sensor Binary Report CC is selected.
272	Basic Set CC and Sensor Binary Report CC are selected.

Parameter 2: Enable/disable wake up 10 minutes when re-power on the Sensor.

Enable/disable wake up 10 minutes when re-power on the Sensor.

Size: 1 Byte, Default Value: 1

SettingDescription

0	Disable.
1	Enable.

Parameter 255: Reset the Sensor.

Reset the Sensor.

Size: 4 Byte, Default Value: 0

SettingDescription

0	Reset to default settings.
1431655765	Reset to default settings and excluded from the network.

Parameter 3: Which value of the Basic Set will be sent when the door is Opened/Closed.

To set which value of the Basic Set will be sent when the door is Opened/Closed.

Size: 1 Byte, Default Value: 1

SettingDescription

1	Basic Set 0x00 when the door is Closed, Basic Set= 0xFF when the door is opened.
0	Basic Set=0xFF when the door is Closed, Basic Set=0x00 when the door is opened.

Parameter 39: Set the low battery value.

Set the low battery value.(10% to 50%).

Size: 1 Byte, Default Value: 10

SettingDescription

10 – 50	The range of low battery value can be set to 10% to 50%.
---------	--

Technical Data

Hardware Platform	ZM5202
Device Type	Notification Sensor
Network Operation	Reporting Sleeping Slave
Firmware Version	HW: 78 FW: 1.05
Z-Wave Version	6.51.06
Certification ID	ZC10-15120008
Z-Wave Product Id	0x0086.0x002.0x0078
Frequency	XXfrequency
Maximum transmission power	XXantenna

Controlled Command Classes

- Basic

Explanation of Z-Wave specific terms

- **Controller** — is a Z-Wave device with capabilities to manage the network.
Controllers are typically Gateways, Remote Controls or battery operated wall controllers.
- **Slave** — is a Z-Wave device without capabilities to manage the network.
Slaves can be sensors, actuators and even remote controls.
- **Primary Controller** — is the central organizer of the network. It must be a controller. There can be only one primary controller in a Z-Wave network.
- **Inclusion** — is the process of adding new Z-Wave devices into a network.
- **Exclusion** — is the process of removing Z-Wave devices from the network.
- **Association** — is a control relationship between a controlling device and

a controlled device.

- **Wakeup Notification** — is a special wireless message issued by a Z-Wave device to announce that it is able to communicate.
- **Node Information Frame** — is a special wireless message issued by a Z-Wave device to announce its capabilities and functions.