




Akuvox NS-2 IP Wireless Network Switch User Guide

[Home](#) » [Akuvox](#) » Akuvox NS-2 IP Wireless Network Switch User Guide

Akuvox NS-2 IP Wireless Network Switch




Contents [[hide](#)]

- 1 [Unpacking](#)
- 2 [Device Installation](#)
- 3 [Power Adapter Installation](#)
- 4 [Device Wiring](#)
- 5 [Application Network Topology](#)
- 6 [Documents / Resources](#)
- 7 [Related Posts](#)

Unpacking

Before you begin using the device, please check the version you got and ensure that the following items are included in the shipped box:






NS-2 x 1







Power cable (with DC) x 1

Device Installation







Device Installation




Description of partial section view

Press down the NS-2 on the front, push the two clasps upwards, and make the buckles snap into the guide rail, and then fix it on to the guide rail.





Description of partial section view

Power Adapter Installation



Place the power adapter on the corresponding position of the guide rail as shown in the figure above, and fasten the plastic buckle on the guide rail to fix the power adapter.

Note: Power adapter was not provided in the shipped box, please purchase it separately if you need it.




Note: The power adapter is 48V/1.25A DC or 24V/2A DC. Please refer to Device Wiring section for more connection details.

Device Wiring


Note:

- Each NS-2 supports a maximum of 6 loads, otherwise, it may not be [powered on or power off during use.
- The PLC-S lead wire of NS-2 must be kept at least 5 cm away from the PLC-1 ~PLC-6 lead wire, otherwise the signal will loop back and the network cannot be used.




Application Network Topology

Application Network Topology



| Adapter Vo ltage | Cable Model | Farthest Distance | Adapter Voltage | Cable Model | Farthest Distance |
|---------------------|-------------|-------------------|--------------------|-------------|-------------------|
| 48V | 24awg | 300m | 24V | 24awg | 150m |
| | 20awg | 300m | | 20awg | 250m |
| | 18awg | 300m | | 18awg | 300m |

Topology-2:devices are series connection with NS-2.



| Adapter Voltage | Cable Model | Farthest Distance | Adapter Voltage | Cable Model | Farthest Distance |
|-----------------|-------------|-----------------------------------|-----------------|-------------|--|
| 48V | 24awg | 1000m /6 EI 150m /4 EI 200m /3 EI | 24V | 24awg | 50m/3EI 150m/1EI |
| | 20awg | 250m /6 EI 300m /5 EI | | 20awg | 100m/3EI 150m/2EI 250m/1EI |
| | 18awg | 300m/6EI | | 18awg | 100m/6EI 150m/4EI 200m/3EI 300m/2EI |

Note: When using different cable, the maximum number of devices can connect to NS-2 under the different maximum distances which can refer to the above table. For example, when using a 24awg cable, if the farthest distance is 100m, the maximum number of devices connect to NS-2 is 6.

Notice Information

Information contained in this document is believed to be accurate and reliable at the time of printing. This document is subject to change without notice, any update to this document can be viewed on Akuvox' s website: <http://www.akuvox.com> © Copyright 2022 Akuvox Ltd. All rights reserved.


AKUVOX (XIAMEN) NETWORKS CO., LTD.

ADD: 10/F, NO.56 GUAN RI ROAD, SOFTWARE PARK II, XIAMEN 361009, CHINA

www.akuvox.com



Documents / Resources

| | |
|---|--|
|  | <p>Akuvox NS-2 IP Wireless Network Switch [pdf] User Guide NS-2 IP, Wireless Network Switch, Network Switch, NS-2 IP, Switch</p> |
|---|--|