



Alecto ADI-250 Door Intercom User Manual

[Home](#) » [Alecto](#) » Alecto ADI-250 Door Intercom User Manual 

Contents

- 1 Alecto ADI-250 Door Intercom
- 2 INTRODUCTION
- 3 INTENDED USE
- 4 PACKAGING CONTENTS
- 5 INSTALLATION
- 6 OVERVIEW
- 7 OPERATION
- 8 SETUP
- 9 EXPANDING WITH MULTIPLE OUTDOOR UNITS
- 10 INCREASING THE RANGE USING THE EXTERNAL ANTENNA
- 11 PHOTOS
- 12 DOOR OPENER
- 13 SYSTEM ERROR
- 14 TECHNICAL SPECIFICATIONS
- 15 Documents / Resources
 - 15.1 References
- 16 Related Posts



Alecto ADI-250 Door Intercom

Alecto ADI-250 Door Intercom pro

INTRODUCTION

The ADI-250 is a wireless video door telephone system. It allows you to see who's at the door and to ask what the purpose of the visit is before you open the door. Additionally, a photo is taken of each visitor ringing your doorbell, including the date and time, which is saved in the memory of the indoor post. The indoor post has a memory


capacity for 50 of these photos.

INTENDED USE


The Alecto ADI-250 allows you to wirelessly see who's at the door and to communicate with this person. The Alecto ADI-250 is only suitable for household use and can in no way prevent undesired visitors.

PACKAGING CONTENTS

outdoor unit with a built-in camera and microphone/speaker, a suspension bracket, optionally with battery compartment (extra-large suspension bracket)




indoor unit with built-in display and microphone/speaker and rechargeable battery pack and belt clip



charger with adaptor



screwdriver with screws for installation and mounting




INSTALLATION

Charger:

1. Insert the small plug of the adaptor cable into the bottom of the adaptor and plug the adaptor into a 230V wall


socket.

2. You may choose to place the charger into a table or to use the 2 screws for wall-mounting. The adaptor for the charger is included.




Indoor unit:

1. Slide the battery cover at the rear of the indoor unit down and off the indoor unit.
2. Install the supplied battery pack in the indoor unit, connecting the plug to the battery input.
3. Slide the battery cover back onto the indoor unit.
4. You may also place the belt clip.
5. Place the indoor unit into the charger and leave it there for 10-15 hours to properly charge the battery pack.




The charge indicator will remain lit while charging (attention: this indicator will NOT switch off when the battery pack is charged).






Outdoor unit

You may choose to have the outdoor unit run on batteries or power it via a power adaptor. When powered by batteries, the monitor function will be unavailable. Batteries or a power adaptor for the outdoor unit are NOT included. You may also choose to use the standard doorbell transformer; the current doorbell and bell pusher will then be excluded.




1. Remove the protective cover by flipping off the cover using a screwdriver underneath the clip.
2. Remove the battery cover by unscrewing the 4 small screws.
3. Install the batteries, paying attention to the + and -. Preferably, use Alkaline batteries.
4. Replace the battery cover onto the outdoor unit, fasten it with the 4 small screws and replace the protective cover.
5. Click the battery compartment into the bottom of the outdoor unit.




Power adaptor: (8~12V AC or DC, 1000mA, excluded)

1. Remove the seal cover by unscrewing the 4 small screws.
2. Connect the 8-12V adaptor according to the illustration below.

3. Fasten the seal cover back onto the outdoor unit.




First, strip the insulation approximately 1cm. You may ignore the (+) and (-) connection. Push in the wire and fix it. You may hide the connection for the battery compartment with the supplied rubber panel with bonding strip. Remove the protective layer of the rubber panel and stick it onto the bottom covering the connections.




Mounting

1. Determine the installation height for the outdoor unit.
2. Hold the suspension bracket against the wall at the desired height and draw the drill holes.
3. Drill the holes, insert the plugs and mount the suspension bracket. You can suspend the bracket exactly straight using the built-in spirit level. When using an external power source, lead the wires through the hole in the rear of the suspension bracket and connect them to the connection strip.
4. Now first slide the top of the outdoor unit into the suspension bracket and then push the bottom into the bracket, according to the illustration below.
5. Now fasten the outdoor unit into the bracket using the supplied screw.




If the camera must be aimed at an angle to the left or right, first mount the wall bracket at an angle to the wall and then place the straight wall bracket onto it.



OVERVIEW

Indoor unit

1. Display
2. Left soft-button
3. Talk button, to answer calls
4. Charge LED indication
5. Manual snapshot, camera selection button
6. Direction buttons
7. Built-in microphone
8. Power button, Stop button, to end calls
9. Right soft-button, to show images, to unlock



10. Switch for clicking the external antenna outward for improved range
11. External antenna
12. Built-in speaker
13. Battery compartment
14. Charger

15. Adaptor cable input

Outdoor unit

16. Built-in speaker

17. Night light


18. Built-in camera

19. Photo cell

20. Bell pusher with built-in lighting

21. Built-in microphone

22. Separate battery compartment



OPERATION

To switch on/off


Outdoor unit: As soon as the batteries are installed or the adaptor is connected, the outdoor unit will be enabled. The outdoor unit cannot be switched off. Indoor unit: Press and hold the button for 4 seconds to switch on the indoor unit. Press and hold the button again for 8 seconds to switch off the indoor unit.

When the doorbell rings

Upon pressing the push button, the push button will illuminate. A “ding dong” sound will be emitted and the face of the visitor will be shown on the display of the indoor unit.

- when the surrounding light is inadequate, the object lighting of the outdoor unit is enabled
- a photo of the visitor is taken automatically and is stored in the memory of the indoor unit (see also chapter 9)
- when you do nothing, the call is ended automatically after ± 20 seconds
- if you want to ignore this visit, press the button; the image of the visitor will disappear from the display

- if you'd like to talk to your visitor, you may press the button to accept the call
- You may talk to your visitor through the built-in microphone and speaker in the indoor unit and in the outdoor unit; please keep in mind NOT to hold the indoor unit against your ear like a regular telephone receiver. Leave the indoor unit in the charger >30cm while talking to your visitor or keep the indoor unit in your hand at approx. 30cm from your mouth and speak at a normal voice volume level.



- the volume of the speaker of the indoor unit may be adjusted using the and buttons (the volume of the speaker of the outdoor unit is fixed and cannot be changed).
- use the and buttons to set the screen brightness.
- a photo was already taken upon ringing the doorbell, but you may choose to take another picture of your visitor during your conversation by pressing the button.
- press the button to disconnect the call (or wait for 2 minutes until the call is disconnected automatically)


When multiple outdoor units are registered: When multiple outdoor units are registered and somebody presses the doorbell, the camera number X# in the upper part of the screen will indicate at which outdoor unit your visitor is calling.

Monitor: (looking outside yourself (only when used on external power))

Also when there's nobody pressing the doorbell, you may still enable the camera and take a picture.


- briefly press the button to switch on the indoor unit from its sleep mode
- press and hold the soft button for 1 second to switch on the monitor function; the display will be enabled to show the area in front of the camera
- you may listen via the speaker (talking back is only possible after pressing the button)
- press the button to take a picture
- press the button to disconnect or wait for 5 minutes until the connection is disconnected automatically

When multiple outdoor units are registered: When multiple outdoor units are registered and you press and hold the button for 1 second, you must first use the and buttons to select the desired outdoor unit and then press the button to confirm.



SETUP

Via the menu function of the indoor unit, you may manage the various settings of the video door phone.



Volume

Except for when in use, you may adjust the volume in the menu:

1. with the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
2. indoor unit MENU soft-button
3. use the and buttons to select the Volume function
4. press the Select soft-button
5. use the and buttons to set the volume
6. press 2x the BACK soft-button to save your settings and to leave the menu

Brightness

Except for when in use, you may adjust the Brightness in the menu:

1. with the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
2. press the MENU soft-button
3. use the and buttons to select the Brightness function
4. press the Select soft-button
5. use the and buttons to set the Brightness
6. press 2x the BACK soft-button to save your settings and to leave the menu

Time and date

The photo of the visitor also shows the time and date. You may set the time and date here:

1. with the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
2. press the MENU soft-button
3. use the and buttons to select the Date & Time function
4. press the Select soft-button
5. press the and buttons to switch between hours, minutes, day and date and use the and buttons to change the settings
6. press 2x the BACK soft-button to save your settings and to leave the menu

Key tone

Each time you press a button, a key tone will be emitted. You may enable or disable this key tone:

1. with the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
2. press the MENU soft-button
3. use the and buttons to select the Key tone function
4. press the Select soft-button
5. use the and buttons to select whether you want to switch the key tone On or Off
6. press the Select soft-button to save your setting and press the BACK button to leave the menu

Automatic snapshot

Of each visitor pressing the doorbell a photo is taken automatically. You may disable or enable this function or set it to 1 photo/press, 2 photos/press or 3 photos/ press:

1. with the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
2. press the MENU soft-button
3. use the and buttons to select the Auto. snap set function.
4. press the Select soft-button
5. use the and buttons to set the automatic snapshot to On or Off
6. press the Select soft-button to save your setting and press the BACK button to leave the menu

To view photos

Of each visitor pressing the doorbell a photo is taken automatically (the automatic snapshot function must be enabled). You may view these photos as follows:

1. with the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
2. press the REPLAY button OR
3. with the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
4. press the MENU soft-button
5. use the and buttons to select the Snap show function.
6. press the Select soft button Now the last photo taken will appear in the display. The red letter in the upper part of the screen indicates which camera has taken the photo. The green digits represent the photo number. Press the Del button to delete a photo. Press the BACK button to leave the photo viewer

Reset to factory settings

1. with the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
2. press the MENU soft-button
3. use the and buttons to select the Default Set function.
4. press the Select soft-button and use the and buttons to choose whether to perform a factory reset (Yes) or not (No)

Factory settings

volume: level 5 brightness: level 5 key tone: on automatic 1 snapshot: on photo memory: empty

EXPANDING WITH MULTIPLE OUTDOOR UNITS

Introduction


Up to a maximum of 4 outdoor units may be connected to a single indoor unit. In this way you can guard multiple entrances to your company or home (main entrance, personnel entrance, warehouse, garden gate, and garage). Additional outdoor units are available via the Alecto service department via the internet www.alecto.nl

To register additional outdoor units

1. Install the batteries into the indoor unit and charge them.
2. Install the batteries into the outdoor unit or connect the adaptor to the unit
3. Keep both the indoor unit and outdoor unit handy
4. Keep a small screwdriver or paperclip handy

To register

1. with the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
2. press the MENU soft-button
3. use the and buttons to select the Register function
4. press 2x the SELECT soft-button; in the lower part of the display 'Searching...' will appear.
5. press 1x the bell pusher of the outdoor unit
6. now press and hold the register button at the rear of the outdoor unit until the camera lighting starts flashing after several seconds
7. the indoor unit and outdoor unit are now searching for each other; the registration is successful as soon as the indoor unit shows the image of the outdoor unit; the number of the outdoor unit is indicated in the middle of the display at the top



Maximum 4 outdoor units

The indoor unit is suitable for registering 4 outdoor units. As soon as you try to register a fifth outdoor unit, the

warning “Register Full” will appear.



To de-register

You can only de-register ALL outdoor units at once. After doing so you may choose to register a certain outdoor unit again.


1. With the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
2. Now simultaneously press the button and the right button and press and hold these buttons for 5 seconds.
3. After 5 seconds the message 'Registration Cleared' will appear and all outdoor units are now de-registered



INCREASING THE RANGE USING THE EXTERNAL ANTENNA

The indoor unit is provided with an external antenna. The antenna sits on top of the indoor unit.

1. Push the silver button to the right.
2. The external antenna will pop out.
3. Rotate the antenna until it's standing upright to increase the reception sensitivity



PHOTOS

Introduction

- Of each person pressing the doorbell a photo is taken automatically.
- This photo is saved in the internal memory of the indoor unit, including the time and date of that picture.
- You may also take photos yourself in the monitor mode.
- The photos are saved in the internal memory of the indoor unit and CANNOT be copied or moved elsewhere.
- The indoor unit has a memory capacity for 50 photos.
- Via the menu function of the indoor unit you may disable the automatic snapshot function for visitors.
- The indoor unit has a memory capacity for 50 photos. When the memory is full, each new photo will overwrite the oldest photo in the memory. You CANNOT export the photos

To view and delete

1. with the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
2. press the Replay soft-button; the most recent photo will be shown
3. use the and buttons to scroll the photo directory
4. in the bottom of the screen the time and date of the snapshot are shown
5. in the upper middle part of the screen the order number of the photo is shown
6. press the left DEL soft-button to delete the current photo, press the right YES button to confirm or press the left NO soft-button to cancel In addition to using the Replay soft-button, you may also view photos via the menu by selecting the 'Snap Show' option in the setup menu.

DOOR OPENER


Introduction

The indoor post is provided with a control function to open an automatic electric door lock. This function is only available when the talk-back function () is activated and the outdoor unit is connected to an external adaptor. The outdoor unit can control both NC (normally closed) and NO (normally opened) door locks.

Operating the door lock

1. Upon pressing the push button, the push button will illuminate. A 'ding dong' bell signal is emitted and the face of your visitor appears in the display of the indoor unit.
2. To talk to your visitor, press the button to accept the call.
3. Press the button to activate the door lock.
4. Your visitor can now open the door and enter.

Door lock connection



Door lock switch duration setup

1. With the indoor unit on stand-by, first briefly press the button to wake up the indoor unit
2. Now simultaneously press the button and the right button and press and hold these buttons for 5 seconds.
"Unlock time" will appear in the display.
3. Use the and buttons to select the correct outdoor post with door lock (1~4)
4. Press the or button to set the switch duration (1~25 sec.)
5. Now press the Back soft-button; "OK" will appear in the display as a confirmation.
6. The screen turns off automatically after 5 seconds



SYSTEM ERROR

If you think that an error has occurred in the system, please remove the batteries from the indoor unit and outdoor unit. Now wait several minutes and replace the batteries. If this does not resolve the problem, please contact the Alecto service department via the internet www.alecto.nl

TECHNICAL SPECIFICATIONS

Indoor-unit

1. **Receiving Frequency Range:** 2.400GHz ~ 2.4835GHz
2. **Monitor:** 3.5" Color LCD
3. **Data Rate:** 2.0Mbps
4. **Receiving Sensitivity :** -90dBm
5. **Demodulation Type:** GFSK
6. **Resolution:** 320x240(RGB)
7. **Transmitting Power:** 19dBm (TYP)
8. **Power Requirement:** Ni-MH3.6V, 800mAh
9. **Power Consumption:** 400mA Max
10. **Operating Temperature:** -10°C ~ 40°C
11. **Operating Humidity:** 0% ~ 85%RH
12. **Weight:** 188g
13. **Size receiver:** 85x115x27mm (WxHxD)
14. **charger:** 93x55x75mm (WxHxD)
15. **No. of outdoor stations:**Max.4

Outdoor-unit


- **Transmit Frequency:** Range 2.400GHz ~ 2.4835GHz
- **Data Rate:** 2.0Mbps
- **Transmitting Power:** 19dBm (TYP)
- **Modulation Type:** GFSK
- **Transmitting Distance:** Outdoor: 200m, Indoor: 50m
- **Image Sensor Type:** 1/4" Color CMOS Image Sensor
- **Effective Pixels:** H:320 V:240
- **Image Processing:** Motion JPEG

- **Image Resolution / Frame Rate:** H:320 V:240 / 25fps
- **White Balance:** Auto
- **Lens:** 2.1mm / F2.6
- **Viewing Angle (Diagonal):** 135°
- **Minimum Illumination:** 1 LUX (without LED illumination)
- **LED:** 6 LEDs
- **Power Requirement:** 8~12V AC or DC +/- 5% 4 LR6(AA), 1.5V alkaline batteries
- **Power Consumption:** 500mA Max (cells) 400mA Max (8~12V AC or DC)
- **Door contact:** Contact rating (Res. load): 0.3A 60VDC / 0.5A 125VAC / 1A 30VDC
- **Max. switch voltage:** 125VAC / 60VDC
- **Max. switching current:** 2A
- **Max. switching power:** 62.5VA / 30W
- **Operating Temperature:** -30°C ~ 40°C
- **Operating Humidity:** 0% ~ 85%RH
- **Weight:** 109g excl. 251 incl. batteries
- **Size:** 50x125x35mm (WxHxD) excl. batteries 50x200x35mm (WxHxD) incl. batteries

DECLARATION OF CONFORMITY

This equipment complies with the essential requirements and provisions as described in the European Directive 2014/53/EU. The declaration of conformity is available at: <http://DOC.hesdo.com/ADI-250-DOC.pdf> **Frequency:** 2.400GHz ~ 2.4835GHz **Maximum Power:** < 19dBm -70-

Documents / Resources

	<p>Alecto ADI-250 Door Intercom [pdf] User Manual ADI-250, Door Intercom, ADI-250 Door Intercom</p>
---	---

References

- [A Alecto.nl](http://Alecto.nl) | alectonl