



# **ALLEGRO MICRO CTD455-BB-06B5 Evaluation Board Owner's Manual**

Home » ALLEGRO MICRO » ALLEGRO MICRO CTD455-BB-06B5 Evaluation Board Owner's Manual



### **Contents**

- 1 ALLEGRO MICRO CTD455-BB-06B5 Evaluation **Board**
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 FAQ
- **5 DESCRIPTION**
- **6 FEATURES**
- **7 USING THE EVALUATION BOARD**
- **8 Power Input and Board Configuration**
- 9 Bill of Materials
- 10 Documents / Resources
  - 10.1 References



**ALLEGRO MICRO CTD455-BB-06B5 Evaluation Board** 



### **Product Information**

# **Specifications**

Model: CT455-A48B5-TS08Type: Evaluation Board

### **Description**

The CT455-A48B5-TS08 Evaluation Board is designed to provide users with a platform to evaluate and test various functionalities.

### **Features**

- Feature 1
- Feature 2
- Feature 3

# **Product Usage Instructions**

# **Getting Started**

- 1. Unbox the CT455-A48B5-TS08 Evaluation Board.
- 2. Connect the necessary cables and power source as instructed in the manual.
- 3. Power on the board following the provided guidelines.

# **Functionality Testing**

Utilize the features of the board to test specific functionalities.

- 1. Perform Function A by following the steps outlined in the user guide.
- 2. Test Feature B by inputting the required parameters.
- 3. Evaluate Function C for its performance under different conditions.

### **Troubleshooting**

 If you encounter any issues while using the board, refer to the troubleshooting section of the user manual for guidance.

#### **Maintenance**

- Ensure the board is kept in a clean and dust-free environment.
- Regularly check for any loose connections or signs of wear and tear.

### **Safety Precautions**

 Always follow the safety guidelines provided in the user manual when operating the CT455-A48B5-TS08 Evaluation Board.

#### **FAQ**

### Q: How do I update the firmware of the evaluation board?

**A:** Firmware update instructions can be found in the user manual. Ensure to follow the steps carefully to avoid any errors.

# Q: Can I use the board with external peripherals?

**A:** Yes, the board supports connectivity with external peripherals. Refer to the manual for compatibility and connection details.

### **DESCRIPTION**

- The Allegro CTD455 evaluation board demonstrates the advantages of the CT455 high dV/dt optimized XtremeSense™ TMR coreless current sensor in enabling high-accuracy current measurements for many consumer, enterprise, and industrial applications.
- The device supports a ±6 mT magnetic field range where the CT455 senses and translates the magnetic field into a linear analog output voltage. The device achieves a total error output of less than ±1.0% over supply voltage and temperature after calibration.
- While the sensor is pre-programmed to compensate for gain and offset temperature drift, the ability to adjust
  offset and gain relaxes mechanical tolerances during sensor mounting. The device has less than 300 ns output
  response time, while the current consumption is approximately 6.0 mA. The CT455 is housed in a very lowprofile, industry-standard 8-lead TSSOP package that is both green and RoHS compliant.

#### **FEATURES**

• Preset magnetic field range: ±6 mT

• Low-noise performance

• Optimized for high dV/dt applications

• Linear analog output voltage

Response time: <300 ns</li>Supply voltage: 5.0 V

• Operating temperature: -40°C to 125°C



Figure 1: CTD455-BB-06B5 Evaluation Board

Table 1: CTD455-BB-06B5 Evaluation Board Configurations

Configuration Name	Part Number	Output Voltage Range	Bandwidth
CTD455-BB-06B5	CT455-A48B5-TS08	0.50 to 4.50 V	1 MHz

**Table 2: General Specifications** 

Specification	Min.	Nom.	Max.	Units
Input Operating Temperat ure	-40	_	125	°C
Input Operating Voltage	4.75	5.0	5.50	V

### **USING THE EVALUATION BOARD**

- This section provides an overview of the connections and configuration options of the CTD455-BB-06B5 evaluation board. Figure 2 highlights the proper configuration.
- The CT455 datasheet contains detailed information on the use and functionality of each pin, and detailed specifications about the sensor, and should be consulted for more information than is contained in this user guide.



Figure 2: CTD455-BB-06B5 Evaluation Board with Busbar

# **Power Input and Board Configuration**

- When current is flowing through a busbar above or below the CT455, the XtremeSense TMR sensor inside the
  chip senses the field which in turn generates a differential voltage signal that then goes through the Analog
  Front-End (AFE) to output a current measure-ment as low as ±1.0% full-scale total output error (EOUT).
- The chip is designed to enable a fast response time of 300 ns for the current measurement from the OUT pin as the bandwidth for the CT455 is 1.0 MHz. Even with a high bandwidth, the chip consumes a minimal amount of power.

### **Power-On Time**

- Power-On Time of 100 μs is the amount of time required by CT455 to start up, fully power the chip, and become fully operational from the moment the supply voltage is greater than the UVLO voltage.
- This time includes the ramp-up time and the settling time (within 10% of steady-state voltage under an applied magnetic field) after the power supply has reached the minimum VCC.

### **Response Time**

Response Time of 300 ns for the CT455 is the time interval between the following terms: when the primary
current signal reaches 90% of its final value, and when the chip reaches 90% of its output corresponding to the
applied current.

### **SCHEMATIC**

Figure 3 below shows the schematic of the CTD455-BB-06B5 evaluation board.





Figure 3: CTD455-BB-06B5 Schematic

# **LAYOUT**

Figures 4 and 5 below show the top and bottom layers of the CTD455-BB-06B5 evaluation board.






Figure 4: CTD455-BB-06B5 Top Layer

Figure 5: CTD455-BB-06B5 Bottom Layer

# **Bill of Materials**

### Table 3: CTD455-BB-06B5 Bill of Materials

Designato r	Quanti ty	Description	Manufacturer	Manufacturer Part Number		
ELECTRICAL COMPONENTS						
РСВ	1	CTD455-BB-06B5 Evaluation Board Allegro MicroSystem		_		
U\$2	1	CT455 Sensor Allegro MicroSystems -		-		
JP3	4	Male Header Connectors Samtec		TSW-103-07-F-S		
C1	1	Capacitor, Ceramic, 1.0 μF, 25 V, 10% X7R 0603	TDK	MSAST168SB7105KT NA01		
VOUT	1	SMA Connector	Samtec	SAM8971-ND		
R0	1	Resistor, 0 Ω	Yageo	RC1206FR-130RL		
OTHER CO	OTHER COMPONENTS					
_	1	Busbar (1/2" width, 1/16" thick)	_	_		
_	2	Connector Heads	TE Connectivity	225693-E225693-E		
_	2	M3x6mm Metal Screws for Connector Heads	UXCell	a15120300ux0251		
_	2	Plastic High-Temperature Screws for Busbar	Misumi	SPS-M5X15-C		
_	2	Plastic High-Temperature Nuts for Bus bar Misumi SPS-M5-N		SPS-M5-N		
_	2	Plastic High-Temperature Washers for Busbar	Misumi	SPS-6-W		

### **RELATED LINKS**

CT455 Product Page: <a href="https://www.allegromicro.com/en/products/sense/current-sensor-ics/sip-package-zero-to-thousand-amp-sensor-ics/ct455">https://www.allegromicro.com/en/products/sense/current-sensor-ics/sip-package-zero-to-thousand-amp-sensor-ics/ct455</a>

### **Revision History**

Number	Date	Description
_	May 23, 2024	Initial release

- Copyright 2024, Allegro MicroSystems.
- The information contained in this document does not constitute any representation, warranty, assurance, guarantee, or inducement by Allegro to the customer for the subject matter of this document. The information being provided does not guarantee that a process based on this infor-mation will be reliable, or that Allegro has explored all of the possible failure modes. It is the customer's responsibility to do sufficient qualification testing of the final product to ensure that it is reliable and meets all design requirements.
- Copies of this document are considered uncontrolled documents.
- For the latest version of this document, visit our website: www.allegromicro.com
- Allegro MicroSystems 955 Perimeter Road

• Manchester, NH 03103-3353 U.S.A. www.allegromicro.com

### **Documents / Resources**



<u>ALLEGRO MICRO CTD455-BB-06B5 Evaluation Board</u> [pdf] Owner's Manual CT455-A48B5-TS08, CTD455-BB-06B5, CTD455-BB-06B5 Evaluation Board, CTD455-BB-06B 5, Evaluation Board, Board

# References

User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.