



aptos MAC DTU Data Transfer Unit User Manual

[Home](#) » [aptos](#) » aptos MAC DTU Data Transfer Unit User Manual 

Contents

1 Aptos MAC™ DTU Data Transfer Unit User Manual

1.1 Important Safety Information

- 1.1.1 Read this First
- 1.1.2 Safety Instructions
- 1.1.3 User
- 1.1.4 Support and Contact Information
- 1.1.5 Other Information

1.2 Aptos Solar Technology Microinverter System

- 1.2.1 Microinverter
- 1.2.2 DTU
- 1.2.3 Aptos Monitoring Server

1.3 Interface Layout

- 1.3.1 Interface Layout
- 1.3.2 Export Management Function (RS485 port)
- 1.3.3 Remote Active Power Control (RS485 port)
- 1.3.4 DRM Port
- 1.3.5 Local Install Assistant

1.4 DTU Installation

- 1.4.1 System Capacity
- 1.4.2 Basic Conditions Required
- 1.4.3 Dimensions
- 1.4.4 System Installation Sequence
- 1.4.5 Preparation
- 1.4.6 Install the DTU

1.5 Complete Installation Map

1.6 Site Creation on HMP

1.7 Customer Login

1.8 Browse the Web Station

1.9 View Phone APP

1.10 LED Indicators

1.11 Technical Data

2 Documents / Resources

2.1 References

3 Related Posts

Aptos MAC™ DTU Data Transfer Unit User Manual





www.aptossolar.com

Solar for Innovators




Version 1.0 (August 2021)

Important Safety Information

Read this First

This manual includes important instructions for installing and maintaining the Aptos Data Transfer Unit (MAC™ DTU).

Safety Instructions

Symbol	Usage
	Indicates a hazardous situation that can result in deadly electric shock hazards, other serious physical injuries, or fire hazards.
	Indicates directions that must be fully understood and followed entirely to avoid potential safety hazards including equipment damage or personal injury.
	Indicates that the described operation must not be carried out. The reader should stop, use caution, and fully understand the operations explained before proceeding.

- Note that only professionals can install or replace DTU.
- Do not try to repair DTU without approval from Aptos. If DTU is damaged, please return to your installer for repairing/replacing. Disassembling DTU without approval from Aptos will invalidate remaining of the warranty period.
- Please read all instructions, warnings, and technical specifications carefully.
- Do not use Aptos products in ways unspecified by manufacturer. Doing so may result death/injury to persons or damage to equipment.

User

This manual is only for professional installation and maintenance personnel to use.

Support and Contact Information

If you have technical queries concerning our products, please contact your installer or distributor. If further support is required, please contact Aptos' support at this link.

- www.aptossolar.com
- Aptos customer service center: info@aptossolar.com

Other Information

Product information is subject to change without notice. The user manual will be updated frequently; please refer to Aptos Solar Technology's official website at www.aptossolar.com for the latest version.

Aptos Solar Technology Microinverter System

Microinverter


The Microinverter converts the DC output of PV modules into grid-compliant AC power. It sends the output information of PV modules and the operation data of the microinverters to the DTU, which is the hardware basis of the module-level monitoring. With conversion efficiency up to 96.7% and MPPT efficiency up to 99.9%, Aptos microinverters rank in the first class of the world's microinverter industry.

DTU

The DTU is the key component in Aptos microinverter system. It works as the communication gateway, which operates between the Aptos microinverters and the Aptos Monitoring Server. The DTU communicates with the microinverter wirelessly via 2.4GHz Proprietary RF (Nordic), collecting the operation data of the system. Meanwhile, the DTU connects to the Internet via router and communicates with Aptos Monitoring Server. The microinverter system operation data will be uploaded to Aptos Monitoring Server via DTU.



Aptos Monitoring Server

The Aptos Monitoring Server collects the operation data and status of the microinverters in the system and provides the module-level monitoring for the users and maintenance staff. The following diagram shows the Aptos Microinverter system:



Interface Layout

Interface Layout



Item	Description
A	SD Card Slot
B	DTU Power Indicator
C	DTU Communication Indicator (With Server)
D	DTU Communication Indicator (With MI)
E	DTU Alarm Indicator
F	WiFi Antenna (2.4G)
G	RS485
H	DRM Port (For Australia only)
I	Ethernet Port
J	USB Port
K	Reset Bottom
L	Power Port
M	2.4G Antenna

Export Management Function (RS485 port)


a. Device Required.

- Aptos Microinverter: 2-in-1 Unit and Single Unit
- DTU: MAC™ DTU:
- Meter: Chint Meter (DDSU666)/Chint Meter (DTSU666)/CCS WattNode Meter

b. Export Control Type

- Type 1: Zero Export: to limit the exporting power to zero so that it can prevent the generated power feed back to the grid.
- Type 2: Export Limit: to limit the exporting power within a certain value.
- Type 3: Production and Consumption Monitoring: enable to measure the PV generating under a high accuracy.

c. Installation Diagram.



Note: Please refer to “Aptos Export Management Technical Note” for more details.

Remote Active Power Control (RS485 port)

Some countries require generating plants to be equipped with a logic interface (input port) in order to cease output active power or limit active power to a regulating level. This logic input can be RS485 port, Ethernet port, etc. MACTM DTU provide RTU Modbus protocol over RS485 port for this remote active power control. For more information, please refer to “Modbus implementation Technical Note”.

DRM Port

DRM port is provided to support several demand response modes as below by connecting external control device with a standard RJ-45 connector. For MACTM DTU, it can support DRM0/5/6/7/8 if used with Aptos microinverters.

Mode	Requirement
DRM0	Operate the disconnection device
DRM1	Do not consume power
DRM2	Do not consume at more than 50% of rated power
DRM3	Do not consume at more than 75% of rated power AND Source reactive power if capable
DRM4	Increase power consumption (subject to constraints from other active DRMs)
DRM5	Do not generate power
DRM6	Do not generate at more than 50% of rated power
DRM7	Do not generate at more than 75% of rated power AND Sink reactive power if capable
DRM8	Increase power generation (subject to constraints from other active DRMs)

Local Install Assistant

Local Install Assistant is a new function integrated with MACTM™ DTU. Please download the Installer App (for installer/distributor use only) first.



MAC™ DTU has improved from the previous generation of DTU products. New functions allow installer to:

- a. One step to complete the WiFi configuration;
- b. Station overall Inverters status indication allows the installer to see how many MI under this DTU is working properly (and the details for each MI) and how many is abnormal (and the details for each MI) with one glance of eyes;
- c. Add the Connection status, which will display the signal strength between each MI with connected DTU, so that installer can adjust the DTU installation location accordingly. This function will simplify the DTU installation, and avoid a second visit by the installer due to a poor connection between DTU and certain MI.

Note: Please refer to “Aptos Local Install Assistant Technical Note” for more details.

DTU Installation

System Capacity

The MAC™ DTU is capable of monitoring up to 99 panels. If the communication between the DTU and microinverter caused by the installation conditions, the number of PV modules that the DTU can monitor may be reduced.

Note: Max. monitoring quantity is for open space, installation condition meets the requirement from both DTU and Microinverter manual, and the distance between Microinverter and DTU needs to be within the required range.

Basic Conditions Required

Before installing the DTU, ensure that the site meets the following requirements:



- Standard 220 VAC power outlet.
- Stable broadband internet connection.
- Router with Ethernet port.

The environmental requirements for DTU installation:

- Away from dust, liquid, acidic, or corrosive gas.
- The temperature should be between -20°C and 55°C.


If you plan to install the DTU on the wall, please prepared two #8 (4.166mm diameter) screws and a screwdriver in advance.

Dimensions



(Unit: mm)

System Installation Sequence



Preparation

A. Download the **Aptos** mobile App



B. Check the box for following items:

- Aptos MAC™ DTU
- Two Antennas
- Adapter
- Bracket
- 5-Pin Plug

C. Choose the way MACTM DTU connects to the Internet:


Use WiFi or Ethernet. Please prepare for the following items, if needed:

- Ethernet Cable (for Ethernet option).
- Aptos Installer App.

Install the DTU

Step 1: Install the antennas

Take two 2.4G antennas out from the box. Screw the antenna into the WiFi port and 2.4G port.



Note: If the DTU installation location is inside the metal box or under the metal / concrete roof, extended 2.4G cable or 2.4G sucker antenna will be suggested, which can be purchased from Aptos or local electrical store (Please contact Aptos Tech. support team for the detail type of the cable or antenna at info@aptossolar.com).

Step 2: Choose an Installation Location


- Installed on the top floor to increase the signal strength.
- Installed near the center of the PV array.
- Installed at least 0.5m above the ground and more than 0.8m away from the corner.

Note: To prevent signal dilution, do not install the DTU directly above metal or concrete.

Step 3: Choose the Installation Method

Option 1: Mount the DTU on the wall.


- Screw the bracket on the wall. Choose at least two screw holes (one from each side) to affix the bracket (the M4 screws need to prepare by installer);



- Match the brackets upper buckle with MAC™ DTU;




- Match the brackets lower buckle by gently press the lower side of the MACTM DTU until you hear a click. Please make sure the antennas are vertical to the wall.



Option 2: Place the DTU on the table


- Place DTU on the table. Ensure the antennas are vertical to the table;



- Plug in the power adapter to power the DTU;
- Set up with Internet.

- Use a smart phone or tablet to open the Installer App and log-in. Approach to “Me” on the bottom of the page and then “Network Configuration”. Complete the WiFi configuration (for WiFi option);
- Use the LAN cable. Connect one side with the house router and the other side with the DTU Ethernet port


Use the smart phone/tablet to open the Installer App and login. Approach to “Me” on the bottom of the page and then “Network Configuration”, select “Ethernet” (for Ethernet option).



Complete Installation Map



Please complete the installation map.

- Peel the serial number label (as circled below) from the DTU and place it on the installation map.



B) Complete system information of the installation map shown as follows.

To sheet _____

N S E W (circle one) 	Panel Group: Azimuth: Tilt: Sheet ___ of ___			Customer Information:				DTU Serial Number:						
	1	2	3	4	5	6	7	8	9	10	11	12	13	14
A														
B														
C														
D														

To sheet _____


To sheet _____

To sheet _____

Site Creation on HMP









- A. Install Aptos Installer APP by searching “Aptos” at the App Store (IOS) or Play Store (Android).
- B. Open the APP and login in with your installer account name and password. If you are a new installer with Aptos, please apply an Installer account from your distributor in advance.
- C. Add Station, select the “Station” tab on the bottom, then select “⊕” on the right top side of the page.
- D. Select “Quick” for Single-DTU and “Profession” for Multi-DTU.
- E. Please fill in the station details accordingly, and press “Next” after completed.
- F. Press “Add DTU ID”, scan the DTU ID (or you can manually input ID) and press “Next” after complete.
- G. Click “Start binding” and choose the angle and tilt base on the installation.
- H. Scan the Microinverter ID (or manually input the ID) and click the check box after completing each ID input. Press “Finish” once all Microinverter ID has been input.
- I. Disable the Scan function on the top of the right-hand side and design the Layout base on the installation. Click the tick box on the top of the right-hand side. Then select “Next” after completing the design.
- J. Upload a picture of the site and select “Finish” to complete the site creation.
- K. The new site will appear on the Station list from the Installer account.
- L. Please click the “Networking” button after the power station is created.

Download mobile phone application to view station information



LED Indicators

The system status can be viewed by Aptos local APP or LED indicators.

LED mark	LED Color	Explanation
		DTU power on or power off
		Network communication
		Microinverter communication
		Fault State

LED States

LED Indicator	Status	Description
---------------	--------	-------------

All		Firmware upgrading
		Starting up
		DTU power on
		DTU power off
		DTU are communicating with Aptos Monitoring Server
		Internet disconnected
		Internet connected, Server disconnected
		Local APP connected
		Microinverters are communicating
		MI IDs Incomplete
		No MI ID (Please perform Networking)
		Normal
		DTU alarm occurred
		Microinverter alarm occurred
		Meter alarm occurred


Technical Data

Model	MAC™ DTU
Type	2.4GHz Proprietary RF (Nordic)
Maximum distance (open space)	200m
Monitoring data limit from solar panels	99 ²
Communication to Cloud	
Type	WIFI(802.11b/g/n) ¹ /Ethernet
Sample rate	Per 15 minutes
Communication to Meter	
Signal	RS485
Maximum distance (RS485 cable)	500m
Display	
LED	LED Indicator * 4 – RUN, Cloud, MI, ALM
APP	Local APP
Power Supply	
Type	External plug-in adapter

Adapter input voltage/frequency	100 to 240 V AC / 50 or 60Hz
Adapter output voltage/current	5V / 2A
Power consumption	2.5W (typical), 5W (maximum)
Mechanical Data	
Ambient temperature (°C)	-20°C to 55°C
Dimensions (W×H×D)	200mm×101mm×29mm
Weight	0.20 kg
Mounting system	Wall mounting / Desktop mounting
Features	
Compliance	FCC 15B, FCC 15C, EN60950-1, EN61000-3-2, EN61000-3-3, EN301489, EN300328, EN300440, RCM
<p>*1 If the DTU installation location is inside the metal box or under the metal/concrete roof, extended antenna will be suggested.</p> <p>*2 Depending on the installation environment, please refer to user manual for more details.</p>	

© 2021 Aptos Solar Technology, LLC. All rights reserved.

Documents / Resources

	aptos MAC DTU Data Transfer Unit [pdf] User Manual MAC DTU, Data Transfer Unit, MAC DTU Data Transfer Unit
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.