

[manuals.plus](#) /› [Suzuki](#) /› [Suzuki Samurai Service Manual \(1986-1988\)](#)**Suzuki Samurai**

Suzuki Samurai Service Manual (1986-1988)

Comprehensive Repair and Maintenance Instructions

INTRODUCTION

This service manual provides detailed information and illustrations for the maintenance, service, and repair of Suzuki Samurai models manufactured between 1986 and 1988. It is designed to assist owners and technicians in performing various tasks, from routine maintenance to complex repairs, ensuring the proper functioning and longevity of the vehicle.

The manual contains 482 pages of comprehensive content, including exploded illustrations, diagrams, and step-by-step instructions to guide you through each procedure. Refer to this manual for accurate and reliable service information.




Figure 1: Front cover of the Suzuki Samurai Service Manual, indicating coverage for 1986, 1987, and 1988 models.

GENERAL INFORMATION AND SPECIFICATIONS

This section outlines general information pertinent to the Suzuki Samurai and provides key specifications of this service manual.

Manual Specifications

Publisher	RePub
Publication Date	January 1, 1986
Language	English
ISBN-10	1649272340
ISBN-13	978-1649272348
Item Weight	3 pounds

USING THIS MANUAL

This manual is organized into various sections, each dedicated to a specific system or component of the Suzuki Samurai. To effectively use this manual, locate the relevant section for the task you wish to perform. Each section contains detailed procedures, diagrams, and specifications.

Illustrations and figures are provided to clarify steps and component locations. Pay close attention to any warnings or notes accompanying the instructions to ensure safety and proper execution of repairs.

PERIODIC MAINTENANCE SERVICE

Regular periodic maintenance is crucial for the optimal performance and longevity of your Suzuki Samurai. This section details the recommended service intervals and procedures for routine checks and replacements.

Key areas covered include fluid checks, filter replacements, lubrication points, and general inspections to prevent potential issues before they escalate.

TROUBLESHOOTING

This section provides guidance on diagnosing common problems that may arise with your Suzuki Samurai. It includes symptoms, possible causes, and recommended diagnostic steps to help identify the root of an issue.

Refer to the specific system sections for detailed repair procedures once the problem has been identified.

ENGINE

The engine section covers all aspects of the Suzuki Samurai's engine, including removal, installation, overhaul, and specific component service. Detailed instructions are provided for various engine-related tasks.

18) Using special tool (C), remove oil filter.

NOTE:

Be careful not to spill oil when removing filter.




Fig. 3-4- 17 (C) Oil filter wrench (099 15-47310)

19) Draw water hoses off water pump inlet pipe.




Fig. 3-4- 18

20) Disconnect PCV (Positive crankcase ventilation valve) hose from cylinder head cover.

21) Take down intake manifold with carburetor.




Fig. 3-4-19

3-12

22) Remove water inlet pipe.




Fig. 3-4-20

23) Take off cylinder head cover.




Fig. 3-4-2 1

24) Loosen 8 valve adjusting screws fully. Leave screws in place.





Fig. 3-4-22

Figure 2: Illustrations detailing engine maintenance procedures, such as oil filter removal (Fig. 3-4-17), water inlet pipe removal (Fig. 3-4-20), cylinder head cover removal (Fig. 3-4-21), and valve adjusting screw procedures (Fig. 3-4-22).



CAR HEATER

Service procedures for the car heater system, covering components such as the heater core, blower motor, and control mechanisms.

IGNITION SYSTEM

This section provides details on the ignition system, including spark plugs, ignition coil, distributor, and wiring. Troubleshooting and replacement guidelines are included.

CRANKING SYSTEM

Information on the starter motor, solenoid, and related components of the cranking system, with procedures for testing and repair.

CHARGING SYSTEM

Covers the alternator, voltage regulator, and battery, detailing inspection, testing, and repair procedures for the charging system.

CLUTCH

This section provides instructions for the inspection, adjustment, removal, and installation of the clutch assembly and its hydraulic components.

GEAR SHIFTING CONTROL

Details on the gear shifting mechanism, including linkages, cables, and adjustments for smooth and precise gear changes.

TRANSMISSION

Comprehensive guide to the transmission system, covering disassembly, inspection, repair, and reassembly procedures for both manual and automatic transmissions.




Figure 4: An internal page from the manual illustrating the inspection of transmission components such as gear teeth (Fig. 14-27), gear shift seals (Fig. 14-28), and the transfer rear case assembly (Fig. 14-32, 14-35).

TRANSFER GEAR BOX

Instructions for servicing the transfer gear box, including removal, disassembly, inspection, and reassembly procedures.

PROPELLER SHAFTS

This section covers the inspection, removal, installation, and balancing of the propeller shafts.

DIFFERENTIAL

Procedures for the inspection, adjustment, and overhaul of the front and rear differential assemblies.

SUSPENSION

Details on the front and rear suspension systems, including springs, shock absorbers, control arms, and alignment procedures.

STEERING SYSTEM

Covers the steering gear, power steering pump (if applicable), steering linkage, and alignment procedures.

BRAKES

This section provides comprehensive instructions for the brake system, including disc brakes, drum brakes,

master cylinder, and brake lines. Procedures for inspection, pad/shoe replacement, and bleeding are included.

Front Wheel Hub & Bearing

1. Loosen the five nuts securing the wheel.
Raise the front end by jacking.
Rest the machine steady on safety stands.
2. Remove the five nuts and take off the wheel.




Fig. 17-1-8

4. Remove brake disc.

NOTE:

If brake disc can not be removed by hand, use 8 mm bolts as shown below.




Fig. 17-1-11 ① 8mm Bolt

3. Remove the caliper with carrier by loosening carrier bolts.

NOTE:

Hang removed caliper with a wire hook or the like so as to prevent brake hose from bending and twisting excessively or being pulled.
Don't operate brake pedal with caliper removed.




Fig. 17-1-9




Fig. 17-1-10

17-6

[For car equipped with free wheeling hub]

5. Remove free wheeling hub cover and circlip.




Fig. 17-1-12-1 ① Circlip remover (09900-06107)

6. Remove free wheeling hub body.




Fig. 17-1-12-2

Figure 5: Illustrations detailing the removal of the front wheel hub and bearing (Fig. 17-1-8, 17-1-9, 17-1-10) and brake disc (Fig. 17-1-11), including notes on special tools like the circlip remover (Fig. 17-1-12-1).

BODY SERVICE

This section covers various body components, including doors, windows, exterior trim, and interior panels. Procedures for removal, installation, and adjustment are detailed.

When it is hard to raise and lower the door glass, the glass may be slanting towards the door sash. If this is the case, loosen the screws fastening the door regulator roller holder, move the holder up and down so that the glass and sash are brought in parallel.




Fig. 20-1-17

[Water proof film]

A proof film that is broken a little may be mended with vinyl tape but should be replaced with polyethylene film as a rule. Apply bonding agent all around the circumference and stick on from the underside.




Fig. 20-1-18

[Regulator handle]

Install the handle at the angle as specified in below figure with the door window glass closed (raised all the way up).

20-6




Fig. 20-1-19

Front Door Lock

Reverse the removal sequence to install the door lock. However, be careful of the following points.

[Door outside open rod]

When installing open rod ① on outside handle ②, adjust clearance "A" to 0 – 2 mm (0 – 0.079 in) by turning adjusting joint ③.

NOTE:

Don't push down push plate ⑥ when installing the open rod.

After installing the open rod, give the outside handle a trial and check if its play felt then is appropriate.




Fig. 20-1-20

Figure 6: Illustrations showing procedures for the front door lock (Fig. 20-1-19, 20-1-20) and window regulator assembly (Fig. 20-1-17, 20-1-18), including notes on waterproofing film and adjustment of the door open rod.

BODY ELECTRICAL EQUIPMENT

Information on the electrical systems within the body, including wiring diagrams, component locations, and troubleshooting for lights, gauges, and accessories.

SERVICE DATA

This section compiles essential service data, including torque specifications, fluid capacities, and standard measurements for various components, crucial for accurate repairs.

