

[Manuals.plus](#) /

› [Air Vent](#) /

› Air Vent Inc. 24" Whole House Fan Model 54301 Instruction Manual

## Air Vent 54301

# Air Vent Inc. 24" Whole House Fan Model 54301 Instruction Manual

## INTRODUCTION

---

Thank you for choosing the Air Vent Inc. 24-inch Whole House Fan, Model 54301. This direct drive whole house fan is designed to efficiently pull air from your living space and exhaust it through the attic, providing effective ventilation for homes up to 1500 square feet. Featuring an automatic shutter and a 2-speed pull chain control, this fan operates at 110V and delivers 4500 CFM. This manual provides essential information for the safe and proper installation, operation, and maintenance of your fan.

## IMPORTANT SAFETY INFORMATION

---

Please read and understand all instructions before installation and operation. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

- Always disconnect power at the circuit breaker before installing, servicing, or cleaning the fan.
- Installation should be performed by a qualified electrician or HVAC professional in accordance with all local and national electrical codes.
- Ensure adequate attic ventilation. The fan requires 864 square inches of open exhaust vents in the attic space for proper operation and to prevent backdrafting.
- Do not operate the fan with damaged wiring or if the fan is visibly damaged.
- Keep hands, clothing, and other objects away from moving parts during operation.
- This fan is for indoor use only, specifically for attic and whole house ventilation.
- Do not use this fan with any solid-state speed control device unless specifically designed for this type of fan.

## SETUP AND INSTALLATION


---

Proper installation is crucial for the performance and safety of your whole house fan. The fan is designed for easier installation, often without the need to cut ceiling joists.

## Installation Requirements:

- **Rough Opening:** A rough opening of 27-3/4 inches by 29 inches is required in the ceiling for the fan and automatic shutter assembly.
- **Attic Ventilation:** Ensure your attic has at least 864 square inches of open exhaust vents. Insufficient attic ventilation can reduce fan efficiency and potentially cause damage.
- **Electrical Connection:** The fan operates on 110V. Wiring should be done by a qualified professional.

## Components Overview:




**Figure 1:** Exploded view of the Air Vent 24-inch Whole House Fan, illustrating the main fan unit, motor, and the separate automatic louvered shutter. This image helps identify the components before assembly.

The fan assembly typically consists of the fan motor and blades mounted within a frame, and a separate automatic louvered shutter. The shutter is white and designed to open when the fan is operating and close when it is off, preventing heat loss or gain.

**General Installation Steps (Consult a professional):**

1. **Prepare the Opening:** Create the 27-3/4" x 29" rough opening in the ceiling where the fan will be installed.
2. **Position the Fan:** Place the fan unit in the attic directly over the prepared opening. Secure it to the ceiling joists or a sturdy frame. The design often allows for installation without cutting joists.
3. **Install the Shutter:** From below, install the automatic louvered shutter into the ceiling opening, ensuring it is flush with the ceiling surface.
4. **Electrical Wiring:** Connect the fan to a 110V power supply. The fan includes a 2-speed pull chain control. Ensure all wiring is secure and compliant with electrical codes.
5. **Seal Gaps:** Seal any gaps around the fan and shutter assembly to prevent air leakage and maximize efficiency.



**Figure 2:** The Air Vent 24-inch Whole House Fan with its automatic louvered shutter. This image shows the complete unit as it would appear before being installed into the ceiling.

## OPERATING INSTRUCTIONS

---

The Air Vent 24-inch Whole House Fan is operated using a simple pull chain control, offering two speed settings.

## How Whole House Fans Work:

A whole house fan draws cooler outside air into your home through open windows and doors, pushing hot, stale indoor air up into the attic and out through attic vents. This creates a comfortable breeze and rapidly cools your home.

### Operating the Fan:

1. **Open Windows:** Before turning on the fan, open several windows throughout your home. The more windows you open, the less concentrated the airflow will be through each, leading to a gentler breeze and more widespread cooling. Opening fewer windows will create a stronger breeze in specific areas.
2. **Turn On:** Locate the pull chain extending from the fan's automatic shutter. Pull the chain once to turn the fan on to the first speed setting (typically low).
3. **Adjust Speed:** Pull the chain again to switch to the second speed setting (high). Pulling it a third time will turn the fan off.
4. **Automatic Shutter:** The white louvered shutter will automatically open when the fan is operating and close when the fan is turned off.
5. **Optimal Use:** Use the fan during cooler parts of the day, such as evenings and mornings, to draw in cool air and flush out accumulated heat.

## MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your Air Vent Whole House Fan.

- **Power Disconnection:** Always disconnect power to the fan at the circuit breaker before performing any maintenance.
- **Cleaning:** Periodically inspect and clean the fan blades and motor housing to remove dust and debris. Use a soft cloth or brush. Do not use harsh chemicals or abrasive cleaners.
- **Shutter Inspection:** Check the automatic louvered shutter for smooth operation. Ensure no debris is obstructing the louvers from opening and closing fully. Clean the louvers as needed.
- **Motor Lubrication:** The fan motor is typically permanently lubricated and does not require additional oiling. Refer to the motor's specific instructions if available.
- **Wiring Check:** Annually inspect electrical connections for any signs of wear, fraying, or loose connections.

## TROUBLESHOOTING

If your Air Vent Whole House Fan is not operating as expected, refer to the following common issues and solutions:

| Problem                      | Possible Cause                                                                                                          | Solution                                                                                                                                             |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| Fan does not turn on         | No power to the fan; Circuit breaker tripped; Faulty pull chain switch; Motor issue.                                    | Check power supply and circuit breaker. Ensure pull chain is fully engaged. If problem persists, consult a qualified electrician.                    |
| Fan runs but airflow is weak | Insufficient attic ventilation; Not enough windows open; Obstruction in fan or attic vents; Fan operating on low speed. | Ensure adequate attic exhaust vents (864 sq. in. recommended). Open more windows. Check for obstructions. Adjust to high speed using the pull chain. |

| Problem                                     | Possible Cause                                                                | Solution                                                                                                                                                             |
|---------------------------------------------|-------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Excessive noise or vibration                | Loose mounting; Debris on fan blades; Unbalanced blades; Motor bearing issue. | Ensure fan is securely mounted. Disconnect power and clean blades. Check for bent or damaged blades. If noise persists, professional service may be required.        |
| Automatic shutter does not open/close fully | Obstruction in louvers; Damaged shutter mechanism.                            | Inspect louvers for debris and clear any obstructions. Ensure the fan is properly installed and aligned. If damaged, contact customer support for replacement parts. |

## SPECIFICATIONS

---

Detailed technical specifications for the Air Vent Inc. 24" Whole House Fan Model 54301.

**Brand:** Air Vent

**Model Number:** 54301

**Product Dimensions (D x W x H):** 24" x 24" x 8"

**Electric Fan Design:** Exhaust Fan

**Power Source:** Electric (110 Volts)

**Wattage:** 60 watts

**Air Flow Capacity:** 4500 Cubic Feet Per Minute (CFM)

**Number of Speeds:** 2

**Controller Type:** Pull Chain Control

**Noise Level:** 47 Decibels

**Room Type:** Attic

**Mounting Type:** Ceiling Mount

**Item Weight:** 15.3 Kilograms

**Finish Type:** Painted

**Blade Material:** Plastic

**Rough Opening Required:** 27-3/4" x 29"

**Minimum Attic Exhaust Vent Area:** 864 square inches

## WARRANTY AND SUPPORT

---

Your Air Vent Inc. 24" Whole House Fan Model 54301 comes with a limited warranty to ensure your satisfaction and product reliability.

- **Parts Warranty:** 10-year limited parts warranty.
- **Labor Warranty:** 5-year limited labor warranty.

For warranty claims, technical assistance, or to inquire about replacement parts, please contact Air Vent Inc. customer support. Keep your proof of purchase for warranty validation.

