

Manuals.plus /

- › Standard Motor Products /
- › Standard Motor Products Fuel Pressure Regulator - PR200 User Manual

Standard Motor Products PR200

Standard Motor Products Fuel Pressure Regulator - PR200 User Manual

Model: PR200 | Brand: Standard Motor Products

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Standard Motor Products Fuel Pressure Regulator, model PR200. Please read this manual thoroughly before installation and keep it for future reference. This fuel pressure regulator is designed to maintain optimal fuel pressure within the vehicle's fuel system, ensuring efficient engine performance.

2. SAFETY INFORMATION

WARNING: Always disconnect the vehicle's battery before performing any work on the fuel system. Fuel systems are under pressure and contain flammable liquids. Exercise extreme caution to prevent fuel leaks, spills, and potential fire hazards. Wear appropriate personal protective equipment, including safety glasses and gloves.

Proposition 65 Warning: This product may expose you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

- Ensure the engine is cool before beginning work.
- Relieve fuel system pressure before disconnecting any fuel lines.
- Work in a well-ventilated area.
- Keep fire extinguishers readily available.
- If unsure about any step, consult a qualified automotive technician.

3. PRODUCT OVERVIEW

The Standard Motor Products Fuel Pressure Regulator PR200 is a critical component designed to regulate the fuel pressure delivered to the engine's fuel injectors. Consistent fuel pressure is vital for proper fuel atomization and engine combustion.

3.1. What's in the Box

- Fuel Pressure Regulator (PR200)

3.2. Product Diagram



Figure 1: Standard Motor Products Fuel Pressure Regulator PR200. This image shows the complete fuel pressure regulator unit, including its main body, mounting bracket, and fuel line connections.

4. SETUP AND INSTALLATION

Installation of the fuel pressure regulator requires mechanical aptitude and adherence to safety protocols. Refer to your vehicle's specific service manual for detailed instructions and torque specifications.

4.1. Pre-Installation Steps

1. Park the vehicle on a level surface and engage the parking brake.
2. Disconnect the negative terminal of the vehicle's battery.
3. Locate the fuel pressure regulator on your vehicle. Its location varies by make and model, but it is typically found on the fuel rail or near the fuel tank.
4. Relieve fuel system pressure. Consult your vehicle's service manual for the correct procedure, which often involves removing the fuel pump fuse or relay and cranking the engine.

5. Place absorbent rags or containers under the fuel lines to catch any residual fuel.

4.2. Removal of Old Regulator

1. Carefully disconnect the vacuum line (if present) from the old regulator.
2. Disconnect the fuel lines connected to the regulator. Be prepared for a small amount of fuel to escape.
3. Unbolt or unclip the old regulator from its mounting point.
4. Inspect the mounting surface and fuel line connections for any damage or debris.

4.3. Installation of New Regulator

1. Ensure all O-rings and seals are properly seated on the new PR200 regulator.
2. Mount the new regulator to its designated location, ensuring it is securely fastened.
3. Reconnect the fuel lines, ensuring they are fully seated and secured. Use new clips or fasteners if required.
4. Reconnect the vacuum line (if present).
5. Reconnect the negative terminal of the vehicle's battery.

4.4. Post-Installation Check

1. Turn the ignition key to the "ON" position (without starting the engine) for a few seconds to allow the fuel pump to prime the system. Repeat this step a few times.
2. Inspect all connections for any signs of fuel leaks.
3. Start the engine and allow it to idle. Re-check for leaks.
4. Monitor engine performance and check for any diagnostic trouble codes (DTCs).

5. OPERATING PRINCIPLES

The Standard Motor Products Fuel Pressure Regulator PR200 operates by maintaining a consistent fuel pressure differential across the fuel injectors. This ensures that the correct amount of fuel is delivered to the engine under various operating conditions. It typically uses a diaphragm and spring mechanism to regulate pressure, often referencing manifold vacuum to adjust fuel pressure relative to engine load.

6. MAINTENANCE

The Fuel Pressure Regulator PR200 is generally a maintenance-free component. However, regular vehicle maintenance and inspections can help identify potential issues early.

- Periodically inspect fuel lines and connections around the regulator for signs of leaks, cracks, or damage.
- Ensure the vacuum line (if applicable) is securely connected and free from cracks or blockages.
- If you notice symptoms of a failing fuel pressure regulator (e.g., hard starting, poor fuel economy, black smoke from exhaust, fuel smell), have your vehicle inspected by a qualified technician.

7. TROUBLESHOOTING

If you experience issues after installing or while using the fuel pressure regulator, consider the following common problems and solutions:

Symptom	Possible Cause	Solution
---------	----------------	----------

Symptom	Possible Cause	Solution
Fuel Leak at Regulator Connections	Improperly seated fuel lines or damaged O-rings/seals.	Ensure fuel lines are fully seated and secured. Replace O-rings/seals if damaged.
Engine Hard Starting / No Start	Incorrect fuel pressure (too low or too high).	Verify fuel pressure with a gauge. Check for proper installation and ensure no vacuum leaks (if applicable).
Poor Fuel Economy / Black Smoke	Fuel pressure too high, leading to rich fuel mixture.	Check fuel pressure. Inspect vacuum line for blockages or disconnections.
Engine Misfires / Rough Idle	Inconsistent fuel pressure.	Verify fuel pressure stability. Check for other fuel system component issues.

If troubleshooting steps do not resolve the issue, it is recommended to consult a certified automotive technician for diagnosis and repair.

8. SPECIFICATIONS

Attribute	Value
Model Number	PR200
Brand	Standard Motor Products
Product Type	Auto Part (Fuel Pressure Regulator)
Item Weight	0.01 ounces
Product Dimensions	2.8 x 2.8 x 7.1 inches
Country of Origin	Mexico
Exterior Finish	Machined

9. WARRANTY INFORMATION

Specific warranty terms and conditions for the Standard Motor Products Fuel Pressure Regulator PR200 are provided by the manufacturer. Please refer to the warranty documentation included with your purchase or visit the official Standard Motor Products website for detailed information regarding warranty coverage, duration, and claims procedures.

10. CUSTOMER SUPPORT

For technical assistance, questions regarding installation, or warranty claims, please contact Standard Motor Products directly. Their official website typically provides contact information, including phone numbers and email addresses for customer support.

Note: Always provide your product model number (PR200) and purchase details when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B000C83PAW>

More documents and user manuals: <https://manuals.plus/>