

- Manuals.plus /
- › [Standard Motor Products](#) /
  - › Standard Motor Products KS62 Knock Sensor User Manual

## Standard Motor Products KS62

# Standard Motor Products KS62 Knock Sensor User Manual

Model: KS62 | Brand: Standard Motor Products

### INTRODUCTION

This user manual provides essential information regarding the Standard Motor Products KS62 Knock Sensor. It covers the product's purpose, installation guidelines, maintenance recommendations, and troubleshooting tips. The KS62 Knock Sensor is designed to detect engine knocking or pinging, which can indicate improper combustion. Upon detection, the sensor sends a signal to the engine control unit (ECU), allowing the ECU to adjust ignition timing and prevent potential engine damage.

Proper installation and understanding of this component are crucial for optimal vehicle performance and longevity. For complex automotive repairs, professional assistance is always recommended.

### PRODUCT OVERVIEW




**Figure 1:** Side view of the Standard Motor Products KS62 Knock Sensor, showing the threaded end for mounting and the sensor body.



**Figure 2:** Angled view of the KS62 Knock Sensor, highlighting the hexagonal base for wrenching and the white connector pin.



**Figure 3:** Top-down view of the KS62 Knock Sensor, showing the central connector pin and the surrounding metal housing.

## INSTALLATION (SETUP)

---

Installation of a knock sensor typically involves working with engine components. It is highly recommended that this procedure be performed by a qualified automotive technician. Incorrect installation can lead to engine damage or improper sensor function.

### General Installation Steps:

1. **Safety First:** Ensure the vehicle is turned off, the engine is cool, and the negative terminal of the battery is disconnected to prevent electrical hazards.
2. **Locate the Old Sensor:** Refer to your vehicle's service manual for the exact location of the knock sensor. It is typically mounted on the engine block or intake manifold.
3. **Disconnect Wiring:** Carefully disconnect the electrical connector from the old knock sensor.
4. **Remove Old Sensor:** Use an appropriately sized wrench or socket to unscrew and remove the old sensor. Be mindful of any coolant or oil that might leak if the sensor is submerged.
5. **Prepare New Sensor:** Ensure the mounting surface is clean. Apply thread sealant if recommended by the vehicle manufacturer.
6. **Install New Sensor:** Carefully thread the new Standard Motor Products KS62 Knock Sensor into its mounting location. Tighten to the vehicle manufacturer's specified torque settings. Overtightening can damage the sensor or engine block.
7. **Reconnect Wiring:** Reconnect the electrical connector to the new sensor, ensuring it clicks securely into place.
8. **Reconnect Battery:** Reconnect the negative terminal of the battery.
9. **Test:** Start the vehicle and check for any warning lights or unusual engine behavior. It may be necessary to clear any stored diagnostic trouble codes (DTCs) using an OBD-II scanner.

## OPERATING PRINCIPLES

---

The Standard Motor Products KS62 Knock Sensor operates by detecting vibrations within the engine block that are characteristic of engine knocking or pre-ignition. These vibrations are caused by uncontrolled combustion events. The sensor converts these mechanical vibrations into an electrical signal, which is then sent to the vehicle's Engine Control Unit (ECU).

Upon receiving a signal indicating knock, the ECU will typically retard the ignition timing for that cylinder or bank of cylinders. This adjustment helps to prevent further knocking, protecting the engine from potential damage and optimizing combustion efficiency. The sensor is a passive component and does not require user interaction during vehicle operation.

## MAINTENANCE

---

Knock sensors are generally robust components and do not require routine maintenance. However, periodic inspection during other engine service can help identify potential issues before they lead to failure.

### Maintenance Considerations:

- **Visual Inspection:** During routine engine checks, visually inspect the sensor and its wiring for any signs of physical damage, corrosion, or loose connections.
- **Wiring Integrity:** Ensure the wiring harness connected to the sensor is not frayed, pinched, or exposed to excessive heat.
- **Cleanliness:** Keep the area around the sensor free from excessive dirt, oil, or debris, which could potentially interfere with its operation or cause premature wear to the wiring.
- **Replacement:** While there is no fixed replacement interval, a knock sensor should be replaced if it fails or if diagnostic trouble codes indicate a malfunction.

## TROUBLESHOOTING

---

A faulty knock sensor can lead to various engine performance issues. If you suspect a problem with your knock sensor, consider the following common symptoms and diagnostic steps:

### Common Symptoms of a Faulty Knock Sensor:

- **Check Engine Light (CEL):** This is the most common indicator. The ECU will typically log a Diagnostic Trouble Code (DTC) related to the knock sensor circuit (e.g., P0325, P0330).
- **Reduced Engine Performance:** The ECU may default to a "safe mode" or a more conservative ignition timing map to prevent knocking, leading to reduced horsepower, poor acceleration, and decreased fuel economy.
- **Audible Knocking/Ping:** If the sensor is completely non-functional, the ECU may not detect actual engine knock, potentially leading to audible knocking sounds, especially under acceleration. This can cause severe engine damage over time.
- **Rough Idling or Stalling:** In some cases, an erratic knock sensor signal can cause the engine to run roughly or even stall.

### Diagnostic Steps:

- **Scan for DTCs:** Use an OBD-II scanner to retrieve any stored trouble codes. This is the first and most important step.
- **Inspect Wiring:** Check the sensor's wiring harness and connector for damage, corrosion, or loose connections.
- **Professional Diagnosis:** Due to the critical role of the knock sensor in engine management, it is highly recommended to have a qualified technician diagnose and replace the sensor if a malfunction is confirmed. They can perform specific tests to verify sensor functionality.

SPECIFICATIONS

| Attribute                   | Value                   |
|-----------------------------|-------------------------|
| Brand                       | Standard Motor Products |
| Model                       | KS62                    |
| Item Dimensions (L x W x H) | 2 x 1.4 x 3.4 inches    |
| Item Weight                 | 3.52 ounces             |
| Style                       | Box                     |
| Mounting Type               | Flange Mount            |
| Output Type                 | Digital                 |
| Specific Uses For Product   | Automotive              |
| UPC                         | 091769328818            |
| Manufacturer Part Number    | KS62                    |
| ASIN                        | B000C83R96              |
| Date First Available        | November 11, 2005       |

IMPORTANT SAFETY INFORMATION & DISCLAIMER

**Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, visit [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov). Always follow vehicle manufacturer's guidelines and safety precautions when working on automotive systems. Disconnect the battery before performing any electrical work. Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves. This manual is for informational purposes only and does not replace professional automotive repair advice or service.

© 2024 Standard Motor Products. All rights reserved.  
For technical support, please refer to the official Standard Motor Products website or contact a certified automotive technician.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B000C83R96>

More documents and user manuals: <https://manuals.plus/>