# Manuals+

Q & A | Deep Search | Upload

### manuals.plus /

- ASUS /
- > ASUS A8N32-SLI Deluxe AI Gaming Edition ATX Motherboard User Manual

### **ASUS A8N32-SLI-Deluxe**

# ASUS A8N32-SLI Deluxe AI Gaming Edition ATX Motherboard User Manual

Model: A8N32-SLI-Deluxe

# 1. Introduction

This manual provides comprehensive instructions for the installation, configuration, and operation of the ASUS A8N32-SLI Deluxe AI Gaming Edition ATX Motherboard. Designed for Socket 939 AMD processors, this motherboard offers advanced features for high-performance computing and gaming. Please read this manual thoroughly before proceeding with installation to ensure proper setup and optimal performance.



Image 1.1: The ASUS A8N32-SLI Deluxe Motherboard, showcasing its layout with CPU socket, memory slots, and expansion slots.

# 2. KEY FEATURES

The ASUS A8N32-SLI Deluxe motherboard incorporates several advanced technologies and features to enhance system performance, stability, and user experience.

- AMD Socket 939 Support: Compatible with AMD Athlon 64 FX, Athlon 64 X2, Athlon 64, and Sempron processors, including dual-core and 64-bit CPUs.
- **True Dual X16 SLI:** Supports two PCI Express x16 slots operating at full speed for enhanced graphics performance.

- **8-Phase Power Design:** Provides stable and efficient power delivery to the CPU, reducing heat generation and extending component lifespan.
- Fanless Design (Heat Pipe & Stack Cool 2): Utilizes passive cooling solutions for chipsets and critical components, ensuring quiet operation and improved heat dissipation without active fans.
- Precision Tweaker: Offers fine-grained control over vDIMM (8-step voltage control), vCore (0.0125V increments), and Stepless Frequency Selection (SFS) for FSB, Memory, and PCI Express frequencies, enabling advanced system tuning.
- Al NOS (Non-delay Overclocking System): Automatically boosts CPU performance based on system load for demanding applications.
- **PEG Link Mode:** Allows users to enhance graphics card performance by adjusting GPU and VGA memory throughput via the BIOS.
- Al Clock Skew: Optimizes memory overclocking capability by automatically skewing memory clock signal timing.
- C.P.R. (CPU Parameter Recall): Recovers previous CPU settings after an overclocking failure without clearing CMOS.
- AMD Cool 'n' Quiet! Technology: Dynamically adjusts CPU voltage and frequency for reduced heat and noise.
- ASUS Q-Fan 2: Intelligently adjusts CPU and chassis fan speeds based on system loading.
- **Dual Gigabit LAN:** Integrated network interfaces for high-speed network connectivity and gateway functionality.
- NV Firewall: Hardware-accelerated firewall for enhanced network security.
- PCI Express Architecture: Supports the latest I/O interconnect technology for high-bandwidth expansion.
- Serial ATA 3Gb/s & SATA on the Go: High-speed storage interface with external SATA port for easy data backup.
- **Dual RAID:** Supports RAID 0, 1, 0+1, 5, and JBOD configurations for data protection and performance.
- IEEE 1394a Interface: High-speed digital interface for audio/video appliances.
- S/PDIF-out: Coaxial S/PDIF-out port for digital audio connectivity to external home theater systems.
- Max. 10 USB 2.0 Ports: Provides extensive connectivity for peripherals with transfer speeds up to 480Mb/s.
- Multi-language BIOS: Offers BIOS setup in multiple languages.
- ASUS CrashFree BIOS2: Features BIOS auto-recovery function using a support CD.
- ASUS EZ Flash: Allows BIOS updates without entering the operating system.
- ASUS MyLogo2: Customizes the boot logo with a personal image.

# 3. SETUP AND INSTALLATION

Follow these steps carefully to install your ASUS A8N32-SLI Deluxe motherboard and its components.

### 3.1 Pre-Installation Checklist

- Ensure you have a compatible AMD Socket 939 CPU.
- Gather necessary tools: Phillips screwdriver, anti-static wrist strap.
- Prepare your computer case with adequate ventilation.
- Unpack the motherboard and verify all accessories are present (SLI connector, cables, modules, manual, etc.).

### 3.2 Motherboard Installation

1. Install the I/O Shield into the rear opening of your computer case.

- 2. Carefully align the motherboard with the standoffs in your case.
- 3. Secure the motherboard with screws, ensuring it is firmly seated.

### 3.3 CPU Installation

- 1. Open the CPU socket lever.
- 2. Align the CPU with the socket, ensuring the golden triangle on the CPU matches the triangle on the socket.
- 3. Gently place the CPU into the socket without forcing it.
- 4. Close the CPU socket lever to secure the CPU.
- 5. Apply thermal paste (if not pre-applied to cooler) and install the CPU cooler according to its manufacturer's instructions.

# 3.4 Memory Installation

- 1. Open the clips at both ends of the DIMM slot.
- 2. Align the notch on the DDR memory module with the key in the DIMM slot.
- 3. Insert the module firmly into the slot until the clips snap into place.
- 4. For dual-channel operation, install modules in matching colored slots (e.g., both blue or both black).

# 3.5 Expansion Card Installation

- 1. Remove the metal bracket cover from the desired expansion slot on your case.
- 2. Align the expansion card with the slot and press down firmly until it is fully seated.
- 3. Secure the card with a screw to the case.
- 4. For SLI configuration, install two compatible PCI Express x16 graphics cards and connect them with the provided SLI bridge connector.

# 3.6 Connecting Peripherals and Power

- Connect the 24-pin ATX power connector and the 4-pin ATX 12V power connector from your power supply to the motherboard.
- Connect SATA and IDE cables from your storage devices to the corresponding ports on the motherboard.
- Connect front panel headers (power switch, reset switch, HDD LED, power LED, USB, audio) to the designated pins on the motherboard. Refer to the motherboard layout diagram in the full manual for exact pin locations.
- Connect any additional USB, FireWire (IEEE 1394a), or other modules to the appropriate headers.

# 4. OPERATING INSTRUCTIONS

### 4.1 First Boot and BIOS Setup

- 1. After connecting all components and power, turn on your computer.
- 2. Press the **DEL** key during the Power-On Self-Test (POST) to enter the BIOS Setup Utility.
- 3. In the BIOS, you can configure various system settings, including boot order, date/time, CPU/memory frequencies, and voltage settings (using Precision Tweaker).
- 4. Save changes and exit the BIOS to continue booting into your operating system installation media.

### 4.2 Driver Installation

After installing your operating system, install the necessary drivers for the motherboard components. These are typically found on the included support CD or can be downloaded from the ASUS support website.

- · Install chipset drivers.
- Install graphics card drivers (if applicable).
- · Install audio drivers.
- · Install network (LAN) drivers.
- Install any other utility drivers (e.g., USB, SATA RAID).

# 5. MAINTENANCE

Regular maintenance helps ensure the longevity and stable operation of your motherboard.

- Dust Removal: Periodically clean dust from inside your computer case, especially from heatsinks and fanless cooling components, using compressed air. Ensure the system is powered off and unplugged before cleaning.
- **BIOS Updates:** Check the ASUS support website for the latest BIOS versions. BIOS updates can improve compatibility, stability, and performance. Use the ASUS EZ Flash utility for safe updates.
- **Driver Updates:** Keep your drivers updated to ensure optimal performance and compatibility with new software and hardware.
- Cable Management: Ensure internal cables are neatly routed to promote good airflow and prevent interference.

# 6. TROUBLESHOOTING

This section addresses common issues you might encounter with your motherboard.

# 6.1 System Does Not Power On

- Verify that the 24-pin ATX and 4-pin ATX 12V power connectors are securely plugged into the motherboard.
- Ensure the power supply is switched on and connected to a working power outlet.
- Check that the front panel power switch cable is correctly connected to the motherboard header.

# 6.2 No Display on Monitor

- Confirm that your graphics card is properly seated in its PCI Express slot and any necessary auxiliary power connectors are attached.
- Ensure the monitor is connected to the graphics card and powered on.
- If using multiple graphics cards in SLI, ensure the SLI bridge is correctly installed.
- Try booting with only one stick of RAM, or reseat all RAM modules.

# 6.3 System Instability or Crashes

- Check CPU and system temperatures. While the motherboard features fanless cooling, ensure adequate case airflow.
- If overclocking, revert to default BIOS settings using C.P.R. or by clearing CMOS.
- Ensure all drivers are correctly installed and up to date.
- Test memory modules individually to rule out faulty RAM.

# 6.4 Network Connectivity Issues

 Verify that the Ethernet cable is securely connected to the LAN port and your network device (router/modem).

- Ensure LAN drivers are installed correctly.
- Check network adapter settings in your operating system.
- If one LAN port is unresponsive, try the other integrated Gigabit LAN port.

# 7. SPECIFICATIONS

| Feature                       | Detail   |
|-------------------------------|--|
| Brand                         | ASUS   |
| Model Number                  | A8N32-SLI-Deluxe   |
| CPU Socket                    | Socket 939   |
| Compatible Processors         | AMD Athlon 64 FX, Athlon 64 X2, Athlon 64, Sempron             |
| Chipset Type                  | NVIDIA nForce4 SLI X16   |
| RAM Memory Technology         | DDR  |
| Memory Clock Speed            | Up to 800 MHz (via SFS)  |
| Memory Storage Capacity (Max) | 4 GB   |
| PCI Express Slots             | 2 x PCI Express x16 (True Dual X16 SLI)                        |
| Storage Interfaces            | 4 x SATA 3Gb/s (nForce4), 2 x SATA (Silicon Image), 2 x ATA133 |
| RAID Support                  | RAID 0, 1, 0+1, 5, JBOD  |
| LAN                           | Dual Gigabit LAN   |
| USB Ports                     | Max. 10 x USB 2.0  |
| FireWire (IEEE 1394a)         | Yes  |
| Audio                         | 8-channel Audio, S/PDIF-out                                    |
| Form Factor                   | ATX  |
| Dimensions                    | 13.3 x 10.9 x 3.3 inches (Package)                             |
| Item Weight                   | 5.05 pounds  |

# 8. WARRANTY AND SUPPORT

ASUS products are designed for reliability and performance. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official ASUS website.

For technical support, driver downloads, BIOS updates, and further product information, please visit the official ASUS support website:

# https://www.asus.com/support/

When contacting support, please have your motherboard model number (A8N32-SLI-Deluxe) and serial number ready.

# Related Documents - A8N32-SLI-Deluxe

P9X79 DELUXE

# Motherboard

### ASUS P9X79 DELUXE Motherboard User Manual

Detailed user manual for the ASUS P9X79 DELUXE motherboard, covering installation, hardware information, BIOS setup, software support, and multi-GPU technology. Includes safety notices and specifications.



# SECO-LARM ENFORCER SLI 820R/-4 Tech Manual: Installation and Operation

Comprehensive technical manual for the SECO-LARM ENFORCER SLI 820R/-4 Factory Keyless Entry Alarm Adapter Security System. Covers installation, wiring diagrams, specifications, programming, and troubleshooting.





# MSI K9N4 SLI Series MS-7325 Mainboard User Manual

Comprehensive user manual for the MSI K9N4 SLI Series (MS-7325 V1.X) ATX mainboard. Covers hardware setup, BIOS configuration, driver installation, nVidia RAID, and technical support for AMD Athlon processors.



# ENFORCER SLI 820R/-4 Owner's Manual: Vehicle Security System

Comprehensive owner's manual for the SECO-LARM ENFORCER SLI 820R/-4 vehicle security system, detailing operation, features, and accessories.





X99-DELUXE Series

# ASUS X99-DELUXE II Series Motherboard User Manual: Installation, BIOS Setup, and Specifications

Comprehensive user manual for the ASUS X99-DELUXE II Series Motherboard, covering detailed installation procedures, BIOS setup configurations, RAID support, and full product specifications. Essential guide for PC builders and enthusiasts.



# ASUS ROG STRIX B550-E GAMING Motherboard User Manual

This comprehensive user manual for the ASUS ROG STRIX B550-E GAMING motherboard provides detailed installation instructions, technical specifications, BIOS setup guidance, and troubleshooting information for PC builders and enthusiasts. It covers CPU, memory, storage, and expansion card installation, along with features like PCIe 4.0, Wi-Fi 6, and advanced audio.


### Documents - ASUS - A8N32-SLI-Deluxe



### [pdf] Decleration of Conformity

Microsoft Word NII 2005 11 08 ASUS A8N32 SLI Deluxe fayer 2 doc jl14 MotherboardThe provides dual PCI Express x16 slots running at full speed for unrestricted performance from today s graphics cards compare Nii SLi 2images10 newegg UploadFilesForNewegg itemintelligence Motherboards Nii ||| ASUS A8N32-SLI Deluxe Motherboard Features True Dual X16 SLI: The ultimate enthusiast platform The A8N32-SLI Deluxe provides dual PCI Express x16 slots running at full speed for unrestricted performance from today s PCI Express graphics cards compare that with the narrow bandwidth x8 platform . Gam...

lang:en score:45 filesize: 585.58 K page\_count: 9 document date: 2005-11-12




### [pdf] User Manual Documentation Warranty

untitled A8N32 SLI ASUS PROVIDES THIS MANUAL AS IS WITHOUT WARRANTY OF ANY KIND EITHER EXPRESS OR IMPLIED INCLUDING BUT NOT No part of this manual including the products and software described in it may be reproduced transmitted transcribed stored a retrieval system or translated into any language form by means except documentation kept purchaser for backup purposes without express written permission ASUSTeK COMPUTER INC E2280 Dlx dlcdnet asus pub mb socket939 Deluxe dlsvr04 80

Motherboard A8N32-SLI Deluxe/WiFi Deluxe E2280 Second Edition V2 October 2005 Copyright 2005 ASUSTeK COMPUTER INC. All Rights Reserved. No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or trans...

lang:en score:42 filesize: 5.76 M page\_count: 164 document date: 2005-10-14



# [pdf]

MB List xls Eileen Ho dlcdnimgs asus A8N32 SLI DELUXE v M2 CROSSHAIR Not recommend A8N5X M2N32 WS PRO A8N E WIFI AP ASUSTeK Support 20060914 compatible mb list websites JP products 1V55ds7dKKu7lunp event 80 thermal 2006

Recommendation for ASUS MB Models Installation For 478/775 installation Retention Only For 754/939/940 installation Retention Only 478/775 939 A8N32-SLI DELUXE A8N5X A8N-E A8N-SLI A8N-SLI DELUXE A8N-SLI PREMIUM A8N-SLI SE A8N-VM A8N-VM CSM A8R32-MVP DELUXE A8R-MVP A8S-X A8V A8V DEL...

lang:da score:39 filesize: 99.26 K page\_count: 1 document date: 2006-09-08



### [pdf] User Manual


Asus M2N Sli Deluxe Manual Pdf SLI vga manual gv 3d1 7950 rh c 1 gigabyte Files ||| GV-3D1-7950-RH GeForceTM 7950 GX2 Rev. 102 \* WEEE logo \* WEEE 2006 GIGABYTE TECHNOLOGY CO., LTD GIGA-BYTE TECHNOLOGY CO., LTD. GBT GBT Macrovision corporation product notice: This product incorporates copyright protection technology that is protected by U.S. patents and other intellectua... lang:af score:37 filesize: 5.89 M page count: 34 document date: 2006-07-04



# [pdf]

Corsair ASUS Joint Launch XMS3500LL PRO corsairmicro 80 corsair pr corsairmemory

For Immediate Release Corsair Strikes Partnership with ASUSTek and Announces
the World's Highest Performing Asus-Ready 1GB Module for the AMD Platform -Jointly developed with ASUS for its new A8N32-SLI Deluxe/WiFi motherboards, the
new 1GB XMS3500LL PRO memory is tailor-made at super low latenci...
lang:en score:34 filesize: 242.81 K page\_count: 2 document date: 0000-00-00




### [pdf] User Manual Guide

Book 1 indb Driver Dll service manual user guide Chapter 2 a8n32 sli dx j2280 gmfok get file M 43694 dlcdnet asus 80 pub ASUS mb socket939 A8N32 SLI Deluxe dlsvr04

...

lang:en score:33 filesize: 3.01 M page\_count: 164 document date: 2006-01-10



### [pdf]

May Wille Aqua Computer Systeme GbR Stephan AC Spannungsregler 20071101deu aquacomputer de handbuecher html file tl files manuals |||

aquacomputer Stand 11/2007 Betriebs- und Montageanleitung Spannungsreglerkhler Betriebs- und Montageanleitung fr Spannungsreglerkhler Sehr geehrter Kunde, wir danken Ihnen fr den Kauf eines Wasserkhlers aus unserem Hause. Sie erhalten mit diesem Khler einen extrem hochqualitativen und auf Ingste ...

lang:de score:32 filesize: 23.25 K page\_count: 2 document date: 2007-11-01



# [pdf] User Manual Specifications Warranty Label

Amd Radeon 7950 Manual Pdf Installation and mounting manual for EK Backplate vga gv 3d1 rh e 1 gigabyte Files |||

GV-3D1-7950-RH GeForceTM 7950 GX2 Graphics Accelerator User's Manual Rev. 102 12MD-3D17950R-102R \* The WEEE marking on the product indicates this product must not be disposed of with user's other household waste and must be handed over to a designated collection point for the recycling of waste elec... lang:en score:28 filesize: 5.36 M page count: 34 document date: 2006-07-04



# [pdf]

g2280 a8n32 sli deluxe dlcdnet asus 80 pub ASUS mb socket939 A8N32 SLI Deluxe

...

lang:en score:28 filesize: 5.59 M page\_count: 164 document date: 2005-12-01



### [pdf]

PR Committed Infineon RAM Allocation Continued AMD Support corsair pr corsairmicro corsairmemory
For Immediate Release Corsair Announces Committed RAM Allocation from Infineon,
and Continued Support for AMD Enthusiasts -- Using exclusively Infineon s Rev. C
DDR SDRAM, Corsair s XMS-3500LL PRO 2GB kit ramps up to deliver ultra-low
latency performance -- Fremont, CA March 1, 2006 Corsair Me...
lang:en score:22 filesize: 248.11 K page\_count: 2 document date: 0000-00-00



### [pdf]

A8N32 SLI Deluxe Front Matter Huang Steven c2280 dlcdnet asus 80 pub ASUS mb socket939 dlsvr04

lang:en score:22 filesize: 6.76 M page count: 164 document date: 2006-01-18



# [pdf] User Manual Decleration of Conformity

Simer 2205C User manual 1153662 archive org manualzz id

EXHIBIT NUMBER BATES NUMBER eX-2176 eX-2177 eX-2178 eX-2179 eX-2180 ASUS 214181eX-218le ASUS 214209 eX-2182 eX-2183 eX-2184 eX-2185 eX-2186 eX-2187 eX-2188 eX-2189 DESCRIPTIVE TITLE STATEMENT OF PuRPOSE Declaration of J. Stading on Behalf of Best Buy Stores, L.P., August 14,2008 Notice of Depos...

lang:en score:21 filesize: 8.09 M page count: 100 document date: 0000-00-00



### [pdf] Catalog

Matbe Antec antec 80 press

Identification - Inscription Rechercher Processeurs Cartes mres Cartes graphiques Mmoire vive Disques durs Moniteurs LCD Lecteurs MP3 Ventilateurs CPU Watercooling Voir tous les prix Antec : les nouveauts en 2006 Par Stphane le 12/01/2006 Rcemment, nous avons eu accs au catalogue 2006 d Antec et ... lang:fr score:19 filesize: 339.09 K page\_count: 3 document date: 2006-01-13



# EKWB EK-KIT S120 Waterblock Compatibility List - EKWB Cooling Configurator

Find detailed motherboard compatibility for the EKWB EK-KIT S120 water cooling block. This guide from EKWB helps PC builders ensure their hardware is compatible for optimal custom liquid cooling setups.

lang:i-klingon score:12 filesize: 165.71 K page\_count: 50 document date: 2016-05-17

