

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Chicago Pneumatic](#) /

› [Chicago Pneumatic CP 886H Air Ratchet Wrench User Manual](#)

Chicago Pneumatic CP 886H

Chicago Pneumatic CP 886H Air Ratchet Wrench User Manual

Model: CP 886H

1. INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Chicago Pneumatic CP 886H Air Ratchet Wrench. Please read this manual thoroughly before using the tool to ensure proper handling and to prevent injury or damage.

The CP 886H is designed for fastening and unfastening applications in confined spaces, offering flexibility and ease of use for tasks such as replacing spark plugs, working on air conditioning systems, water pumps, and exhaust systems.



Figure 1: Chicago Pneumatic CP 886H Air Ratchet Wrench. This image displays the full view of the CP 886H air ratchet wrench, highlighting its compact design and 1/4" air connector.

2. SAFETY INFORMATION

Always observe general safety precautions when operating pneumatic tools. Failure to follow these instructions may result in serious injury.

General Safety Guidelines:

- Wear appropriate personal protective equipment (PPE), including eye protection, hearing protection, and gloves.
- Ensure the work area is clean, well-lit, and free from obstructions.
- Keep bystanders, especially children, away from the operating area.
- Do not operate the tool if you are tired or under the influence of drugs, alcohol, or medication.
- Disconnect the air supply before changing accessories, performing maintenance, or when the tool is not in use.

- Never point the tool at yourself or others.
- Use only genuine Chicago Pneumatic replacement parts and accessories.

Pneumatic Tool Specific Safety:

- Ensure the air supply pressure does not exceed the maximum recommended pressure for the tool.
- Check air hoses for wear, damage, or leaks before each use.
- Avoid kinking or crushing air hoses.
- Do not carry the tool by the air hose.
- Always use a clean, dry, regulated air supply.

3. COMPONENTS

The Chicago Pneumatic CP 886H Air Ratchet Wrench consists of several key components:

- **Ratchet Head:** Compact design for access in tight spaces.
- **Square Drive:** For attaching sockets.
- **Direction Control:** Easy-grip mechanism for changing rotation direction (right/left).
- **Trigger:** Activates the air motor.
- **Air Inlet:** 1/4" NPT connection for air supply.
- **Exhaust Port:** Directs expelled air away from the workpiece.

4. SETUP

Proper setup is crucial for optimal performance and safety.

1. Air Supply Connection:

- Ensure your air compressor is capable of providing the required air pressure and volume (refer to specifications).
- Install a quick-connect fitting (not included) onto the 1/4" NPT air inlet of the ratchet wrench.
- Connect the air hose from your regulated air supply to the tool. Ensure all connections are secure to prevent air leaks.

2. Lubrication:

- Before first use, and daily thereafter, apply 3-5 drops of pneumatic tool oil into the air inlet.
- Run the tool for a few seconds to distribute the oil.
- Using an in-line oiler is recommended for continuous lubrication.

3. Socket Attachment:

- Select the appropriate socket for your application.
- Firmly push the socket onto the square drive of the ratchet head until it locks into place.

5. OPERATION

Follow these steps for safe and effective operation of your air ratchet wrench.

1. **Prepare the Workpiece:** Ensure the fastener is accessible and clear of debris.
2. **Select Direction:** Use the easy-grip direction control to set the ratchet to either tighten (clockwise) or loosen (counter-clockwise) the fastener.
3. **Position the Tool:** Place the socket firmly onto the fastener.
4. **Engage the Trigger:** Press the trigger to activate the air motor. Apply steady pressure to the tool.
5. **Monitor Torque:** The CP 886H is designed for quick fastening and unfastening. For critical torque applications, always use a calibrated torque wrench for final tightening.

6. **Release Trigger:** Release the trigger once the fastener is tightened or loosened.



Figure 2: Chicago Pneumatic CP 886H Air Ratchet Wrench in use. This image shows the air ratchet wrench being used to tighten a bolt, demonstrating its application in automotive maintenance.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your tool.

- **Daily Lubrication:** As mentioned in the setup section, apply pneumatic tool oil daily into the air inlet.
- **Cleaning:** Keep the tool clean and free from dirt and debris. Wipe down the exterior with a clean cloth. Do not use harsh solvents.
- **Air Filter:** Regularly check and clean or replace the air filter in your air compressor and/or air line to ensure a clean air supply to the tool.
- **Hose Inspection:** Inspect air hoses and fittings for wear, cuts, or leaks. Replace damaged components immediately.
- **Storage:** Store the tool in a dry, clean environment when not in use. Disconnect it from the air supply.

7. TROUBLESHOOTING

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Tool not operating or low power	Insufficient air pressure	Check compressor pressure and regulator setting.
	Lack of lubrication	Add pneumatic tool oil to the air inlet.
	Blocked air inlet/filter	Clean or replace air filter.
	Damaged air hose/fittings	Inspect and replace damaged components.
Air leaks	Loose fittings	Tighten all connections.
	Damaged O-rings or seals	Inspect and replace O-rings/seals.
	Damaged air hose	Replace damaged air hose.
Excessive noise or vibration	Lack of lubrication	Add pneumatic tool oil.
	Worn internal components	Contact an authorized service center for inspection and repair.

8. SPECIFICATIONS

Technical data for the Chicago Pneumatic CP 886H Air Ratchet Wrench:

- **Model:** CP 886H
- **Brand:** Chicago Pneumatic
- **Material:** Aluminum
- **Air Inlet:** 1/4" NPT
- **Weight:** Approximately 2.62 lbs (1.19 kg)
- **Length:** Approximately 26 cm (10.2 inches)
- **Recommended Air Pressure:** Consult product packaging or official Chicago Pneumatic documentation for specific pressure ranges.
- **Maximum Torque:** Consult product packaging or official Chicago Pneumatic documentation for specific torque ratings.

9. WARRANTY AND SUPPORT

For warranty information, technical support, or to locate an authorized service center, please refer to the official Chicago Pneumatic website or contact your local distributor. Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 Chicago Pneumatic. All rights reserved.