

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Mustek](#) /
- › [Mustek ScanExpress A3 2400 Pro Scanner User Manual](#)

Mustek ScanExpress A3 2400 Pro

Mustek ScanExpress A3 2400 Pro Scanner User Manual

Model: ScanExpress A3 2400 Pro

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Mustek ScanExpress A3 2400 Pro Scanner. This high-resolution flatbed scanner is designed for scanning large documents up to A3 size, offering a 2400 dpi optical resolution and 48-bit color depth for detailed image capture. Please read this manual thoroughly before using the scanner to ensure proper functionality and to maximize its performance.



Image 1.1: The Mustek ScanExpress A3 2400 Pro Scanner. This image displays the scanner unit with its lid closed, showcasing its large flatbed design suitable for A3 documents.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your scanner package. If any items are missing or damaged, contact your retailer or Mustek customer support.

- Mustek ScanExpress A3 2400 Pro Scanner Unit
- USB 2.0 Cable
- Power Adapter
- Software Installation CD (Drivers and Application Software)
- Quick Start Guide
- User Manual (this document, typically provided digitally or in print)

3. SETUP

3.1 System Requirements

Ensure your computer meets the following minimum requirements for optimal scanner performance:

- Operating System: Windows 7 or later (32-bit or 64-bit)
- Processor: Intel Pentium III or higher (or equivalent)
- RAM: 512 MB or more
- Hard Disk Space: 500 MB available
- Interface: USB 2.0 port
- CD-ROM/DVD-ROM drive (for software installation from disc)

3.2 Hardware Connection

1. **Unpack the Scanner:** Carefully remove the scanner from its packaging. Remove all protective materials, including any tape or foam inserts.
2. **Connect the Power Adapter:** Plug the power adapter into the scanner's power input port, then plug the other end into a standard electrical outlet.
3. **Connect the USB Cable:** Connect one end of the supplied USB 2.0 cable to the USB port on the scanner and the other end to an available USB 2.0 port on your computer.
4. **Power On:** Press the power button on the scanner. The power indicator light should illuminate.

3.3 Software Installation

The scanner requires driver and application software to function correctly.

1. **Insert the Installation CD:** Place the provided software installation CD into your computer's CD-ROM/DVD-ROM drive. The setup program should start automatically. If it does not, navigate to the CD drive in "My Computer" or "This PC" and double-click on "setup.exe" or "install.exe".
2. **Follow On-Screen Instructions:** Follow the prompts to install the scanner drivers and the bundled application software. It is recommended to install all components for full functionality.
3. **Restart Computer:** After the installation is complete, restart your computer if prompted. This ensures all drivers are properly loaded.
4. **Verify Installation:** After restarting, you can verify the scanner installation by checking Device Manager (Windows) or by attempting to launch the scanning software.

Note: If you do not have a CD-ROM drive or encounter issues with the provided disc, please visit the official Mustek support website to download the latest drivers and software for your model.

4. OPERATING INSTRUCTIONS

4.1 Basic Scanning Procedure

1. **Prepare Document:** Open the scanner lid and place the document face down on the scanner glass. Align the document with the corner guide. Ensure the document is flat and free of wrinkles.
2. **Close Lid:** Gently close the scanner lid.
3. **Launch Scanning Software:** Open the Mustek scanning application installed on your computer. Alternatively, some applications (like Photoshop) can access the scanner directly via its TWAIN driver.
4. **Select Scan Settings:**
 - **Scan Mode:** Choose between Color, Grayscale, or Black & White. For detailed images, select Color (48-bit recommended).
 - **Resolution (DPI):** Set the desired scanning resolution. The scanner supports up to 2400 dpi optical resolution. Higher DPI settings result in larger file sizes and longer scan times.
 - **Scan Area:** Define the area of the document you wish to scan. For A3 documents, ensure the entire area is selected.
 - **Destination:** Choose where the scanned image will be saved (e.g., a specific folder, directly to an application).
5. **Preview (Optional):** Click the "Preview" button to see a quick scan of your document. This allows you to adjust settings before the final scan.
6. **Initiate Scan:** Click the "Scan" button to begin the scanning process. The scanner light will move across the document.
7. **Save File:** Once the scan is complete, save the image in your preferred format (e.g., JPEG, TIFF, PDF).

4.2 Advanced Software Functions

The included software provides various functions beyond basic scanning:

- **Copy:** Scan a document and send it directly to a connected printer.
- **Fax:** Scan a document and send it via a connected fax modem.
- **Email:** Scan a document and attach it to a new email message.
- **PDF:** Scan documents directly into PDF format, including multi-page PDFs.
- **OCR (Optical Character Recognition):** Convert scanned text documents into editable text files.

Refer to the software's built-in help documentation for detailed instructions on using these advanced features.

5. MAINTENANCE

5.1 Cleaning the Scanner Glass

Dust, smudges, or fingerprints on the scanner glass can affect scan quality.

1. **Power Off:** Turn off the scanner and unplug the power adapter.
2. **Clean Glass:** Use a soft, lint-free cloth lightly dampened with a non-abrasive glass cleaner. Wipe the scanner glass gently. Do not spray cleaner directly onto the glass.
3. **Dry:** Use a dry, soft cloth to wipe the glass until it is completely dry.
4. **Clean Lid:** Wipe the underside of the scanner lid (the white backing) with a soft, dry cloth to remove any dust.

Caution: Do not use abrasive cleaners, alcohol, or solvents, as these can damage the scanner glass or plastic components.

5.2 General Care

- Keep the scanner in a clean, dust-free environment.

- Avoid exposing the scanner to direct sunlight or extreme temperatures.
- Do not place heavy objects on the scanner lid.
- Handle the scanner with care to prevent physical damage.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your scanner.

Problem	Possible Cause	Solution
Scanner does not power on.	Power cable not connected; power outlet faulty; scanner power button not pressed.	Ensure power cable is securely connected to both scanner and outlet. Try a different outlet. Press the power button firmly.
Computer does not detect the scanner.	USB cable loose or faulty; drivers not installed correctly; scanner not powered on.	Check USB cable connection. Try a different USB port. Reinstall scanner drivers. Ensure scanner is powered on.
Poor scan quality (streaks, blurry images, incorrect colors).	Scanner glass dirty; document not flat; incorrect scan settings (resolution, color mode).	Clean the scanner glass (refer to Section 5.1). Ensure document is flat and properly aligned. Adjust scan resolution and color settings in the software.
Scanning process hangs or does not complete.	Software conflict; insufficient system resources; TWAIN driver issue.	Close other applications. Ensure your computer meets system requirements. Try updating or reinstalling the scanner software and TWAIN driver. If using a third-party application (e.g., Photoshop), ensure it's compatible with the TWAIN driver and running in the correct mode (e.g., 32-bit if required by older drivers).
Scanner makes unusual noises.	Internal obstruction; mechanical issue.	Power off and unplug the scanner. Carefully check for any foreign objects on the scanner glass or under the lid. If the noise persists, contact customer support.

If the problem persists after trying these solutions, please contact Mustek customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Model Number	ScanExpress A3 USB 2400 Pro
Scanner Type	Flatbed Document Scanner
Optical Resolution	2400 dpi x 2400 dpi

Feature	Detail
Color Depth	48-bit Color
Maximum Scan Size	A3 (approx. 11.7 x 16.5 inches or 297 x 420 mm)
Connectivity	USB 2.0
Optical Sensor Technology	CIS (Contact Image Sensor)
Product Dimensions	24.5 x 20.3 x 6.5 inches (62.2 x 51.6 x 16.5 cm)
Item Weight	12.9 pounds (5.85 kg)
Minimum System Requirements	Windows 7
Manufacturer	Mustek
Date First Available	September 14, 2004

8. WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the warranty card included in your product packaging or visit the official Mustek website.

For technical support, driver downloads, or frequently asked questions, please visit the Mustek support portal or contact their customer service department. Contact details can typically be found on the Mustek website or in the Quick Start Guide.

