

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Epson](#) /

› [Epson TM-T88V Thermal Receipt Printer Instruction Manual](#)

## Epson C31CA85084

# Epson TM-T88V Thermal Receipt Printer Instruction Manual

Model: TM-T88V (C31CA85084)

## INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Epson TM-T88V Thermal Receipt Printer. The TM-T88V is designed for reliable and high-speed receipt printing in various point-of-sale environments. Please read this manual thoroughly before using the printer to ensure proper functionality and longevity.

## PACKAGE CONTENTS

Verify that all items are present in the package:

- Epson TM-T88V Thermal Receipt Printer
- Power Supply Unit (PS180)
- AC Power Cable
- Roll of Thermal Paper (for initial setup)
- User Manual (this document)



Image: Epson TM-T88V printer, power supply, and connecting cables. The printer is dark grey with the Epson logo on the front. The power supply is a black rectangular unit, and two black cables are coiled in the foreground.

Note: Communication cables (USB or Serial) are typically sold separately and are not included in the standard package.

## SETUP

### 1. Connecting the Power Supply

1. Connect the power supply unit (PS180) to the printer's power input port.
2. Plug the AC power cable into the power supply unit.
3. Insert the AC power cable into a standard electrical outlet.
4. Press the power button on the front of the printer to turn it on. The power indicator light should illuminate.

### 2. Loading Thermal Paper

1. Open the printer's roll paper cover by pushing the lever on the right side and lifting the cover.
2. Insert a new roll of thermal paper into the paper compartment. Ensure the paper feeds from the bottom of the roll and the leading edge is straight.
3. Pull approximately 2-3 inches of paper past the cutter.
4. Close the roll paper cover firmly until it clicks into place. The printer will automatically feed the paper to the correct starting position.

### 3. Connecting to a Computer/POS System

The TM-T88V supports USB and Serial (RS232) connectivity.

- **USB Connection:** Connect a USB cable (Type A to Type B, not included) from your computer or POS system to the USB port on the printer.
- **Serial Connection:** Connect a Serial (RS232 25-pin, not included) cable from your computer or POS system to the Serial port on the printer.

After connecting, install the appropriate printer drivers for your operating system (Windows, Mac OS X, Linux). Drivers are typically available on the Epson support website.

## OPERATING INSTRUCTIONS

### Printing a Receipt

Once the printer is set up and drivers are installed, it will function as a standard printer for your POS software or application. Send print commands from your software, and the printer will automatically print and cut the receipt.

- Ensure the printer is powered on and connected to your system.
- Verify that thermal paper is loaded correctly and not jammed.
- Initiate the print command from your point-of-sale application.
- The printer will print the receipt and automatically cut the paper.

### LED Indicators

- **Power LED:** Indicates the printer is powered on.
- **Error LED:** Illuminates or flashes to indicate an error condition (e.g., paper out, cover open, cutter error). Refer to the Troubleshooting section.
- **Paper LED:** Illuminates when paper is low or out.

## MAINTENANCE

### Replacing Thermal Paper

When the Paper LED illuminates or the printer stops printing, the thermal paper roll needs replacement. Follow the steps outlined in the "Loading Thermal Paper" section under Setup.

### Cleaning the Printer

Regular cleaning helps maintain print quality and extends printer life.

- Turn off the printer and disconnect the power cable before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or isopropyl alcohol to clean the exterior of the printer.
- To clean the thermal print head, open the paper cover and gently wipe the print head surface with a cotton swab lightly moistened with isopropyl alcohol. Allow it to dry completely before closing the cover and powering on.
- Clean the paper path and cutter area to remove any paper dust or debris.

Avoid using abrasive cleaners or solvents that could damage the printer's surfaces.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Printer does not power on.	Power cable disconnected; power outlet issue.	Check all power connections. Try a different power outlet.
No printing / Error LED on.	Paper out or jammed; cover open; communication error.	Load new paper. Close cover securely. Check communication cable connection. Reinstall drivers if necessary.

Problem	Possible Cause	Solution
Poor print quality (faded, blank lines).	Thermal print head dirty; low-quality thermal paper; print head wear.	Clean the thermal print head. Use recommended thermal paper. If issue persists, contact support.
Paper does not cut automatically.	Cutter jammed; cutter mechanism dirty.	Turn off printer, open cover, carefully remove any paper debris from the cutter area. Clean the cutter.

## SPECIFICATIONS




Image: Side view of the Epson TM-T88V printer with dimensions. The height is indicated as 6.3 inches (16 cm).

Feature	Detail
Model Name	TM-T88V
Item Model Number	C31CA85084
Printing Technology	Thermal Line Printing
Print Resolution	203 dpi (dots per inch)
Print Speed (Monochrome)	Up to 30 lines per second (approximate, high-speed)
Printer Output	Monochrome
Connectivity	USB 2.0, Serial (RS232 25-pin)
Special Feature	Auto Cutter

Feature	Detail
Supported Media	Thermal Receipt Paper Rolls (typically 3.125 inches / 80mm width)
Product Dimensions (D x W x H)	7" x 5" x 5" (approximate)
Item Weight	2.43 pounds
Memory Storage	64 MB
Compatible Operating Systems	Microsoft Windows (7, Vista, XP, 2000), Mac OS X (v10.4, v10.5, v10.6), Linux
Color	Epson Dark Grey

## WARRANTY INFORMATION

The Epson TM-T88V Thermal Receipt Printer comes with a Limited Warranty. For specific terms, conditions, and duration of your warranty, please refer to the warranty card included with your product or visit the official Epson website. Keep your purchase receipt as proof of purchase for warranty claims.

## SUPPORT

For technical assistance, driver downloads, or further information regarding your Epson TM-T88V printer, please visit the official Epson support website or contact Epson customer service.

Official Epson Website: [www.epson.com/support](http://www.epson.com/support)