

[Manuals.plus](#) /

› [Fasco](#) /

› Fasco D367 3.3" Double Shaft Motor - 115V 1550 RPM User Manual

Fasco D367

Fasco D367 3.3" Double Shaft Motor - 115V 1550 RPM User Manual

1. INTRODUCTION

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your Fasco D367 3.3" Double Shaft Motor. Please read these instructions carefully before attempting to install or operate the motor. Retain this manual for future reference.



Image 1.1: Fasco D367 3.3" Double Shaft Motor. This image displays the motor with its double shaft design, typically used in various fan and blower applications.

2. SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of injury or damage:

- **Electrical Hazard:** Ensure power is disconnected before installation, maintenance, or servicing. Only qualified personnel should perform electrical wiring.
- **Moving Parts:** Keep hands, clothing, and tools clear of rotating parts during operation.
- **Proper Grounding:** The motor must be properly grounded to prevent electrical shock.
- **Ventilation:** Ensure adequate ventilation around the motor to prevent overheating.
- **Environmental Conditions:** Do not expose the motor to excessive moisture, dust, or corrosive environments unless specifically rated for such conditions.
- **Secure Mounting:** Always ensure the motor is securely mounted to prevent vibration and potential detachment.

3. SETUP AND INSTALLATION

Follow these steps for proper installation:

- 1. Unpacking:** Carefully remove the motor from its packaging. Inspect for any shipping damage.
- 2. Mounting:** Mount the motor securely using appropriate fasteners. Ensure the mounting surface is stable and capable of supporting the motor's weight and operational forces. The double shaft design allows for flexibility in application.
- 3. Electrical Connection:**
 - Verify that the power supply matches the motor's voltage (115 Volts) and frequency requirements.
 - Connect the motor wiring according to local electrical codes and the wiring diagram provided with the motor (if applicable). Ensure all connections are tight and insulated.
 - Properly ground the motor chassis.
- 4. Shaft Connection:** Attach the driven components (e.g., fan blades, pulleys) to the motor shafts. Ensure they are balanced and properly aligned to prevent excessive vibration and premature bearing wear.
- 5. Pre-Operation Check:** Before applying power, manually rotate the shafts to ensure free movement and no obstructions.

4. OPERATING INSTRUCTIONS

Once installed and all safety checks are complete, the motor is ready for operation.

- **Power On:** Apply power to the motor. It should start smoothly and reach its rated speed of 1550 RPM.
- **Monitoring:** During initial operation, monitor the motor for unusual noises, excessive vibration, or overheating. If any anomalies are detected, immediately disconnect power and investigate the cause.
- **Continuous Operation:** The Fasco D367 motor is designed for continuous duty within its specified ratings.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the motor's lifespan.

- **Cleaning:** Periodically clean the exterior of the motor to remove dust and debris, which can impede cooling. Ensure power is off before cleaning.
- **Inspection:** Regularly inspect the motor for signs of wear, loose connections, or damage to wiring. Check mounting bolts for tightness.
- **Bearings:** This motor typically features permanently lubricated bearings. No routine lubrication is required. If unusual bearing noise is detected, consult a qualified technician.
- **Ventilation:** Ensure that air inlets and outlets are clear and unobstructed.

6. TROUBLESHOOTING

Refer to the following table for common issues and their potential solutions.

Problem	Possible Cause	Solution
Motor does not start	No power supply; Incorrect wiring; Overload protection tripped; Seized bearings	Check power source and circuit breaker; Verify wiring connections; Reset overload; Inspect bearings for free rotation
Motor runs hot	Insufficient ventilation; Overload; High ambient temperature; Incorrect voltage	Clear obstructions; Reduce load; Ensure proper operating environment; Verify correct voltage supply

Problem	Possible Cause	Solution
Excessive noise or vibration	Loose mounting; Unbalanced load; Worn bearings; Misalignment	Tighten mounting bolts; Balance load; Replace bearings (if worn); Realign components
Motor hums but does not turn	Starting capacitor fault (if applicable); Mechanical obstruction; Low voltage	Consult qualified technician; Remove obstruction; Verify voltage supply

If troubleshooting steps do not resolve the issue, contact a qualified service technician.

7. SPECIFICATIONS

Key technical specifications for the Fasco D367 motor:

- **Brand:** Fasco
- **Model Number:** D367
- **Motor Type:** 3.3" Double Shaft Motor
- **Voltage:** 115 Volts
- **Speed:** 1550 RPM
- **Material:** Copper
- **Item Weight:** 5.17 Pounds (approx. 2.34 kg)
- **Package Dimensions:** 18 x 4 x 4 inches (approx. 45.7 x 10.2 x 10.2 cm)
- **UPC:** 707022318501

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact Fasco directly. Specific warranty terms and conditions may vary.

For technical support or service inquiries, please contact your authorized Fasco dealer or visit the official Fasco website for contact details.

© 2026 Fasco. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question