

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Dynex](#) /
- › [Dynex Universal AC Adapter dx-ac500 User Manual](#)

Dynex dx-ac500

Dynex Universal AC Adapter dx-ac500 User Manual

Model: dx-ac500

INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Dynex Universal AC Adapter, model dx-ac500. This adapter is designed to provide power to a variety of electronic devices requiring 12 Volts DC input, utilizing a standard 120 Volts AC wall outlet. Please read this manual thoroughly before operating the device to ensure proper setup and to prevent damage to the adapter or your electronic equipment.

SAFETY INFORMATION

- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Do not expose to rain, moisture, or extreme temperatures.
- **Electrical Hazard:** To reduce the risk of electric shock, do not disassemble the adapter. Refer all servicing to qualified service personnel.
- **Ventilation:** Ensure adequate ventilation around the adapter. Do not cover the adapter or place it in an enclosed space during operation.
- **Voltage Compatibility:** Only connect the adapter to a 120V AC wall outlet. Ensure your device requires 12V DC input before connecting.
- **Cable Care:** Do not place heavy objects on the power cord or allow it to be pinched. Avoid bending or twisting the cord excessively.
- **Children:** Keep the adapter and its components out of reach of children.
- **Unplug When Not In Use:** Disconnect the adapter from the wall outlet when not in use for extended periods.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Dynex Universal AC Adapter (main unit)

- Multiple interchangeable DC output tips



Image: The Dynex Universal AC Adapter main unit with its integrated power cord and several detachable DC output tips of various sizes and configurations.

SETUP

1. **Identify Device Requirements:** Before connecting, determine the correct voltage and polarity required by your electronic device. This information is usually found on the device itself, its original power adapter, or in its user manual. This adapter provides 12V DC output.
2. **Select the Correct Tip:** Choose the interchangeable DC output tip that physically fits your device's power input port. Ensure a snug fit.
3. **Connect Tip to Adapter:** Firmly attach the selected tip to the output cable of the Dynex Universal AC Adapter. Ensure it is fully seated.
4. **Connect Adapter to Device:** Insert the connected tip into your electronic device's power input port.
5. **Plug into Power Outlet:** Plug the Dynex Universal AC Adapter into a standard 120V AC wall outlet.

The adapter features an LED indicator that illuminates when power is supplied, confirming proper connection to the wall outlet.

OPERATING INSTRUCTIONS

Once properly set up, the Dynex Universal AC Adapter operates automatically. When plugged into a live 120V AC outlet and connected to a compatible device, it will supply the necessary 12V DC power. The LED indicator on the adapter will glow to confirm it is receiving power.

To discontinue operation, simply unplug the adapter from the wall outlet first, then disconnect it from your electronic device.

MAINTENANCE

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter, cable, and tips for any signs of damage, such as frayed wires, cracks, or loose connections. If damage is found, discontinue use immediately and replace the

adapter.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Adapter LED is off, device not powering on/charging.	No power from wall outlet. Adapter not fully plugged in. Faulty outlet.	Check if the wall outlet is live by plugging in another device. Ensure the adapter is fully inserted into the outlet. Try a different outlet.
Adapter LED is on, but device not powering on/charging.	Incorrect tip selected. Loose connection between tip and adapter or device. Device requires different voltage/amperage. Device malfunction.	Verify the correct tip is used and securely connected. Ensure the tip is fully inserted into the device. Confirm your device requires 12V DC. Test the device with its original adapter if available.
Adapter feels excessively hot.	Overload. Poor ventilation.	Disconnect immediately. Ensure the device's power requirements do not exceed the adapter's capacity. Provide adequate ventilation around the adapter. If overheating persists, discontinue use.

SPECIFICATIONS

Model	dx-ac500
Brand	Dynex
Input Voltage	120 Volts AC
Output Voltage	12 Volts DC
Item Weight	0.3 Ounces (approximately 8.5 grams)
Color	Black

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official Dynex website. For technical support or inquiries, please contact Dynex customer service through their official channels.

Please retain your proof of purchase for warranty claims.

