

[Manuals.plus](#) /

› [Standard Motor Products](#) /

› Standard Motor Products DS-2302 Switch User Manual

Standard Motor Products DS-2302

Standard Motor Products DS-2302 Switch User Manual

Model: **DS-2302** | Brand: **Standard Motor Products**

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of the Standard Motor Products DS-2302 Intermotor Power Window Switch. This component is designed as a direct replacement part for specific vehicle applications, ensuring reliable control of your vehicle's power windows. Please read this manual thoroughly before attempting any installation or operation.

2. PRODUCT OVERVIEW

The DS-2302 is a power window switch assembly, typically located on the driver's side door, providing control for all power windows in the vehicle. It features individual window controls and may include an "AUTO" function for one-touch operation of the driver's window.



Figure 2.1: Front view of the DS-2302 switch. This image displays the primary control surface of the power window switch, including the master lock/unlock button, individual window control buttons, and the "AUTO" function label for the driver's window.



Figure 2.2: Angled view of the DS-2302 switch. This perspective highlights the ergonomic design and the physical arrangement of the buttons, providing a better understanding of its form factor for installation.

3. SPECIFICATIONS

Feature	Detail
Operation Mode	ON-OFF
Current Rating	20 Amps
Operating Voltage	5 Volts
Contact Type	Normally Open
Connector Type	Crimp
Brand	Standard Motor Products
Terminal	Screw
Item dimensions L x W x H	3 x 7 x 3 inches
Mounting Type	Panel Mount
Connectivity Protocol	X-10
Unit Count	1.0 Count
Number of Items	1
Global Trade Identification Number	00025623525310
Manufacturer	Standard Motor Products
UPC	025623525310
Item Weight	6.1 ounces
Product Dimensions	3 x 7 x 3 inches
Item model number	DS-2302

Feature	Detail
Manufacturer Part Number	DS-2302
ASIN	B005F9MPYA
Date First Available	July 7, 2004

4. SETUP AND INSTALLATION

Installation of the DS-2302 power window switch typically involves replacing the existing switch assembly in the vehicle's door panel. Due to the complexity of automotive electrical systems and interior trim, professional installation is highly recommended. If you choose to perform the installation yourself, proceed with caution and ensure you have the necessary tools and automotive repair knowledge.

4.1. Safety Precautions

- Always disconnect the vehicle's negative battery terminal before beginning any electrical work to prevent accidental short circuits or electrical shock.
- Wear appropriate personal protective equipment, including safety glasses and gloves.
- Ensure the vehicle is parked on a level surface with the parking brake engaged.

4.2. Installation Steps (General Guidance)

1. **Access the Existing Switch:** Carefully remove the interior door panel trim to gain access to the existing power window switch assembly. This often involves removing screws and prying clips. Refer to your vehicle's specific service manual for exact instructions.
2. **Disconnect Wiring:** Once the switch is accessible, carefully disconnect the electrical connector(s) from the old switch. Note the orientation and any locking tabs.
3. **Remove Old Switch:** Unclip or unscrew the old switch from its mounting bracket or door panel housing.
4. **Install New Switch:** Position the new DS-2302 switch into the mounting location and secure it.
5. **Connect Wiring:** Reconnect the vehicle's electrical harness to the new switch. Ensure the connection is secure and fully seated.




Figure 4.1: Electrical connector pins. This image shows the multi-pin connector interface on the back of the switch, which connects to the vehicle's wiring harness. Ensure proper alignment and secure connection during installation.




Figure 4.2: Internal electrical contacts. This detailed view illustrates the copper contacts inside the switch, responsible for completing the electrical circuits to operate the windows. These contacts are crucial for the switch's functionality.

6. **Test Functionality:** Before reassembling the door panel, reconnect the negative battery terminal and test the operation of all power windows from the newly installed switch. Ensure all windows move smoothly up and down and that any "AUTO" functions work correctly.
7. **Reassemble:** Once confirmed operational, reassemble the door panel and any removed trim pieces in reverse order of removal.

5. OPERATING INSTRUCTIONS

The Standard Motor Products DS-2302 switch operates similarly to most factory power window switches. Ensure the vehicle's ignition is in the "ON" or "ACC" position for the power windows to function.

- **Individual Window Control:** To operate a specific window, press down on the corresponding switch button to lower the window, and pull up on the button to raise the window. Release the button to stop the window at the desired position.
- **"AUTO" Function (if applicable):** For the driver's window (and sometimes other windows), a full press down on the switch may activate an "AUTO" function, causing the window to fully lower without holding the button. A full pull up may cause the window to fully raise. A quick tap in either direction will stop the window.
- **Window Lock:** The master switch assembly typically includes a window lock button. When engaged, this button disables the operation of passenger window switches, allowing only the driver to control all windows. Press the button to toggle the lock function.

6. MAINTENANCE

The DS-2302 power window switch is a sealed unit and generally requires no internal maintenance. However, proper care of the surrounding area can prolong its lifespan and ensure reliable operation.

- **Keep Clean:** Regularly wipe the surface of the switch with a soft, damp cloth to remove dust and grime. Avoid using harsh chemicals or abrasive cleaners.
- **Avoid Liquid Spills:** Prevent liquids from spilling onto or into the switch assembly, as this can cause electrical shorts or corrosion.
- **Check Connections:** If the switch is ever removed or reinstalled, ensure all electrical connections are clean, secure, and free from corrosion.

7. TROUBLESHOOTING

If you experience issues with your power window switch, consider the following common troubleshooting steps. Always ensure safety precautions are followed before attempting any diagnosis.

Problem	Possible Cause(s)	Solution
Window does not move when switch is pressed.	• Blown fuse. • Faulty wiring or connection. • Faulty window motor. • Faulty switch. • Window lock engaged (for passenger windows).	• Check and replace relevant fuse in the vehicle's fuse box. • Inspect wiring harness connections at the switch and motor for looseness or corrosion. • Test window motor for power and ground. • Test switch continuity with a multimeter. • Disengage window lock button.

Problem	Possible Cause(s)	Solution
Window moves slowly or intermittently.	- Weak electrical connection. - Friction in window track. - Failing window motor.	- Check and clean electrical connections. - Lubricate window tracks. - Consider replacing the window motor.
"AUTO" function does not work.	- Switch calibration issue. - Faulty switch.	- Refer to vehicle's service manual for window "AUTO" function reset/recalibration procedure. - If recalibration fails, the switch may be faulty.

If these steps do not resolve the issue, it is recommended to consult a qualified automotive technician for further diagnosis and repair.

8. WARRANTY AND SUPPORT

For information regarding the warranty coverage for your Standard Motor Products DS-2302 switch, please refer to the warranty documentation provided with your purchase or visit the official Standard Motor Products website. Warranty terms and conditions are subject to the manufacturer's policy.

For technical support, installation assistance, or to inquire about replacement parts, please contact Standard Motor Products customer service directly. Contact information can typically be found on their official website or product packaging.

Note: This manual provides general guidance. Specific vehicle models may have unique installation or operational requirements. Always consult your vehicle's factory service manual for detailed instructions.

© 2024 Standard Motor Products. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question