

Tupperware Thatsa Bowl Junior 2.75L

Tupperware Thatsa Bowl Junior 2.75L User Manual

Model: Thatsa Bowl Junior 2.75L

INTRODUCTION

Thank you for choosing the Tupperware Thatsa Bowl Junior 2.75L. This manual provides essential information for the proper use, care, and maintenance of your new bowl. Please read it thoroughly before first use and keep it for future reference.

SAFETY INFORMATION

- Do not use the bowl in a microwave oven.
- Keep away from direct heat sources or open flames.
- Ensure the lid is properly sealed to prevent spills, especially when transporting liquids.
- Handle with care when filled with hot contents.

PRODUCT OVERVIEW

The Tupperware Thatsa Bowl Junior 2.75L is a versatile food storage and preparation bowl designed for everyday use. It features a durable plastic construction and an airtight, liquid-tight seal.



Image: The Tupperware Thatsa Bowl Junior 2.75L in pastel pink, shown with its white lid. The bowl has a wide rim and a handle-like extension on one side, designed for easy gripping and mixing. The lid is designed to create an airtight and liquid-tight seal.

Key Features:

- Capacity: 12 Cups (2.75 Liters)
- Air-Tight and Liquid-Tight Seal
- Dishwasher Safe
- Durable Plastic Construction

SETUP

Before first use, wash the bowl and lid thoroughly with warm soapy water. Rinse well and dry completely. No assembly is required.

OPERATING INSTRUCTIONS

Filling the Bowl:

1. Place the bowl on a stable, flat surface.
2. Pour or place desired contents into the bowl. Do not overfill; leave some space at the top for the lid.

Sealing the Lid:

1. Place the lid on top of the bowl, aligning it properly.

2. Press down firmly on the center of the lid.
3. Working your way around the rim, press down with your thumbs to create a tight seal. You may hear a "burp" sound as air is expelled, indicating a good seal.

Opening the Lid:

1. Locate the small tab or lip on the edge of the lid.
2. Lift the tab gently to break the seal.
3. Continue lifting around the rim until the lid can be easily removed.

MAINTENANCE AND CARE

Cleaning:

- The Thatsa Bowl Junior and its lid are dishwasher safe. Place them on the top rack of your dishwasher for best results.
- Alternatively, wash by hand with warm water and mild dish soap. Use a soft sponge or cloth to avoid scratching.
- Rinse thoroughly and allow to air dry completely before storing to prevent odors.

Storage:

- Store the bowl and lid separately or with the lid loosely placed on top to allow air circulation and prevent odors.
- Avoid storing near strong odors or direct sunlight.

TROUBLESHOOTING

Lid is difficult to seal:

- Ensure the rim of the bowl and the lid are clean and dry. Food particles or moisture can interfere with the seal.
- Make sure the lid is correctly aligned before pressing down.
- If the bowl or lid is new, the plastic may be stiff. Repeated use will make it more flexible.

Stains or odors:

- For stubborn stains, create a paste with baking soda and water, apply to the stain, let sit for a few hours, then wash.
- To remove odors, place a crumpled piece of newspaper or a few charcoal briquettes inside the bowl with the lid on for a day or two. Then wash thoroughly.

SPECIFICATIONS

Attribute	Detail
Brand	Tupperware
Model	Thatsa Bowl Junior
Capacity	2.75 Liters (12 Cups)
Material	Plastic
Color	Pastel Pink

Dishwasher Safe	Yes
Microwaveable	No
Special Feature	Airtight, Liquid-tight
Dimensions (Approx.)	9 x 9 x 4.5 inches
Item Weight	8.8 ounces

WARRANTY AND SUPPORT

Tupperware products are known for their durability and quality. For specific warranty information or support inquiries, please refer to the official Tupperware website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, visit the [Tupperware Store on Amazon](#).

© 2023 Tupperware. All rights reserved.