

[Manuals.plus](#) /

› [Sling Media](#) /

› Sling Media Slingbox 500 Instruction Manual

## Sling Media SB500-100

# Sling Media Slingbox 500 Instruction Manual

Model: SB500-100

## 1. INTRODUCTION

The Sling Media Slingbox 500 allows you to watch and control your live home television content on various devices such as tablets, smartphones, PCs, or Macs. This device streams your home TV signal over the internet, providing access to your programming from virtually anywhere with an internet connection. It supports full HD 1080p resolution and features HDMI and Wi-Fi connectivity for simplified setup.

## 2. PACKAGE CONTENTS

Before beginning installation, ensure all components are present:

- Slingbox 500 unit
- Power Adapter
- Remote Control (or IR blaster cables, if applicable)
- Ethernet Cable
- HDMI Cable (often included)



**Figure 2.1:** Front view of the Slingbox 500 unit, showcasing its sleek design.

## 3. SETUP

### 3.1 Physical Connections

Connect the Slingbox 500 to your television source (e.g., cable box, satellite receiver) and your home network. Refer to the port diagram below for proper connections.



**Figure 3.1:** Rear panel of the Slingbox 500, showing various input and output ports including Power, Reset, USB, Network (Ethernet), HDMI In, HDMI Out, and Audio/Video (component/composite) connections.

1. **Power:** Connect the power adapter to the "POWER" port on the Slingbox 500 and then to an electrical outlet.
2. **Video Source:**
  - For HDMI sources: Connect an HDMI cable from your TV source's HDMI OUT to the Slingbox 500's "HDMI IN" port. Then, connect another HDMI cable from the Slingbox 500's "HDMI OUT" to your TV's HDMI IN.
  - For Component/Composite sources: Connect the appropriate video and audio cables from your TV source to the corresponding "AUDIO" and "VIDEO" (component/composite) input ports on the Slingbox 500.
3. **Network:**
  - For wired connection: Connect an Ethernet cable from your router to the "NETWORK" port on the Slingbox 500.
  - For wireless connection: The Slingbox 500 supports Wi-Fi. Configuration will be done during the on-screen setup process.
4. **USB:** The USB port can be used for future accessories or updates.

### 3.2 Initial Configuration

After connecting the hardware, power on the Slingbox 500. Follow the on-screen instructions displayed on your television (connected via HDMI OUT) to complete the setup process. This typically includes:

- Network setup (Wi-Fi password entry or confirming Ethernet connection).
- Identifying your television source (cable box, satellite receiver) and configuring the IR blaster for remote control functionality.
- Creating a Sling account or logging into an existing one.

## 4. OPERATING INSTRUCTIONS

### 4.1 Accessing Your Slingbox

To watch your TV content remotely, you will need the Slingplayer application. This application is available for various platforms:

- **Mobile Devices:** Download the Slingplayer app from your device's app store (e.g., Apple App Store, Google Play Store).

Note that the mobile app may require a separate purchase.

- **Computers:** Access your Slingbox via a web browser by visiting the Sling website and logging into your account.

## 4.2 Watching Live TV and Content

Once connected through the Slingplayer app or website, you will see your live television feed. The interface provides a virtual remote control to change channels, adjust volume, and navigate your TV source's menu, just as if you were at home.

- **Channel Changing:** Use the virtual keypad or channel up/down buttons on the Slingplayer interface.
- **Integrated YouTube:** The Slingbox 500 features an integrated YouTube app and Web Gallery for discovering trending videos. Contextual YouTube recommendations may also be available based on the show you are watching.
- **Gallery View:** Utilize the Gallery View for easy program discovery, allowing you to sort by genre or set up favorites.

## 4.3 Home TV Interface

When connected to a television via the HDMI OUT port, the Slingbox 500 provides a home TV interface, enhancing the local viewing experience with features like live sports integration and the Gallery View.

# 5. MAINTENANCE

## 5.1 Cleaning

To maintain the Slingbox 500, periodically wipe the exterior with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as these can damage the finish or internal components.



**Figure 5.1:** Top view of the Slingbox 500, showing its smooth, black surface.

## 5.2 Software Updates

Ensure your Slingbox 500 firmware and Slingplayer applications are kept up-to-date. Updates often include performance improvements, bug fixes, and new features. The device typically checks for firmware updates automatically when connected to the internet.

## 6. TROUBLESHOOTING

This section addresses common issues you might encounter with your Slingbox 500.

- **No Picture/Sound:**

- Verify all cables (HDMI, audio/video, power) are securely connected.
- Ensure your TV source (cable box, satellite receiver) is powered on and functioning correctly.
- Check the input selection on your television if connected directly to the Slingbox 500's HDMI OUT.

- **Cannot Connect to Slingbox:**

- Confirm the Slingbox 500 is powered on and connected to your home network (check network cable or Wi-Fi status).
- Restart your router and modem.
- Ensure your Slingplayer app or web interface is updated to the latest version.
- Verify your internet connection on the device you are using to access the Slingbox.

- **Poor Video Quality or Frequent Disconnections:**

- Check your internet speed at both the Slingbox location and the viewing location. A stable, high-speed connection is crucial for optimal streaming.
- If using Wi-Fi, try moving the Slingbox closer to your router or using a wired Ethernet connection for better stability.
- Reduce the streaming quality settings within the Slingplayer app if your internet connection is limited.

- **Remote Control Not Working:**

- Ensure the IR blaster cable (if used) is properly positioned near your TV source's IR receiver.
- Re-run the remote control setup in the Slingbox 500's on-screen configuration.

- **Resetting the Device:** If issues persist, a factory reset may be necessary. Locate the "RESET" button on the rear panel (refer to Figure 3.1) and use a paperclip to press and hold it for approximately 10 seconds until the device restarts. Note that this will erase all settings, and you will need to reconfigure the Slingbox.



Figure 6.1: Bottom view of the Slingbox 500, showing ventilation grilles for heat dissipation and product labels.

## 7. SPECIFICATIONS

### Slingbox 500 Technical Specifications

| Feature                 | Detail                                                           |
|-------------------------|------------------------------------------------------------------|
| Model Name              | SB500-100                                                        |
| Brand                   | Sling Media                                                      |
| Resolution              | 1080p (Full HD)                                                  |
| Connectivity Technology | Wi-Fi, Ethernet                                                  |
| Connector Type          | HDMI, Component, Composite                                       |
| Special Features        | Full HD Resolution, Enhanced User Experience, Integrated YouTube |
| Item Weight             | 1.22 pounds                                                      |
| Product Dimensions      | 16.38 x 3.13 x 10 inches                                         |
| Color                   | Black                                                            |
| Batteries               | 2 AAA batteries required (for remote, if applicable)             |

## 8. WARRANTY AND SUPPORT

### 8.1 Legal Disclaimer

Please note that all sales are final. Refer to your purchase documentation for specific warranty terms and conditions provided by the retailer or manufacturer at the time of purchase.

### 8.2 Customer Support

For further assistance, technical support, or detailed warranty information, please visit the official Sling Media support website or contact their customer service department. Contact information is typically provided in the product packaging or on the manufacturer's website.

© 2025 Sling Media. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B009FU8BR0>

More documents and user manuals: <https://manuals.plus/>