

Manuals.plus /

> [Fasco](#) /

> Fasco A320 Blower Instruction Manual

Fasco A320

Fasco A320 Blower Instruction Manual

Model: A320 | Brand: Fasco

1. INTRODUCTION

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your Fasco A320 Specific Purpose Blower. This blower is designed for various applications requiring air movement, featuring a 1/60 HP shaded pole motor, 115 Volts, 3000 RPM, 1 speed, 0.8 Amps, and CCW (Counter-Clockwise) rotation with sleeve bearings. Please read this manual thoroughly before attempting any installation or operation.

2. IMPORTANT SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of injury, electric shock, or damage to the product.

- Electrical Safety:** Ensure the power supply matches the blower's voltage (115 Volts). Disconnect power before installation, maintenance, or servicing. All electrical wiring should be performed by a qualified electrician and comply with local and national electrical codes.
- Mechanical Safety:** Keep hands, loose clothing, and tools away from moving parts during operation. The blower contains rotating components that can cause injury.
- Installation Environment:** Install the blower in a dry, well-ventilated area, free from flammable materials or corrosive atmospheres. Ensure proper mounting to prevent vibration and noise.
- Intended Use:** This blower is designed for specific air movement purposes. Do not use it for applications outside its specified capabilities or in hazardous environments unless explicitly rated for such use.
- Personal Protective Equipment (PPE):** Wear appropriate PPE, such as safety glasses and gloves, during installation and maintenance.

3. PACKAGE CONTENTS

Verify that all items are present upon unpacking:

- Fasco A320 Specific Purpose Blower (1 unit)
- Instruction Manual (this document)

If any components are missing or damaged, contact your supplier immediately.

4. TECHNICAL SPECIFICATIONS



Figure 1: Fasco A320 Specific Purpose Blower. This image displays the Fasco A320 blower unit, featuring a black motor housing connected to a silver-colored centrifugal fan enclosure with an air outlet duct. The fan enclosure has visible internal blades.

Parameter	Value
Model Number	A320
Motor Type	Shaded Pole
Horsepower (HP)	1/60 HP
Voltage	115 Volts
Amperage	0.8 Amps
Speed	3000 RPM
Number of Speeds	1
Rotation	CCW (Counter-Clockwise)
Bearing Type	Sleeve Bearing

Parameter	Value
Dimensions (L x W x H)	16.51 x 13.97 x 17.78 cm
Item Weight	454 g (approximately 1 lb)

5. INSTALLATION

Proper installation is crucial for the blower's performance and longevity. If you are not experienced with electrical or mechanical installations, it is recommended to seek assistance from a qualified professional.

5.1 Pre-Installation Checklist

- Verify that the blower's specifications match your application requirements.
- Ensure the mounting surface is stable and capable of supporting the blower's weight and operational forces.
- Confirm that the electrical supply is disconnected at the source before beginning work.
- Gather all necessary tools and hardware for mounting and wiring.

5.2 Mounting the Blower

1. Position the blower in the desired location, ensuring adequate clearance for airflow and maintenance.
2. Align the mounting holes on the blower housing with the pre-drilled holes on your mounting surface.
3. Secure the blower using appropriate fasteners (bolts, nuts, washers) that are suitable for the weight and vibration of the unit. Ensure all fasteners are tightened securely to prevent movement during operation.
4. Verify that the blower is level and stable.

5.3 Electrical Connection

WARNING: Electrical shock hazard. Ensure power is OFF before wiring.

1. Connect the blower's electrical leads to the 115 Volt power supply according to local electrical codes and the wiring diagram provided with your specific application (if applicable).
2. Ensure all connections are secure and insulated to prevent short circuits.
3. Confirm proper grounding of the blower unit.
4. Once wiring is complete, double-check all connections before restoring power.

6. OPERATION

The Fasco A320 blower is designed for continuous operation within its specified parameters.

1. **Initial Start-up:** After installation and verifying all connections, restore power to the unit. The blower should start smoothly.
2. **Monitoring:** During initial operation, observe the blower for any unusual noises, vibrations, or overheating. If any anomalies are detected, immediately disconnect power and refer to the Troubleshooting section.
3. **Airflow:** Confirm that the blower is producing the expected airflow for your application.
4. **Continuous Operation:** The blower is designed for continuous duty. Ensure it is not obstructed and has adequate ventilation to prevent overheating.

7. MAINTENANCE

Regular maintenance helps ensure optimal performance and extends the lifespan of your Fasco A320 blower. Always disconnect power before performing any maintenance.

7.1 Cleaning

- **Exterior:** Periodically clean the exterior of the blower housing with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Impeller/Inlet:** Inspect the blower's inlet and impeller for any accumulation of dust, debris, or foreign objects. Clean carefully using a brush or vacuum cleaner. Ensure no debris falls into the motor housing.

7.2 Bearings

The Fasco A320 uses sleeve bearings, which are typically pre-lubricated and sealed for life, requiring no additional lubrication under normal operating conditions. If unusual noise or resistance is noted, the motor may require professional inspection or replacement.

7.3 Inspections

- Regularly check all mounting hardware for tightness.
- Inspect electrical connections for signs of wear, corrosion, or loose wiring.
- Listen for any changes in operating noise or unusual vibrations.

8. TROUBLESHOOTING

Before attempting any repairs, ensure the power supply to the blower is disconnected.

Problem	Possible Cause	Solution
Blower does not start	No power supply Loose electrical connections Motor failure	Check power source and circuit breaker Inspect and tighten all wiring connections Contact a qualified technician for motor inspection/replacement
Low airflow	Obstructed inlet/outlet Dirty impeller Incorrect rotation	Clear any obstructions Clean the impeller (refer to Maintenance) Verify wiring for correct CCW rotation
Excessive noise or vibration	Loose mounting hardware Debris in impeller Worn bearings Unbalanced impeller	Tighten all mounting bolts Clean impeller (refer to Maintenance) Professional inspection/replacement of motor Professional inspection/replacement of impeller
Blower overheats	Insufficient ventilation Motor overload Restricted airflow	Ensure adequate air circulation around the motor Verify the blower is not operating beyond its rated capacity Check for and clear any airflow obstructions

9. WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation provided at the time of purchase or contact your Fasco product supplier. If you require technical support or replacement parts, please provide your model number (A320) and any relevant purchase details when contacting customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question