

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Casio](#) /
- > [Casio TQ358-1D Bell Desktop Alarm Clock with Snooze User Manual](#)

## Casio TQ358-1

# Casio TQ358-1D Bell Desktop Alarm Clock with Snooze User Manual

Model: TQ358-1

## INTRODUCTION

Thank you for purchasing the Casio TQ358-1D Bell Desktop Alarm Clock with Snooze. This manual provides detailed instructions for the proper setup, operation, and maintenance of your new alarm clock. Please read this manual thoroughly before use and keep it for future reference.

## IMPORTANT SAFETY PRECAUTIONS

- Do not expose the clock to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping the clock or subjecting it to strong impacts.
- Do not attempt to disassemble or modify the clock. This will void the warranty.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of used batteries according to local regulations.

## PACKAGE CONTENTS

Please check to ensure all items are present in your package:

- Casio TQ358-1D Bell Desktop Alarm Clock
- User Manual (this document)

*Note: Batteries are not included and must be purchased separately.*

## PRODUCT OVERVIEW

Familiarize yourself with the components of your alarm clock:



**Image:** Front view of the Casio TQ358-1D Bell Desktop Alarm Clock. It features a black analog dial with white numbers, two prominent bells on top, and a small light button. The clock has a classic twin-bell design.

1. **Time Set Knob:** Located on the back, used to adjust the current time.
2. **Alarm Set Knob:** Located on the back, used to set the desired alarm time.
3. **Alarm ON/OFF Switch:** Located on the back, slides to activate or deactivate the alarm.
4. **Snooze/Light Button:** Located on top, press for temporary backlight and snooze function.
5. **Battery Compartment:** Located on the back, holds the required batteries.

## SETUP

---

### 1. Battery Installation

1. Open the battery compartment cover located on the back of the clock.
2. Insert one (1) AA battery (not included) according to the polarity indicators (+ and -) inside the compartment.
3. Close the battery compartment cover securely.

### 2. Setting the Current Time

1. Locate the **Time Set Knob** on the back of the clock.
2. Rotate the knob in either direction until the hour and minute hands display the correct current time.
3. Ensure you set the correct AM/PM if your clock has a 12-hour display with an AM/PM indicator (this model typically does not have a separate AM/PM indicator, but the alarm setting will differentiate).

### 3. Setting the Alarm Time

1. Locate the **Alarm Set Knob** on the back of the clock.
2. Rotate the knob until the small alarm hand points to your desired wake-up time.
3. *Important:* For analog clocks, the alarm hand typically makes one full rotation in 12 hours. If you set the alarm for 7:00 AM, ensure the main time is also set to AM when you activate the alarm, or the alarm will sound at 7:00 PM.

## OPERATING INSTRUCTIONS

---

### 1. Activating/Deactivating the Alarm

- To **activate** the alarm, slide the **Alarm ON/OFF Switch** (usually on the back or side) to the "ON" position. A small indicator (often red) may appear.
- To **deactivate** the alarm, slide the **Alarm ON/OFF Switch** to the "OFF" position.

### 2. Snooze Function

- When the alarm sounds, press the large **Snooze/Light Button** on the top of the clock.
- The alarm will temporarily stop and sound again after approximately 5-10 minutes (duration may vary by model).
- To completely stop the alarm, slide the **Alarm ON/OFF Switch** to the "OFF" position.

### 3. Backlight Function

- To illuminate the clock face in low light conditions, press and hold the **Snooze/Light Button** on the top.
- The light will remain on as long as the button is pressed.

## MAINTENANCE

---

### 1. Cleaning the Clock

- Wipe the clock's exterior with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the finish.
- Avoid getting moisture into the clock's internal components.

### 2. Battery Replacement

- When the clock's display becomes dim or the alarm function weakens, it is time to replace the battery.
- Follow the "Battery Installation" steps in the Setup section to replace the old battery with a new AA battery.
- Dispose of used batteries responsibly.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Clock not working / Display is blank.	Dead or incorrectly installed battery.	Check battery polarity. Replace with a new AA battery.

Problem	Possible Cause	Solution
Alarm does not sound.	Alarm is not activated. Alarm time is incorrectly set. Battery is low.	Ensure Alarm ON/OFF switch is in "ON" position. Verify alarm hand is set correctly for AM/PM. Replace battery.
Alarm sounds at the wrong time (e.g., PM instead of AM).	Alarm hand is set for the opposite 12-hour cycle.	Adjust the main time or alarm time by 12 hours to match the desired AM/PM cycle.
Backlight is dim or not working.	Low battery.	Replace with a new AA battery.

## SPECIFICATIONS

<b>Model Number</b>	TQ358-1
<b>Brand</b>	Casio
<b>Display Type</b>	Analog
<b>Power Source</b>	Battery Powered (1x AA battery, not included)
<b>Material</b>	Plastic
<b>Color</b>	Black
<b>Dimensions (L x W x H)</b>	3.9 x 0.5 x 3 inches
<b>Item Weight</b>	5.3 ounces
<b>Special Features</b>	Alarm, Snooze, Built-in Light

## WARRANTY AND SUPPORT

Casio products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Casio website. For technical support or inquiries, please contact Casio customer service through their official channels.

You can find more information and support at the official Casio website: [www.casio.com](http://www.casio.com)

