

Stanley 7061628

Stanley MIKROMIG Welding Machine

USER MANUAL

Brand: Stanley

1. INTRODUCTION

Welcome to the official user manual for your Stanley MIKROMIG Welding Machine, model 7061628. This manual provides essential information for the safe and efficient operation, setup, maintenance, and troubleshooting of your welding machine. Please read this manual thoroughly before using the product to ensure proper function and to prevent injury or damage.

The Stanley MIKROMIG is a semi-automatic flux-cored wire welding machine, particularly suited for welding thin sheet metal and bodywork. It is designed for ease of use and reliability.

2. SAFETY INFORMATION

Always prioritize safety when operating welding equipment. Failure to follow these safety guidelines can result in serious injury or property damage.

- **Eye Protection:** Always wear a suitable welding mask or helmet with appropriate shade lenses to protect your eyes from intense light and UV radiation. A basic welding mask is included with your machine.
- **Body Protection:** Wear flame-resistant clothing, welding gloves, and sturdy footwear to protect your skin from sparks, heat, and electrical shock.
- **Ventilation:** Ensure adequate ventilation in your work area to disperse welding fumes, which can be harmful if inhaled.
- **Fire Hazards:** Keep flammable materials away from the welding area. Have a fire extinguisher readily available.
- **Electrical Safety:** Ensure the machine is properly grounded. Do not operate in wet conditions. Inspect cables for damage before each use.
- **Overheating Protection:** The Stanley MIKROMIG is equipped with an overheating circuit breaker. If the machine overheats, it will automatically shut down. Allow it to cool down before resuming operation.
- **Children and Bystanders:** Keep children and unauthorized persons away from the welding area.

3. PRODUCT OVERVIEW

The Stanley MIKROMIG Welding Machine is a compact and powerful unit designed for various welding tasks, especially with thin materials. Familiarize yourself with its components:



This image displays the Stanley MIKROMIG welding machine, a yellow and black unit, alongside its essential accessories. These include a black welding mask, a spool of flux-cored wire, a ground clamp with cable, and a welding torch with its cable.

- **Welding Machine Unit:** The main power source and control panel.
- **Welding Torch:** Used to direct the welding wire and create the arc. Features a direct connection.
- **Ground Clamp with Cable:** Connects to the workpiece to complete the electrical circuit.
- **Wire Feed Adjustment Knob:** Controls the speed at which the flux-cored wire is fed.
- **Display Screen:** Indicates the wire feed speed.
- **Intensity Adjustment Levels:** Two settings for welding current (MIN/MAX).
- **Overheating Circuit Breaker:** Safety feature to prevent damage from excessive heat.
- **Flux-Cored Wire Spool:** The consumable welding material. A 300g test spool is included.
- **Welding Mask:** Basic eye protection for welding.

4. SETUP

Follow these steps to set up your Stanley MIKROMIG Welding Machine:

1. **Unpacking:** Carefully remove all components from the packaging. Inspect for any shipping damage.
2. **Placement:** Place the welding machine on a stable, level surface in a well-ventilated area, away from flammable materials.
3. **Wire Spool Installation:**
 - Open the wire compartment.
 - Mount the 0.5 kg flux-cored wire spool (0.8/1.0 mm diameter) onto the spindle. Ensure it rotates freely.
 - Feed the wire through the guide tube and into the wire feed mechanism.
 - Close the compartment.
4. **Ground Clamp Connection:** Connect the ground clamp cable to the appropriate terminal on the welding machine. Secure the ground clamp firmly to the workpiece or a clean, bare metal part of the welding table.

5. **Torch Connection:** The welding torch cable has a direct connection to the machine. Ensure it is securely attached.
6. **Power Connection:** Plug the machine's power cord into a suitable 230V - 50Hz electrical outlet. Ensure the outlet can handle the machine's power requirements (1.9 KVA absorbed power at 60%).

5. OPERATION

Once set up, you can begin welding. Always wear your welding mask and protective gear before starting.

1. **Power On:** Turn the power switch to the "ON" position.
2. **Adjust Welding Current:** Select the desired intensity level (MIN or MAX) based on the thickness of the material you are welding. The welding current range is 35 - 95 A.
3. **Adjust Wire Feed Speed:** Use the wire feed adjustment knob to set the appropriate wire feed speed. The display screen will show the current setting. Experiment with different speeds to find the optimal setting for your application.
4. **Welding:**
 - Position the torch nozzle close to the workpiece.
 - Press the trigger on the torch to start the wire feed and initiate the welding arc.
 - Move the torch steadily along the joint, maintaining a consistent arc length.
 - Release the trigger to stop welding.
5. **Duty Cycle:** The machine has a duty cycle of 95 A ~ 20%. This means it can weld at 95 Amps for 2 minutes out of every 10-minute period. Exceeding the duty cycle can cause the machine to overheat and activate the circuit breaker.
6. **Overheating Protection:** If the machine stops during operation, the overheating circuit breaker may have activated. Turn off the machine and allow it to cool down for at least 10-15 minutes before attempting to restart.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your welding machine.

- **Cleaning:** Regularly clean the machine's exterior with a dry cloth. Keep the wire feed mechanism free of dust and debris.
- **Wire Spool Replacement:** When the wire spool is empty, replace it with a new 0.5 kg flux-cored wire spool of the appropriate diameter (0.8/1.0 mm).
- **Torch Nozzle and Contact Tip:** Inspect the torch nozzle and contact tip regularly for wear and spatter buildup. Clean or replace as necessary to ensure consistent wire feeding and arc stability.
- **Cable Inspection:** Periodically check all cables (power, ground, torch) for cuts, abrasions, or loose connections. Replace damaged cables immediately.
- **Storage:** Store the welding machine in a dry, clean environment when not in use.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your Stanley MIKROMIG Welding Machine.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Machine does not power on.	No power supply; power switch off; internal fault.	Check power outlet and cable. Ensure power switch is ON. If problem persists, contact support.
No welding arc.	Poor ground connection; incorrect wire feed; worn contact tip; no wire.	Ensure ground clamp is securely attached to clean metal. Check wire feed setting. Replace contact tip. Check wire spool.
Wire not feeding properly.	Wire tangled; incorrect wire feed tension; clogged liner; worn drive roller.	Untangle wire. Adjust wire feed tension. Clean or replace liner. Inspect and replace drive roller if worn.
Machine shuts off during welding.	Overheating circuit breaker activated.	Turn off machine and allow it to cool down for 10-15 minutes. Reduce duty cycle or welding current if frequently occurring.
Poor weld quality.	Incorrect current/wire speed; improper technique; dirty workpiece.	Adjust current and wire speed settings. Practice welding technique. Clean workpiece thoroughly before welding.

8. TECHNICAL SPECIFICATIONS

Specification	Value
Model Number	7061628
Voltage	230V - 50Hz
Absorbed Power (at 60%)	1.9 KVA
No-Load Voltage	17 - 23.5 V
Welding Current Adjustment Range	35 - 95 A
Intensity Adjustment Levels	2
Duty Cycle	95 A ~ 20%
Torch Length	2 m
Wire Spool Capacity	0.5 kg
Flux-Cored Wire Diameter	0.8/1.0 mm
Insulation Class	H
Protection Rating	IP 21
Dimensions (L x W x H)	36 x 21.5 x 39.5 cm
Weight	15.15 kg
Included Accessories	300g test spool of flux-cored wire, welding mask

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase. Warranty terms and conditions may vary by region and retailer.

For technical support, spare parts, or service inquiries, please contact Stanley customer service or your authorized dealer. Keep your model number (7061628) and purchase receipt handy when contacting support.

While specific spare parts availability information is not provided, general maintenance items like wire spools and contact tips are widely available.

© 2024 Stanley. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.