

Tiger JBV-A18U-W

Tiger JBV-A18U-W Micom Rice Cooker Instruction Manual

MODEL: JBV-A18U-W

Introduction

The Tiger JBV-A18U Micom multi-functional rice cooker is designed to simplify your cooking process, allowing for simultaneous preparation of rice and a main dish using the innovative tacook synchronized cooking function. Its advanced cooking system precisely monitors temperatures to ensure perfectly cooked meals. This manual provides essential information for the safe and efficient operation, maintenance, and care of your rice cooker.

Key Features

- **Syncro-cooking function "tacook"**: Prepare main dish and rice simultaneously.
- **One-push operation**: Simple and intuitive control.
- **4 cooking menu settings**: Includes Synchrony-cooking, Plain rice, Brown rice, and Slow cooking.
- **Easy-to-clean non-stick fluorine coated inner pot**: Ensures effortless cleaning.
- **Convenient Keep-Warm function**: Maintains rice temperature for up to 12 hours.
- **Included accessories**: Non-stick spatula, Cooking plate, Measuring cup, and Cookbook for Synchrony-cooking.

Setup Guide

1. Unpacking

Carefully remove all components from the packaging. Ensure all accessories are present: inner pot, tacook cooking plate, rice measuring cup, spatula, and spatula holder.

2. Initial Cleaning

Before first use, wash the inner pot, tacook cooking plate, measuring cup, and spatula with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the rice cooker with a damp cloth.

3. Placement

Place the rice cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure

adequate ventilation around the unit.



Figure 1: Front view of the Tiger JBV-A18U-W Rice Cooker.

4. Power Connection

Plug the power cord into a standard 120-volt electrical outlet. Ensure the cord is not pinched or placed under heavy objects.



Figure 2: Side view showing the power cord connection.

Operating Instructions

1. Components Overview

Familiarize yourself with the inner pot, tacook cooking plate, and control panel buttons.





Figure 3: Rice cooker opened, showing the inner pot and tacook cooking plate.

2. Measuring Rice and Water

Use the provided measuring cup for accurate rice measurement. The inner pot has markings for Plain, Synchro, and Brown rice, indicating the appropriate water levels for each type and quantity of rice. For example, if cooking 2 cups of plain rice, fill water up to the '2' mark on the 'Plain' scale.



Figure 4: Inner pot with clear water level markings.

3. Cooking Modes

The rice cooker offers four automated cooking settings:

- **Plain Rice:** For perfectly cooked white rice.
- **Synchro-cooking:** Allows simultaneous cooking of rice in the inner pot and a main dish in the tacook cooking plate. The tacook plate is designed to prevent flavors from mixing.
- **Brown Rice:** Optimized for cooking brown rice.
- **Slow Cook/Steam:** For slow-cooked dishes or steaming various foods.



Figure 5: Control panel with Plain, Synchro-cooking, Brown, and Slow Cook/Steam options.



Figure 6: Example of the tacook cooking plate in use.

4. Keep Warm Function

Once cooking is complete, the rice cooker automatically switches to the Keep-Warm function, maintaining the ideal temperature for up to 12 hours. This ensures your rice is ready to serve whenever you are.

Care and Maintenance

1. Cleaning the Inner Pot

The non-stick fluorine coated inner pot is easy to clean. Hand wash with warm, soapy water and a soft sponge. Avoid abrasive cleaners or scouring pads to prevent damage to the non-stick coating. Do not wash in a dishwasher.

2. Cleaning the Lid and Exterior

The inner lid is detachable for thorough cleaning. Wash it with warm, soapy water. Wipe the exterior of the rice cooker with a damp cloth. Ensure all parts are completely dry before reassembling or storing.

Troubleshooting

- **Rice is too dry or hard:** Ensure correct water-to-rice ratio according to the inner pot markings. Make sure the lid is properly sealed during cooking.
- **Rice is too wet or mushy:** Reduce the water slightly for the next batch. Ensure rice is properly rinsed before cooking to remove excess starch.
- **Burnt smell during first use:** A slight burning plastic smell may occur during the initial use, which is normal and should dissipate after the first few uses.
- **Lid snaps up quickly when opened:** Always use caution when opening the lid after cooking to avoid steam burns.

Product Specifications

Brand	Tiger
Model Number	JBV-A18U-W
Capacity	10 Cups (Uncooked)
Product Dimensions	15.1"D x 11.9"W x 10"H
Item Weight	7.5 Pounds
Power Source	Corded Electric
Wattage	672 watts
Voltage	120 Volts
Material	Plastic (body), Aluminum (lid)
Color	White
Country of Origin	China



Figure 7: Product dimensions for placement reference.

Warranty and Support

For detailed warranty information and customer support, please refer to the official user manual provided with your product or visit the manufacturer's website. A digital version of the user manual can often be found online:

[Download User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question