

Yato YT-2298

YATO YT-2298 Crimping Tool Instruction Manual

INTRODUCTION

The YATO YT-2298 is a robust hand tool designed for creating secure electrical connections by crimping terminals onto wires. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your crimping tool. Please read these instructions carefully before use to ensure proper function and longevity of the tool.



Image: YATO YT-2298 Crimping Tool. This image displays the overall design of the YATO YT-2298 crimping tool, highlighting its handles and crimping jaws.

1. SETUP AND INITIAL INSPECTION

Before using the YATO YT-2298 crimping tool, perform a brief inspection to ensure it is in proper working condition.

- 1. Unpacking:** Carefully remove the crimping tool from its packaging.
- 2. Visual Inspection:** Check the tool for any signs of damage, such as bent jaws, loose handles, or cracks. Do not use the tool if any damage is observed.

3. **Cleanliness:** Ensure the crimping jaws are free from debris, dirt, or any foreign material that could affect performance.
4. **Functionality Check:** Open and close the handles a few times to ensure smooth operation and proper jaw alignment.

2. OPERATING INSTRUCTIONS

Follow these steps for effective and safe crimping:

1. **Select the Correct Terminal and Wire:** Ensure the terminal and wire gauge are compatible with each other and with the crimping tool's designated crimp size. Refer to the markings on the tool's jaws for appropriate sizes.
2. **Strip the Wire:** Using a wire stripper, carefully remove the insulation from the end of the wire to the appropriate length, typically matching the barrel length of the terminal. Avoid cutting or nicking the wire strands.
3. **Insert Wire into Terminal:** Insert the stripped end of the wire fully into the terminal barrel. Ensure all wire strands are inside the terminal.
4. **Position Terminal in Crimping Tool:** Open the crimping tool jaws and place the terminal into the correct crimping slot. The slot should match the size and type of the terminal (e.g., insulated, non-insulated). Ensure the terminal is seated firmly.





Image: Close-up of YATO YT-2298 crimping tool jaws. This image shows the various crimping slots on the tool, which are used to match different terminal sizes and types.

5. **Perform the Crimp:** Squeeze the handles of the crimping tool firmly and completely until the crimp cycle is finished. The tool may have a ratchet mechanism that prevents it from opening until a full crimp is achieved.
6. **Inspect the Crimp:** After crimping, release the handles and remove the crimped terminal. Visually inspect the crimp for proper formation. It should be tight and secure, with no loose wire strands. Gently tug on the wire to ensure it is securely held by the terminal.

3. MAINTENANCE

Proper maintenance ensures the longevity and reliable performance of your YATO YT-2298 crimping tool.

- **Cleaning:** After each use, wipe the tool with a clean, dry cloth to remove any dirt, dust, or residue. For stubborn grime, a mild solvent can be used, ensuring it does not damage the tool's finish or moving parts.
- **Lubrication:** Periodically apply a small amount of light machine oil to the pivot points and moving parts to ensure smooth operation. Wipe off any excess oil.

- **Storage:** Store the crimping tool in a dry, clean environment to prevent rust and corrosion. Keep it away from excessive moisture and extreme temperatures.
- **Inspection:** Regularly inspect the crimping jaws for wear or damage. Worn jaws can lead to poor crimps.

4. TROUBLESHOOTING

If you encounter issues with your crimping tool, refer to the following common problems and solutions:

- **Poor Crimp Quality (Loose or Damaged):**
 - **Cause:** Incorrect terminal/wire size for the chosen crimp slot. Insufficient pressure applied during crimping. Worn or damaged crimping jaws.
 - **Solution:** Ensure the terminal and wire match the crimping slot. Apply full pressure until the crimp cycle is complete. Inspect jaws for wear and replace the tool if necessary.
- **Tool Jaws Sticking or Difficult to Operate:**
 - **Cause:** Lack of lubrication. Dirt or debris in the pivot points or jaws.
 - **Solution:** Clean the tool thoroughly and apply light machine oil to all moving parts.
- **Wire Pulls Out of Terminal After Crimping:**
 - **Cause:** Wire not stripped to the correct length. Wire strands not fully inserted into the terminal. Incorrect crimp size used.
 - **Solution:** Ensure proper wire stripping length and full insertion. Verify the correct crimp slot was used for the terminal and wire gauge.

5. SPECIFICATIONS

Manufacturer	Yato
Model Number	YT-2298
Product Dimensions (L x W x H)	3.6 x 7.2 x 23.4 cm
Product Weight	598 grams
Color	Black
Handle Type	Profiled
Power Source	Manual

6. WARRANTY INFORMATION

Specific warranty information for the YATO YT-2298 crimping tool is not provided in the product details. Please refer to the manufacturer's official website, product packaging, or your point of purchase for detailed warranty terms and conditions.

7. CUSTOMER SUPPORT

For technical assistance, spare parts, or further inquiries regarding your YATO YT-2298 crimping tool, please contact Yato customer service. Contact details, including phone numbers and email addresses, are typically available on the official Yato website (www.yato.com) or included with the product packaging.