



[Manuals.plus](#) /

› [HEALTHLINE](#) /

› Healthline Folding Walker W1-SRK3 Instruction Manual

HEALTHLINE W1-SRK3

Healthline Folding Walker W1-SRK3 Instruction Manual

Model: W1-SRK3 | Brand: HEALTHLINE

INTRODUCTION

This Healthline Folding Walker is designed to provide stable and reliable support for adults requiring mobility assistance. Constructed from lightweight, anodized extruded aluminum, it features a reinforced crossbar for enhanced stability. The walker is equipped with two 5-inch front wheels and two sets of rear glides, allowing for smooth movement across various floor types. Its convenient 2-button push mechanism enables easy folding for storage and transport. The height-adjustable legs ensure a comfortable and secure fit for users of different heights.

Exactly What **You'll Receive**



Figure 1: Components included with the Healthline Folding Walker.

SETUP INSTRUCTIONS

The Healthline Folding Walker requires minimal assembly and no tools. Follow these steps to prepare your walker for use:

1. **Unfold the Walker:** Gently pull the sides of the walker apart until it locks into its open position. Ensure both sides are fully extended and locked.
2. **Attach Front Wheels:** The walker comes with two 5-inch front wheels. Insert the wheel legs into the front frame tubes until the spring buttons snap into place.
3. **Install Rear Glides:** Remove the existing rubber tips from the rear legs. Insert the provided rear glide caps onto the rear legs. These glides facilitate movement across different floor surfaces.
4. **Adjust Height:** Press the spring buttons on each leg and slide the leg up or down to the desired height. Ensure all four legs are adjusted to the same height and the spring buttons are fully engaged in the adjustment holes. The palm grips

should be at wrist level when standing upright with arms relaxed.

Verified Size

Folds to 25" | Height adjusts 28" to 38"



Figure 2: Walker dimensions and height adjustment points.

Video 1: Demonstration of how to replace walker wheels and install glides.

OPERATING INSTRUCTIONS

Using the Walker

- Always ensure the walker is fully open and locked before use.
- Place the walker approximately one arm's length in front of you.
- Step forward with your weaker leg first, followed by your stronger leg.
- Maintain an upright posture and use the walker for balance and support.

- Do not lean heavily on one side of the walker. Distribute your weight evenly.

Folding the Walker

To fold the walker for storage or transport, locate the two red push-buttons on the top bar of the walker. Press both buttons simultaneously and gently push the sides of the walker inwards until it folds flat. The compact design allows for easy storage in closets or vehicles.



Figure 3: The 2-button easy fold mechanism.

Confidence Indoors & Outdoors



Figure 4: The Healthline Folding Walker provides stable support for indoor and outdoor use.

MAINTENANCE

- **Cleaning:** Wipe down the walker frame with a damp cloth and mild soap as needed. Avoid abrasive cleaners.
- **Inspection:** Regularly check all screws, bolts, and moving parts to ensure they are secure. Inspect the wheels and glides for wear and tear. Replace worn parts immediately to maintain safety and performance.
- **Storage:** Store the walker in a dry place away from extreme temperatures. When folded, it takes up minimal space.

TROUBLESHOOTING

- **Walker feels unstable:** Ensure all four legs are adjusted to the same height and the spring buttons are fully engaged. Check for loose connections and tighten if necessary.
- **Difficulty moving:** Inspect wheels and glides for debris or excessive wear. Clean or replace as needed. Ensure the walker is used on appropriate surfaces.

- **Difficulty folding:** Ensure both red push-buttons are pressed simultaneously and fully. Check for any obstructions in the folding mechanism.

SPECIFICATIONS

Feature	Detail
Model Number	W1-SRK3
Material	Aluminum, Rubber
Weight Capacity	300 lbs (136 kg)
Item Weight	6.83 lbs (3.1 kg)
Maximum Height	38.5 inches (97.8 cm)
Minimum Height	25.5 inches (64.8 cm)
Width Between Handles	18 inches (45.7 cm)
Overall Bottom Outside Front Width (incl. wheels)	24 inches (61 cm)
Front Width (inside wheel to wheel)	17 inches (43.2 cm)
Outside Bottom Back Width	22 inches (55.9 cm)
Inside Bottom Back Width	19 inches (48.3 cm)
Wheels	Two 5-inch front wheels
Foldable	Yes

WARRANTY AND SUPPORT

Healthline is committed to providing quality products. If your product arrives defective or incomplete, please contact the manufacturer or seller for immediate replacement or return. Your safety and satisfaction are our priority. For further assistance or inquiries, please refer to the contact information provided with your purchase or visit the official Healthline website.

