

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Vemo](#) /

› [Vemo V30-72-0145 Wheel Speed Sensor User Manual](#)

Vemo V30-72-0145

Vemo V30-72-0145 Wheel Speed Sensor User Manual

Model: V30-72-0145 | Brand: Vemo

1. PRODUCT OVERVIEW

The Vemo V30-72-0145 is a high-quality wheel speed sensor designed for automotive applications. This sensor plays a critical role in vehicle safety systems, including the Anti-lock Braking System (ABS), Traction Control System (TCS), and Electronic Stability Program (ESP). It accurately measures the rotational speed of the wheel and transmits this data to the vehicle's Electronic Control Unit (ECU), enabling precise control over braking and stability functions.



Figure 1: The Vemo V30-72-0145 wheel speed sensor, showing its main body, cable, and connector. The sensor features a flange mount design and is constructed from durable Acrylonitrile Butadiene Styrene.

2. SPECIFICATIONS

Attribute	Detail
Brand	Vemo
Model Number	V30-72-0145
Material	Acrylonitrile Butadiene Styrene
Item Weight	1.6 ounces
Dimensions (L x W x H)	4.9 x 1 x 9 inches
Mounting Type	Flange Mount
Position	Front
OEM Part Numbers	MERCEDES-BENZ: 220 540 01 17, 220 540 02 17

3. SETUP AND INSTALLATION

Installation of the Vemo V30-72-0145 wheel speed sensor should be performed by a qualified technician or an individual with experience in automotive repair. Incorrect installation can lead to system malfunctions and compromise vehicle safety.

3.1. Pre-Installation Checks

- Ensure the vehicle's ignition is off and the battery is disconnected to prevent electrical hazards.
- Identify the correct wheel location for sensor replacement (e.g., front left, front right).
- Inspect the new sensor for any visible damage or defects.
- Gather necessary tools, which typically include wrenches, sockets, a flathead screwdriver, and potentially a diagnostic scanner.

3.2. Removal of Old Sensor

1. Safely lift the vehicle and secure it with jack stands. Remove the wheel.
2. Locate the existing wheel speed sensor. It is usually mounted near the wheel hub or steering knuckle.
3. Disconnect the electrical connector by carefully pressing the release tab and pulling it apart. Avoid pulling on the wires.
4. Unbolt the sensor from its mounting point. Some sensors may be held by a single bolt, while others might be pressed into a bore.
5. Carefully remove the old sensor. If it is seized, use penetrating oil and gentle persuasion. Avoid damaging the sensor ring or tone wheel.

3.3. Installation of New Sensor

1. Clean the mounting surface and bore thoroughly to ensure proper seating of the new sensor. Remove any rust or debris.
2. Insert the new Vemo V30-72-0145 sensor into its mounting location. Ensure it is fully seated and aligned correctly.
3. Secure the sensor with the mounting bolt(s). Tighten to the manufacturer's specified torque, if available. Do not overtighten.

4. Connect the electrical connector firmly until it clicks into place. Ensure a secure connection.
5. Route the sensor cable along the original path, securing it with any clips or ties to prevent chafing or interference with moving parts.
6. Reinstall the wheel and lower the vehicle.
7. Reconnect the battery.

3.4. Post-Installation Verification

- Start the vehicle and check for any ABS, TCS, or ESP warning lights on the dashboard.
- If a diagnostic scanner is available, clear any stored fault codes related to the wheel speed sensor.
- Perform a short test drive to confirm proper operation of the ABS and other related systems. The warning lights should extinguish if the sensor is functioning correctly.

4. OPERATING PRINCIPLES

The Vemo V30-72-0145 wheel speed sensor operates on the principle of electromagnetic induction or the Hall effect, depending on its specific design. Most modern wheel speed sensors are active sensors, meaning they require a power supply and generate a digital signal.

- **Sensor Ring/Tone Wheel:** The sensor works in conjunction with a toothed wheel (tone wheel) or a magnetic encoder ring, typically located on the wheel hub or axle shaft.
- **Signal Generation:** As the wheel rotates, the teeth of the tone wheel or the magnetic poles of the encoder ring pass by the sensor. This movement induces a voltage pulse (in passive sensors) or causes a change in the magnetic field detected by the Hall effect element (in active sensors).
- **Signal Transmission:** These pulses or changes are converted into an electrical signal, which is then sent to the vehicle's ECU. The frequency of these pulses is directly proportional to the wheel's rotational speed.
- **ECU Interpretation:** The ECU uses this speed data from all wheels to determine if a wheel is locking up during braking (ABS), slipping during acceleration (TCS), or if the vehicle is losing directional stability (ESP). Based on this information, the ECU can modulate brake pressure or engine power to maintain control.

5. MAINTENANCE

Wheel speed sensors are generally low-maintenance components. However, periodic inspection can help ensure their longevity and proper function.

- **Visual Inspection:** During routine vehicle maintenance (e.g., tire rotations, brake inspections), visually inspect the sensor and its wiring for any signs of physical damage, corrosion, or fraying.
- **Cleanliness:** Ensure the sensor head and the tone wheel/encoder ring are free from excessive dirt, rust, or debris, which can interfere with accurate readings. Use a soft brush or compressed air for cleaning if necessary.
- **Secure Mounting:** Verify that the sensor is securely mounted and not loose.
- **Wiring Integrity:** Check that the wiring harness is properly routed and secured, preventing it from rubbing against moving parts or hot surfaces.

Do not attempt to disassemble the sensor, as it is a sealed unit and not user-serviceable.

6. TROUBLESHOOTING

If you experience issues with your vehicle's ABS, TCS, or ESP systems, or if a warning light illuminates, the wheel speed sensor may be a contributing factor. Here are common troubleshooting steps:

Symptom	Possible Cause	Solution
ABS/TCS/ESP warning light illuminated	Faulty sensor, damaged wiring, dirty tone wheel, or ECU issue.	<p>Check sensor wiring for damage or loose connections.</p> <p>Inspect tone wheel for damage or excessive debris.</p> <p>Use an OBD-II scanner to retrieve fault codes. Codes like C0031-C0034 (for wheel speed sensor circuits) indicate a sensor issue.</p> <p>Test sensor resistance/voltage output (requires specific tools and knowledge).</p> <p>Replace the sensor if it tests faulty.</p>
Erratic speedometer readings	Incorrect signal from a wheel speed sensor (less common for this specific sensor, but possible if used for speedometer input).	<p>Verify sensor connection and integrity.</p> <p>Check for bent or damaged tone wheel teeth.</p> <p>Consult a professional for diagnosis.</p>
ABS activates at low speeds or when stopping	Sensor signal discrepancy, often due to a dirty or damaged tone wheel, or a faulty sensor.	<p>Clean the tone wheel and sensor head.</p> <p>Inspect for physical damage to the tone wheel.</p> <p>If issues persist, professional diagnosis is recommended.</p>

Note: Many issues related to wheel speed sensors require specialized diagnostic tools and automotive knowledge. If you are unsure about any step, it is highly recommended to seek assistance from a certified automotive technician.

7. WARRANTY AND SUPPORT


Vemo products are manufactured to high standards. For specific warranty information regarding the Vemo V30-72-0145 wheel speed sensor, please refer to the warranty documentation provided with your purchase or visit the official Vemo website. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

For technical support, installation queries, or warranty claims, please contact your authorized Vemo distributor or the Vemo customer service department. Ensure you have your product model number (V30-72-0145) and proof of purchase available when contacting support.

Vemo Official Website: www.vemo.com (This is a placeholder URL, please verify the actual Vemo website for support.)

© 2024 Vemo. All rights reserved. This manual is for informational purposes only.

Related Documents - V30-72-0145

 <p>USER GUIDE LG V30™</p> <p>Copyright ©2017 LG Electronics Inc. All rights reserved. MLP7028701110 www.lg.com</p>	<p>LG V30 User Guide: Features, Settings, and Tips</p> <p>Comprehensive user guide for the LG V30 smartphone, covering setup, features, camera, settings, apps, safety, and troubleshooting. Learn to maximize your device's potential.</p>
 <p>Monitoring relays and float switch</p> <p>72</p>	<p>Finder 72 Series Monitoring Relays and Float Switches Technical Catalog</p> <p>Comprehensive guide to Finder's 72 Series monitoring relays, including level control relays (72.01, 72.11, 72.51), priority change relays (72.42), and float switches (72.A1, 72.B1, 72.C1). Features, specifications, applications, and ordering information.</p>
 <p>5</p>	<p>5TH WHEEL Electric Scooter ES09 User Manual</p> <p>Comprehensive user manual for the 5TH WHEEL Electric Scooter ES09, covering safety instructions, product features, assembly, operation, maintenance, troubleshooting, and technical specifications.</p>
 <p>Relee de supraveghere și Plutătoare cu contact comutator</p> <p>72</p>	<p>Finder Series 72: Liquid Level Relays, Load Alternators, and Float Switches</p> <p>Comprehensive technical documentation for Finder Series 72 products, including liquid level monitoring relays (72.01, 72.11, 72.51), load alternating relays (72.42), and float switches (72.A1, 72.B1, 72.C1). Features detailed specifications, applications, accessories, wiring diagrams, and usage instructions.</p>
 <p>6</p>	<p>Egoluce 0206 LED Downlight Installation Guide & Specifications</p> <p>Comprehensive installation guide for Egoluce 0206 series LED downlights, including models 6690 Star1, 6691 Star2, 6692 Star IP, and 6693 Star RGB. Features remote driver information and safety instructions.</p>
 <p>72</p>	<p>Finder Serie 72 Level Control Relays and Float Level Regulators</p> <p>Comprehensive technical catalog for Finder Serie 72 level control relays and float level regulators, detailing types 72.01, 72.11, 72.42, 72.51, 72.A1, 72.B1, and 72.C1. Includes product specifications, applications, wiring diagrams, and accessories for industrial automation.</p>