

[Manuals.plus](#) /

› [Everflourish](#) /

› Everflourish EMT707 Weekly Digital Timer Instruction Manual

Everflourish EMT707

Everflourish EMT707 Weekly Digital Timer Instruction Manual

Model: EMT707

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Everflourish EMT707 Weekly Digital Timer. Please read these instructions carefully before using the device to ensure proper function and safety. This timer is designed to automatically control the power supply to electrical appliances based on your programmed schedule.

2. PRODUCT OVERVIEW

The Everflourish EMT707 is a plug-in digital timer featuring a clear LCD display and multiple control buttons for precise scheduling. It includes a standard European Type F (Schuko) plug and socket.



Figure 1: Front view of the Everflourish EMT707 Weekly Digital Timer. The device features an LCD screen at the top, surrounded by control buttons. Below the controls is a standard European Type F (Schuko) socket.

2.1. Controls and Display

- **LCD Display:** Shows current time, day, and programming status.
- **WEEK Button:** Used to set the day of the week.
- **HOURL Button:** Used to set the hour.
- **MIN Button:** Used to set the minute.
- **ON/AUTO/OFF Button:** Cycles through ON, AUTO, and OFF modes.
- **RST/RCL Button:** Resets settings or recalls programmed events.
- **CLOCK Button:** Used to set the current time and day.
- **PROG Button:** Enters programming mode to set ON/OFF times.
- **RESET Button (Recessed):** A small, recessed button (often requiring a pointed object like a pen) to perform a full factory reset.

3. SETUP

1. **Initial Charge:** Before first use, plug the timer into a live power outlet for at least 10-15 minutes to charge its internal battery. The display may be blank or dim until sufficiently charged.

2. **Reset:** After charging, use a pointed object (e.g., a pen tip) to press the recessed **RESET** button. This clears all previous settings and ensures proper operation. The display should show "0:00" and a flashing cursor.

3. **Set Current Time:**

- Press and hold the **CLOCK** button.
- While holding **CLOCK**, press the **WEEK** button repeatedly to set the current day (MO, TU, WE, TH, FR, SA, SU).
- While holding **CLOCK**, press the **HOURL** button repeatedly to set the current hour (0-23).
- While holding **CLOCK**, press the **MIN** button repeatedly to set the current minute (0-59).
- Release the **CLOCK** button. The time is now set.

4. OPERATING INSTRUCTIONS

4.1. Setting Programs (ON/OFF Times)

The timer allows you to set up to 10 ON/OFF programs for various days or combinations of days.

1. Press the **PROG** button once. The display will show "1 ON" and "0:00".
2. Press the **WEEK** button to select the desired day(s) for this program. Options include individual days, weekdays, weekends, or all 7 days.
3. Press the **HOURL** button to set the desired ON hour.
4. Press the **MIN** button to set the desired ON minute.
5. Press the **PROG** button again. The display will show "1 OFF" and "0:00".
6. Repeat steps 2-4 to set the desired OFF time for the first program.
7. Continue pressing **PROG** to cycle through "2 ON", "2 OFF", up to "10 ON", "10 OFF", setting each program as needed.
8. After setting all desired programs, press the **CLOCK** button to exit programming mode and return to the current time display.

4.2. Manual Override (ON/AUTO/OFF)

Press the **ON/AUTO/OFF** button to cycle through the following modes:

- **ON:** The timer output is continuously ON, overriding all programs.
- **OFF:** The timer output is continuously OFF, overriding all programs.
- **AUTO:** The timer operates according to the programmed ON/OFF schedules. This is the standard operating mode for automated control.

Ensure the timer is in **AUTO** mode for your programs to execute.

5. MAINTENANCE

- **Cleaning:** Wipe the timer with a dry, soft cloth. Do not use liquid cleaners or immerse the device in water.
- **Storage:** If storing the timer for an extended period, ensure it is fully charged periodically to maintain the internal battery's health.
- **Environment:** Use the timer indoors only, in a dry environment, away from direct sunlight, extreme temperatures, and humidity.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Internal battery is not charged.	Plug the timer into a live power outlet for at least 10-15 minutes to charge the battery.
Timer does not turn ON/OFF at programmed times.	◦ Timer is not in AUTO mode. ◦ Incorrect program settings. ◦ Current time is not set correctly.	◦ Press ON/AUTO/OFF until "AUTO" is displayed. ◦ Review and correct your ON/OFF program settings (Section 4.1). ◦ Verify and reset the current time (Section 3.3).
All settings are lost or timer behaves erratically.	System error or power fluctuation.	Perform a full reset by pressing the recessed RESET button with a pointed object. Then, re-set the current time and programs.

7. SPECIFICATIONS

- **Model:** EMT707
- **Type:** Weekly Digital Timer
- **Power Supply:** 230V~, 50Hz (Standard European)
- **Programs:** Up to 10 ON/OFF programs per day/week.
- **Internal Battery:** Rechargeable for memory backup.

Note: Specific electrical ratings (e.g., maximum current/power) should be verified on the product's physical label.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer or manufacturer's official website. Keep your purchase receipt as proof of purchase.