

GIFPRO Micro Master

GIFPRO Micro Master Microwave Pressure Cooker Instruction Manual

Model: Micro Master

1. INTRODUCTION

The GIFPRO Micro Master Microwave Pressure Cooker is designed to provide a fast and efficient way to cook a variety of meals using your microwave oven. With its 2.85-liter capacity, it is ideal for preparing meats, stews, beans, rice, chicken, pasta, and vegetables, helping to retain essential vitamins and minerals. This manual provides important instructions for safe and effective use, maintenance, and troubleshooting.

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance.

- **Valve Operation:** Ensure the pressure release valve on the lid is **open** during the cooking process in the microwave. Close the valve only after removing the cooker from the microwave to allow food to rest for approximately 5 minutes before serving.
- **Steam Release:** Always open the lid carefully, directing steam away from your face and hands, to avoid burns. Use the handles to secure the lid when opening.
- **Microwave Power:** Do not operate the cooker for more than 30 minutes at maximum power (e.g., 750 watts). If your microwave has a higher wattage (e.g., 900 watts), adjust cooking times accordingly or use a lower power setting. If longer cooking is required, remove the cooker, allow it to cool slightly, then resume cooking.
- **Food Preparation:** Do not use the cooker for frying or toasting. Avoid cooking very dry foods without sufficient liquid. Do not boil liquids alone at maximum power.
- **Capacity Limit:** Do not fill the cooker beyond approximately two-thirds (2/3) of its total capacity to prevent overflow and ensure proper pressure build-up.
- **Utensils:** Do not use a blender or other sharp utensils directly inside the cooker, as this may scratch or damage the plastic. Transfer food to another container for blending if necessary.
- **Microwave Settings:** Ensure your microwave is set to the standard microwave function. Never use

the grill or combination modes with this product, as it can cause damage to the cooker.

- **Lid Assembly:** Always ensure the lid is properly secured and latched before placing the cooker in the microwave.

3. COMPONENTS

The GIFPRO Micro Master Microwave Pressure Cooker consists of the following main parts:

- **Main Pot:** The primary cooking vessel with integrated handles.
- **Lid:** Features a double-layer design with a pressure release valve and securing tabs.
- **Pressure Release Valve:** A small, removable component on the lid that regulates steam pressure.



Image 1: The GIFPRO Micro Master Microwave Pressure Cooker, fully assembled with its lid and pressure release valve. This image shows the cooker's compact, white design with integrated side handles.

4. SETUP

Before first use, wash all components thoroughly with warm, soapy water. Ensure all parts are dry before assembly.

1. **Assemble the Lid:** The lid is designed to be detachable for cleaning. To assemble, align the two halves of the lid and press them firmly together until they click into place. Ensure the pressure release valve is securely inserted into its opening.

2. **Attach Lid to Pot:** Place the assembled lid onto the main pot, aligning the securing tabs on the lid with the corresponding slots on the pot. Press down firmly and engage the side latches to secure the lid. It may require a firm push to ensure a tight seal.

5. OPERATING INSTRUCTIONS (COOKING GUIDE)

The Micro Master Microwave Pressure Cooker simplifies cooking by utilizing steam pressure within your microwave. Always ensure the pressure release valve is open during cooking.

1. **Prepare Ingredients:** Place your desired ingredients into the main pot. Add the appropriate amount of liquid (water, broth, etc.) as required by your recipe. Remember not to exceed two-thirds of the pot's capacity.
2. **Secure the Lid:** Place the lid onto the pot and securely fasten the side latches. Ensure the pressure release valve is in the **open** position.
3. **Microwave Cooking:** Place the cooker into your microwave oven. Cook according to your recipe's instructions, keeping in mind the maximum recommended cooking time of 30 minutes at 750W. Adjust time or power for different microwave wattages.
4. **Resting Period:** Once cooking is complete, carefully remove the cooker from the microwave using oven mitts. Close the pressure release valve and allow the food to rest for approximately 5 minutes. This allows the internal pressure to equalize and flavors to meld.
5. **Serve:** After the resting period, carefully open the pressure release valve (if closed) and then unlatch and remove the lid, directing steam away from your face. Serve your freshly cooked meal.

Cooking Tips:

- For dishes like rice, lentils, and stews, ensure adequate liquid is added.
- When cooking vegetables, a small amount of water is often sufficient to create steam.
- If you are unsure about liquid quantities, check the food periodically by carefully removing the cooker from the microwave, releasing pressure, and opening the lid. Add more liquid if needed.
- The cooker is suitable for 2-3 normal servings or 4 smaller servings.



Image 2: The GIFPRO Micro Master Microwave Pressure Cooker shown with cooked broccoli and another dish, illustrating its versatility for preparing various meals. The lid is partially open, revealing the contents.

6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your GIFPRO Micro Master Microwave Pressure Cooker.

- **Disassembly:** For thorough cleaning, the lid can be disassembled into its two halves. Gently pull the bottom cover of the lid using the designated tab until it separates. The black pressure valve can also be removed for cleaning.
- **Washing:** The cooker is dishwasher safe (top rack recommended). However, hand washing with warm, soapy water and a soft sponge is recommended to preserve the plastic and prevent scratching.
- **Stains:** Some foods, especially those with strong colors like turmeric, may cause staining. To minimize staining, clean the cooker immediately after use. For persistent stains, soaking overnight in a mild detergent solution may help. Avoid harsh chemicals or abrasive scrubbers.
- **Drying:** Ensure all parts are completely dry before reassembling and storing.

7. TROUBLESHOOTING

- **Lid Does Not Seal Properly:** Ensure the two halves of the lid are correctly assembled and that the side latches are fully engaged. Sometimes a firm push is needed to create a tight seal.

- **Food Not Cooking Evenly or Quickly:** Verify that the pressure release valve was open during cooking. Check your microwave's power setting and adjust cooking time as necessary. Ensure sufficient liquid was added to generate steam.
- **Staining Occurs:** This is normal with certain ingredients. Refer to the Cleaning and Maintenance section for tips on stain removal.
- **Steam Escaping Excessively:** Confirm the lid is properly sealed and the pressure release valve is correctly seated. If steam escapes from around the lid, it may not be fully latched.

8. SPECIFICATIONS

- **Brand:** GIFPRO
- **Model:** Micro Master
- **Capacity:** 2.85 Liters
- **Dimensions:** Approximately 20 x 20 x 15 cm
- **Material:** Food-grade plastic (PP5)
- **Color:** White
- **Control Method:** Manual
- **Operating Mode:** Manual

9. WARRANTY AND SUPPORT

Specific warranty information for the GIFPRO Micro Master Microwave Pressure Cooker is not provided in the product details. For any questions regarding your product, warranty claims, or support, please contact the retailer or manufacturer directly through their official channels. Keep your proof of purchase for any potential claims.