

[Manuals.plus](#) /

› [Matrix](#) /

› Matrix MX-S1x Stepper User Manual

Matrix MX-S1x

Matrix MX-S1x Stepper User Manual

Model: MX-S1x | Brand: Matrix

INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Matrix MX-S1x Stepper. Please read this manual thoroughly before using the equipment.

The Matrix MX-S1x Stepper is designed to provide a robust and effective cardiovascular workout. It features large independent pedals for biomechanically correct movement, a speed control function for adjusting workout intensity, and an electronically controlled brake system that precisely manages pedal descent from 32 to 122 steps per minute.

PRODUCT OVERVIEW



An image showing the Matrix MX-S1x Stepper from a front-right angle, highlighting its console, handlebars, and large independent pedals. This view provides a comprehensive look at the machine's overall design and key components.

Familiarize yourself with the main components of your stepper:

- **Console:** Displays workout data such as time, steps, and calories.
- **Handlebars:** Provide stability and support during your workout.
- **Pedals:** Large, independent pedals designed for safe and effective stepping motion.
- **Brake System:** Electronically controlled to manage pedal descent.
- **Frame:** The main structural support of the machine.

SETUP

Unpacking and Placement

1. Carefully remove all components from the packaging. Retain packaging materials for future transport or storage.
2. Verify that all parts listed in the assembly guide (not provided in this manual, refer to separate assembly instructions if included with purchase) are present and undamaged.
3. Place the stepper on a flat, stable surface. Ensure there is adequate clear space around the machine (at least 0.6 meters or 2 feet) for safe operation and access.
4. Avoid placing the machine in direct sunlight or near heat sources, and ensure it is in a well-ventilated area.

Assembly (General Guidance)

While specific assembly instructions are typically provided with the product packaging, general steps may include:

- Attaching the main console mast to the base frame.
- Securing the handlebars to the console mast.
- Connecting any necessary electrical cables for the console and brake system.
- Ensuring all bolts and fasteners are tightened securely before use.

Always refer to the dedicated assembly guide that came with your Matrix MX-S1x Stepper for detailed, step-by-step instructions.

OPERATING INSTRUCTIONS

Powering On and Console Use

1. Connect the power cord to a suitable electrical outlet.
2. The console should illuminate. If not, check the power connection.
3. The console display will show various workout metrics. Use the console buttons (e.g., Start, Stop, Program, Up/Down arrows) to navigate menus, select programs, and adjust settings.

Starting a Workout

1. Step onto the pedals, one foot at a time, ensuring you maintain balance by holding the handlebars.
2. Begin a stepping motion. The machine will typically activate once movement is detected or after pressing a 'Start' button on the console.
3. **Speed Control:** The MX-S1x features a speed control function. Use the designated controls on the console to easily change the intensity of the stepping action during your workout. Increasing the speed will increase the challenge.
4. **Brake System:** The electronically controlled brake precisely controls the pedal descent. This system allows for a smooth and controlled stepping motion, with a range of 32 to 122 steps per minute. Adjustments to resistance or stepping rate are typically made via the console.
5. Maintain an upright posture and engage your core throughout the exercise.

Ending a Workout

Gradually slow down your stepping motion. Press the 'Stop' button on the console. Once the pedals have come to a complete stop, carefully step off the machine.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Matrix MX-S1x Stepper.

Cleaning

- Wipe down the machine after each use with a damp cloth to remove sweat and dust.
- Do not use abrasive cleaners or solvents, as these can damage the finish and electronic components.
- Keep the console free of moisture.

Inspections

- Periodically check all bolts, nuts, and screws to ensure they are tight. Tighten any loose fasteners.
- Inspect the pedals and their mechanisms for any signs of wear or damage.
- Check the power cord for fraying or damage. If damaged, discontinue use and contact customer support.

Lubrication

Consult your product's specific maintenance guide for lubrication requirements. Generally, moving parts may require periodic lubrication to ensure smooth operation and prevent squeaking. Use only recommended lubricants.

TROUBLESHOOTING

This section addresses common issues you might encounter with your Matrix MX-S1x Stepper.

Problem	Possible Cause	Solution
Machine not powering on / Console blank.	Power cord not connected; Outlet not active; Circuit breaker tripped.	Ensure power cord is securely plugged into the machine and a working outlet. Check household circuit breaker.
Pedals not moving smoothly or making noise.	Loose fasteners; Lack of lubrication; Obstruction.	Check and tighten all visible bolts and nuts. Apply recommended lubricant if necessary. Inspect for any foreign objects.
Console display inaccurate or erratic.	Loose cable connection; Sensor issue.	Check all console cable connections. Power cycle the machine (unplug, wait 30 seconds, plug back in).
Resistance/Speed adjustment not working.	Electronic control issue; Cable disconnection.	Ensure all electronic connections are secure. If the issue persists, contact customer support.

If you encounter a problem not listed here, or if the suggested solutions do not resolve the issue, please contact Matrix customer support.

SPECIFICATIONS

Attribute	Detail
Brand	Matrix
Model	MX-S1x
Sport Type	Fitness
Manufacturer	Johnson Health Tech
ASIN	B00V824Z46

Attribute	Detail
First Available	26 March 2015
Pedal Control	Electronically controlled brake, 32 to 122 steps per minute

WARRANTY AND SUPPORT

For information regarding the warranty coverage for your Matrix MX-S1x Stepper, please refer to the warranty card included with your purchase or visit the official Matrix Fitness website. Warranty terms and conditions may vary by region and retailer.

For technical support, parts, or service inquiries, please contact the manufacturer, Johnson Health Tech, or your authorized Matrix Fitness dealer. Have your model number (MX-S1x) and ASIN (B00V824Z46) ready when contacting support.

Contact information for Johnson Health Tech can typically be found on their official website or on the product packaging.

© 2024 Matrix Fitness. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question