

MOPEDIA RP735

MOPEDIA RP735 2-Wheel Walker Instruction Manual

Model: RP735 | Brand: MOPEDIA

1. INTRODUCTION

Thank you for choosing the MOPEDIA RP735 2-Wheel Walker. This instruction manual provides essential information for the safe assembly, operation, and maintenance of your new mobility aid. Please read this manual thoroughly before using the walker and keep it for future reference.

The MOPEDIA RP735 is a foldable walker featuring an anodized aluminum structure. Its lightweight design and two fixed front wheels allow for easy maneuverability, providing stable support for elderly and disabled individuals without risking loss of balance. Equipped with non-slip rubber tips and padded handles, it further enhances user safety by preventing slipping. This walker is primarily recommended for indoor use.



Image 1.1: MOPEDIA RP735 2-Wheel Walker. This image displays the walker in its upright, ready-to-use position, highlighting its aluminum frame, two front wheels, and rear non-slip rubber tips.

2. SAFETY INFORMATION

Your safety is paramount. Please observe the following precautions:

- Always ensure the walker is fully open and stable before use.
- Verify that all locking mechanisms and height adjustment pins are securely engaged.
- Do not exceed the maximum weight limit of **130 kg (286 lbs)**.
- Regularly inspect the rubber tips on the rear legs and the front wheels for wear. Replace them if they show signs of damage or excessive wear.
- Use the walker on flat, stable surfaces. Avoid uneven terrain, stairs, or escalators.
- Do not use the walker as a seat or to transport heavy objects.
- Keep hands and fingers clear of moving parts during folding and unfolding.
- Consult a healthcare professional or therapist for proper gait training and usage techniques.

3. PACKAGE CONTENTS

Upon unpacking, please ensure all the following components are present:

- MOPEDIA RP735 Walker Frame (pre-assembled with front wheels and rear legs)
- Padded Hand Grips (pre-installed)
- Non-slip Rubber Tips (pre-installed on rear legs)
- Instruction Manual (this document)

If any parts are missing or damaged, do not use the walker. Contact your retailer or MOPEDIA customer support immediately.

4. SETUP AND ASSEMBLY

4.1 Unfolding the Walker

1. Place the folded walker on a flat, stable surface.
2. Gently pull the sides of the walker outwards until the frame fully extends and locks into place. Ensure the locking mechanisms (if present) are engaged.
3. Verify that all four legs are firmly on the ground and the walker is stable before proceeding.

4.2 Adjusting Height

The walker's height is adjustable to suit individual user needs. Proper height adjustment is crucial for comfort and safety.

1. Locate the spring-loaded adjustment pins on each leg.
2. Press the pin inward and slide the leg extension up or down to the desired height.
3. Release the pin, ensuring it fully protrudes through one of the adjustment holes, locking the leg securely in place.
4. Repeat for all four legs, ensuring they are adjusted to the same height. The walker height can be adjusted from **82 cm to 99 cm** in 2.5 cm increments.
5. To check for proper height, stand upright with your arms relaxed at your sides. The top of the handgrips should align with your wrist crease. When gripping the handles, your elbows should have a slight bend (approximately 15-20 degrees).

5. OPERATING INSTRUCTIONS

The MOPEDIA RP735 walker is designed to provide support and stability during ambulation, primarily for indoor use.

- Positioning:** Stand behind the walker, gripping both padded handles firmly. Ensure your body is centered within the walker frame.
- Moving Forward:** Push the walker slightly forward, allowing the front wheels to roll. The rear legs with rubber tips will provide resistance and stability.
- Walking:** Step forward with one foot, then bring the other foot to meet it. Maintain a steady pace. Do not lean heavily on the walker; it is a support aid, not a device to bear full body weight.
- Turning:** To turn, gently pivot the walker in the desired direction while maintaining your grip and balance. Avoid sharp, sudden turns.
- Sitting Down:** Back up to a sturdy chair until the back of your legs touch the chair. Maintain a firm grip on the walker handles, then slowly lower yourself into the chair. Do not use the walker to pull yourself up or down.

Always maintain a slow, controlled movement. If you feel unsteady, stop and regain your balance before continuing.

6. MAINTENANCE AND CARE

Regular maintenance ensures the longevity and safe operation of your MOPEDIA RP735 walker.

- Cleaning:** Wipe the aluminum frame and padded handles with a damp cloth and mild soap. Do not use abrasive cleaners or solvents. Dry thoroughly after cleaning.
- Inspection:** Periodically check all screws, bolts, and pins to ensure they are tight and secure.
- Rubber Tips:** Inspect the non-slip rubber tips on the rear legs for wear, cracks, or flattening. Replace them immediately if damaged, as worn tips can compromise stability.
- Wheels:** Check the front wheels for smooth rotation and ensure they are free of debris. Clean any hair or lint that may accumulate around the wheel axles.
- Storage:** When not in use, fold the walker and store it in a dry, clean place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Walker feels unstable or wobbly.	Legs not adjusted to the same height; adjustment pins not fully engaged; loose connections; worn rubber tips.	Ensure all legs are at the same height and adjustment pins are locked. Check all screws and bolts for tightness. Inspect and replace worn rubber tips.
Front wheels do not roll smoothly.	Debris (hair, lint) caught in wheels; damaged wheels.	Clean any debris from around the wheel axles. If wheels are damaged, contact customer support for replacement.

Problem	Possible Cause	Solution
Walker does not fold or unfold easily.	Mechanism obstructed or stiff.	Check for any obstructions. Apply a silicone-based lubricant to moving parts if stiff, avoiding contact with handgrips or rubber tips.

If you encounter a problem not listed here or if the suggested solutions do not resolve the issue, please contact MOPEDIA customer support.

8. SPECIFICATIONS

Model:	RP735
Brand:	MOPEDIA
Material:	Anodized Aluminum, Rubber
Base Dimensions (L x W x H):	51.5 cm x 52.5 cm x 47/50 cm (approx. 20.3 in x 20.7 in x 18.5/19.7 in)
Adjustable Height:	82 cm - 99 cm (approx. 32.3 in - 39 in) in 2.5 cm increments
Product Weight:	2.6 kg (approx. 5.7 lbs)
Maximum User Weight:	130 kg (approx. 286 lbs)
Foldable:	Yes

9. WARRANTY AND SUPPORT

Specific warranty information for the MOPEDIA RP735 walker is not provided in this document. For details regarding warranty coverage, terms, and conditions, please refer to the documentation included with your purchase or contact your retailer.

For technical support, replacement parts, or any other inquiries, please contact MOPEDIA customer service through their official website or the contact information provided by your retailer.