

## THOMSON TM-AF0929

# Thomson TM-AF0929 Digital Air Fryer 3.5L User Manual

Model: TM-AF0929

## 1. INTRODUCTION

---

Thank you for choosing the Thomson TM-AF0929 Digital Air Fryer. This appliance is designed to cook your favorite foods with little to no oil, providing a healthier alternative to traditional frying. Its rapid air circulation system ensures even cooking and crispy results. Please read this manual thoroughly before first use to ensure safe and optimal operation of your air fryer.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

**WARNING: To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions.**

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Ensure adequate ventilation around the appliance during use.

### 3. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your Thomson Digital Air Fryer.



**Figure 3.1:** Thomson TM-AF0929 Digital Air Fryer with the food basket extended, displaying cooked french fries. This view highlights the main body, digital control panel, and the removable non-stick food basket.



**Figure 3.2:** Front view of the Thomson TM-AF0929 Digital Air Fryer, showcasing its sleek black design and the illuminated LCD touch screen control panel. The panel displays temperature, time, and various cooking presets.

### Key Components:

- **Main Unit:** Houses the heating element and fan for rapid air circulation.
- **Digital Control Panel:** LCD display with touch screen for setting temperature, time, and selecting cooking presets.

- **Non-Stick Food Basket:** Removable basket with a 3.5L capacity for holding food during cooking.
- **Handle:** Ergonomic handle for safely pulling out and inserting the food basket.
- **Air Outlet Vent:** Located at the back of the unit for hot air exhaust.

## 4. SETUP AND FIRST USE

---

1. **Unpacking:** Carefully remove the air fryer and all packaging materials. Keep packaging for future storage or disposal.
2. **Cleaning:** Before first use, clean the food basket and any removable parts with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the air fryer on a stable, heat-resistant surface, away from walls and other appliances to allow for proper air circulation. Ensure there is at least 10 cm (4 inches) of free space on the back and sides, and 10 cm (4 inches) above the appliance.
4. **Power Connection:** Plug the power cord into a grounded wall outlet.
5. **Initial Run (Optional but Recommended):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) to eliminate any manufacturing odors. A slight odor may be present, which is normal and will dissipate.

## 5. OPERATING INSTRUCTIONS

---

### Control Panel Overview:

The Thomson TM-AF0929 features an intuitive LCD display with touch controls.

- **Power Button:** Turns the appliance on/off and starts/pauses cooking.
- **Temperature Control (+/-):** Adjusts cooking temperature from 80°C to 200°C.
- **Timer Control (+/-):** Sets cooking time up to 30 minutes.
- **Menu Button (M):** Cycles through pre-set cooking programs (Hot keys).
- **Pre-set Icons:** Indicate various food types for quick selection.

### Basic Operation:

1. **Prepare Food:** Place your ingredients into the non-stick food basket. Do not overfill the basket; ensure there is enough space for air circulation.
2. **Insert Basket:** Slide the food basket firmly back into the main unit until it clicks into place.
3. **Power On:** Press the Power button to turn on the air fryer. The display will illuminate.
4. **Set Temperature and Time:**
  - Use the Temperature (+/-) buttons to set your desired cooking temperature (80°C - 200°C).
  - Use the Timer (+/-) buttons to set your desired cooking time (up to 30 minutes).
5. **Use Pre-set Programs (Optional):** Press the Menu (M) button to cycle through the pre-set cooking programs. Once a program is selected, the air fryer will automatically set the recommended temperature and time. You can adjust these manually if needed.
6. **Start Cooking:** Press the Power button again to start the cooking process. The fan and heating element will activate.
7. **Shake/Turn Food (Mid-Cycle):** For even cooking, especially with items like fries or chicken wings, it is recommended to shake or turn the food halfway through the cooking time. Pull out the basket, shake/turn, and

reinsert. The air fryer will automatically resume cooking.

- 8. **Cooking Completion:** The air fryer will emit an "Auto Ready sound prompt" when the set cooking time has elapsed. The display will show "OFF" or similar.
- 9. **Remove Food:** Carefully pull out the food basket using the handle. Use heat-resistant tongs to remove the cooked food.

**Note:** Cooking times and temperatures may vary based on food quantity, density, and desired crispiness. Refer to general air frying guidelines for specific recipes.

## 6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your air fryer.

- 1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
- 2. **Clean Food Basket:** The non-stick food basket can be washed with warm water and a mild dishwashing detergent. Use a non-abrasive sponge or cloth. For stubborn residue, soak the basket in warm soapy water for 10-15 minutes. The basket is generally dishwasher safe, but hand washing is recommended to preserve the non-stick coating.
- 3. **Clean Interior:** Wipe the interior of the air fryer with a damp cloth. Do not use abrasive cleaners or steel wool.
- 4. **Clean Exterior:** Wipe the exterior of the air fryer with a soft, damp cloth.
- 5. **Heating Element:** If necessary, gently clean the heating element with a soft brush to remove any food residue. Ensure the appliance is completely cool and unplugged.
- 6. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

**CAUTION:** Never immerse the main unit of the air fryer in water or any other liquid.

## 7. TROUBLESHOOTING

If you encounter issues with your air fryer, consult the following table before contacting customer support.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; Power outlet malfunction; Basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Check if the food basket is fully pushed into the main unit.
Food is not cooked evenly.	Basket is overfilled; Food not shaken/turned.	Do not overfill the basket. Shake or turn food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; Fatty ingredients.	Clean the food basket and interior thoroughly after each use. For fatty foods, add a small amount of water to the bottom of the drawer to prevent smoke.
Food is not crispy.	Too much moisture; Not enough oil (for certain foods); Incorrect temperature/time.	Pat food dry before air frying. Lightly coat some foods with oil. Adjust temperature or cooking time as needed.






## 8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model	TM-AF0929
Brand	THOMSON
Capacity	3.5 Liters
Power	1500 Watts
Voltage	240 Volts
Temperature Control	80°C to 200°C
Timer	Up to 30 minutes
Control Method	Touch (LCD Display)
Special Features	Programmable, Rapid circulation system, Cooking menu system with Hot keys, Auto Ready sound prompt
Material	Aluminium, Plastic
Color	Black
Dimensions (Package)	36 x 33.5 x 33.5 cm
Weight (Package)	5.52 kg

## 9. WARRANTY AND SUPPORT

This Thomson TM-AF0929 Digital Air Fryer comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details. For technical support, service, or warranty claims, please contact Thomson customer service through their official website or the contact information provided in your product documentation. Ensure you have your model number (TM-AF0929) and proof of purchase ready when contacting support. For more information, you may visit the official Thomson website or contact your local distributor.

	<p><a href="#">Thomson Go Plus Pro Bruksanvisning</a></p> <p>Lär dig installera, konfigurera och använda din Thomson Go Plus Pro smarta display med denna omfattande användarmanual. Innehåller säkerhetsinformation, installationsanvisningar, knappfunktioner, inställningar och felsökning.</p>
	<p><a href="#">Thomson Smart TV ar Google TV: Lietotāja rokasgrāmata</a></p> <p>Šī visaptverošā lietotāja rokasgrāmata sniedz būtisku informāciju jūsu jaunā Thomson Smart TV ar Google TV uzstādīšanai un lietošanai. Tā aptver visu, sākot no sākotnējās instalācijas un savienojumiem līdz funkciju, iestatījumu un problēmu novēršanas izpētei.</p>
	<p><a href="#">Thomson Go Plus Pro: Navodila za uporabo in nastavitve</a></p> <p>Podroben uporabniški priročnik za Thomson Go Plus Pro pametni zaslon, ki zajema namestitev, nastavitve, uporabo funkcij, systemske nastavitve in odpravljanje težav.</p>
	<p><a href="#">Thomson Go Plus Pro - Uživatelská příručka</a></p> <p>Uživatelská příručka pro Thomson Go Plus Pro. Získejte podrobné pokyny k instalaci, nastavení, ovládání, bezpečnosti, řešení problémů a technickým specifikacím tohoto inteligentního displeje Thomson.</p>
	<p><a href="#">Thomson Go Plus Käyttöohje</a></p> <p>Tämä käyttöohje tarjoaa kattavat tiedot Thomson Go Plus -laitteen asentamisesta, käytöstä ja turvallisuusohjeista. Opi yhdistämään laitteesi, säätämään asetuksia ja käyttämään sen ominaisuuksia.</p>

**THOMSON**

Thomson Go Plus Pro



[Thomson Go Plus Pro Gebruikershandleiding: Installatie, Instellingen en Probleemoplossing](#)

Gedetailleerde gebruikershandleiding voor de Thomson Go Plus Pro smart display, inclusief installatie-instructies, bedieningsgids, instellingenmenu's en probleemoplossing.