

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Sencor](#) /
- › [Sencor SRC 136 WH Digital Clock Radio User Manual](#)

Sencor SRC 136 WH

Sencor SRC 136 WH Digital Clock Radio User Manual

Comprehensive instructions for setup, operation, and maintenance.

1. PRODUCT OVERVIEW



This image shows the Sencor SRC 136 WH Digital Clock Radio. The device features a black top panel with control buttons for volume, tuning, alarm, snooze, and function. The front panel displays the time in white LED digits. The side casing is white.

Key Features

- Digital LED Display for time and status indicators.
- FM/PLL Radio Tuner for clear reception.
- Dual Alarm Functionality (Alarm 1 and Alarm 2).
- Snooze Function for temporary alarm pause.
- Sleep Timer for automatic radio shutdown.
- Dimmer Function for display brightness adjustment.

Package Contents

- Sencor SRC 136 WH Digital Clock Radio Unit
- Power Adapter
- User Manual (this document)

2. CONTROLS AND DISPLAY

Front Display Indicators

- **PM:** Indicates PM time in 12-hour format.
- **AL1:** Indicates Alarm 1 is active.
- **AL2:** Indicates Alarm 2 is active.
- **SLEEP:** Indicates Sleep Timer is active.

Top Panel Buttons

Button	Function
MEMORY / THE SET	Save radio stations / Enter time/alarm setting mode.
VOL- / ALT	Decrease volume / Set Alarm 1.
VOL+ / ALR	Increase volume / Set Alarm 2.
TUNING- / HOUR	Tune radio frequency down / Adjust hour in setting mode.
TUNING+ / MINUTE	Tune radio frequency up / Adjust minute in setting mode.
SNOOZE / DIMMER / SLEEP	Activate snooze / Adjust display brightness / Activate sleep timer.
FUNCTION	Switch between radio and time display / Confirm settings.

3. INITIAL SETUP

3.1 Power Connection

1. Connect the power adapter to the DC IN jack on the back of the unit.
2. Plug the power adapter into a standard wall outlet. The display will light up.

3.2 Battery Backup Installation

The unit requires 2 x AA batteries (not included) for time and alarm settings backup during a power outage.

1. Open the battery compartment cover on the bottom of the unit.
2. Insert 2 x AA batteries, observing the correct polarity (+/-).
3. Close the battery compartment cover securely.

3.3 Setting the Time

1. In standby mode, press and hold the **MEMORY / THE SET** button. The hour digits will flash.
2. Use the **TUNING- / HOUR** and **TUNING+ / MINUTE** buttons to adjust the hour.
3. Press **MEMORY / THE SET** again. The minute digits will flash.
4. Use the **TUNING- / HOUR** and **TUNING+ / MINUTE** buttons to adjust the minutes.
5. Press **MEMORY / THE SET** or wait a few seconds for the setting to be saved.

4. OPERATING INSTRUCTIONS

4.1 Radio Operation (FM/PLL)

1. Press the **FUNCTION** button to switch to FM radio mode. The frequency will be displayed.
2. Use the **TUNING- / HOUR** and **TUNING+ / MINUTE** buttons to manually tune to a desired frequency.
3. To auto-scan and save stations: Press and hold **MEMORY / THE SET**. The radio will scan and store available stations.
4. To recall saved stations: Briefly press **MEMORY / THE SET** repeatedly to cycle through saved presets.
5. Adjust volume using the **VOL- / ALT** and **VOL+ / ALR** buttons.

4.2 Setting Alarms (Alarm 1 / Alarm 2)

1. Press and hold **VOL- / ALT** for Alarm 1 or **VOL+ / ALR** for Alarm 2. The alarm hour will flash.
2. Use **TUNING- / HOUR** and **TUNING+ / MINUTE** to set the desired alarm hour.
3. Press the respective alarm button again (**VOL- / ALT** or **VOL+ / ALR**). The alarm minute will flash.
4. Use **TUNING- / HOUR** and **TUNING+ / MINUTE** to set the desired alarm minute.
5. Press the respective alarm button again to select the alarm source (Buzzer or Radio).
6. Press the respective alarm button one more time or wait for a few seconds to confirm and activate the alarm. The AL1 or AL2 indicator will appear on the display.

4.3 Snooze Function

When the alarm sounds, press the **SNOOZE / DIMMER / SLEEP** button to temporarily silence the alarm for approximately 9 minutes. The alarm will sound again after this period.

4.4 Sleep Timer Function

1. While the radio is playing, press the **SNOOZE / DIMMER / SLEEP** button repeatedly to cycle through sleep timer options (e.g., 90, 60, 30, 15 minutes, OFF).
2. The radio will automatically turn off after the selected duration. The SLEEP indicator will be lit.

4.5 Dimmer Function

In standby mode, briefly press the **SNOOZE / DIMMER / SLEEP** button to adjust the brightness of the LED display (High, Low, Off).

5. CARE AND MAINTENANCE

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** If not in use for an extended period, disconnect from power and remove backup batteries. Store in a cool, dry place.
- **Battery Replacement:** Replace backup batteries annually or when the display shows signs of fading during power outages.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power / Display off	Power adapter not connected or faulty.	Ensure power adapter is securely plugged into the unit and a working wall outlet.
Poor radio reception / Static	Antenna not extended or poor signal.	Extend the FM wire antenna fully. Reposition the unit for better reception.
Alarm does not sound	Alarm not activated or set incorrectly.	Verify AL1/AL2 indicator is lit. Recheck alarm time and source settings.
Time/settings lost after power outage	Backup batteries are dead or not installed.	Install new AA batteries in the battery compartment.

7. TECHNICAL SPECIFICATIONS





Feature	Specification
Model Number	SRC 136 WH
Power Consumption	3.5 Watts
Backup Battery Voltage	1.5 Volts (for AA batteries)
Dimensions (L x W x H)	13 x 12.4 x 4.6 cm
Weight	360 Grams
Display Type	Digital LED
Power Source	AC Power Adapter (with AA battery backup)
Color	White

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Sencor website. Keep your purchase receipt as proof of purchase.

For further assistance, you may contact Sencor customer service through their official channels.

Related Documents - SRC 136 WH

 <p>EN * User Manual CZ * Uživatelská příručka SK * Používateľská príručka HU * Felhasználói kézikönyv PL * Podręcznik użytkownika LT * Naudojimo vadovas</p> <p>ALARM RADIO CLOCK RADIOCLOCK RADIOCLOCK RADIOCLOCK RADIOCLOCK RADIOCLOCK RADIOCLOCK</p>	<p>Sencor SRC 136 Alarm Radio Clock User Manual</p> <p>User manual for the Sencor SRC 136 alarm radio clock, providing instructions on setup, operation, alarm settings, FM radio functions, and technical specifications.</p>
 <p>EN * User Manual CZ * Uživatelská příručka SK * Používateľská príručka HU * Felhasználói kézikönyv PL * Podręcznik użytkownika LT * Naudojimo vadovas</p> <p>ALARM RADIO CLOCK RADIOCLOCK RADIOCLOCK RADIOCLOCK RADIOCLOCK RADIOCLOCK RADIOCLOCK</p>	<p>SENCOR SRC 136 Alarm Radio Clock User Manual</p> <p>User manual for the SENCOR SRC 136 Alarm Radio Clock. This guide provides instructions on setup, operation, features, and specifications for the SRC 136 model.</p>
	<p>SENCOR SRC 3100 B Projection Alarm Clock Radio User Manual</p> <p>Comprehensive user manual for the SENCOR SRC 3100 B Projection Alarm Clock Radio. Learn how to set the time and alarms, operate the radio, use the projection feature, and understand specifications and warranty information.</p>
	<p>Sencor SRC 1100 W LED Alarm Clock Radio User Manual</p> <p>This user manual provides instructions for the Sencor SRC 1100 W LED Alarm Clock Radio, covering setup, operation, alarm settings, radio functions, and troubleshooting.</p>
 <p>EN * User Manual CZ * Uživatelská příručka SK * Používateľská príručka HU * Felhasználói kézikönyv PL * Podręcznik użytkownika</p> <p>Digital Alarm Clock with Thermometer Digitalni budilnik s toplomerom Digitalni budilnik s toplomerom Digitalni budilnik s toplomerom Digitalni budilnik s toplomerom Digitalni budilnik s toplomerom Digitalni budilnik s toplomerom</p>	<p>Návod na použitie SENCOR SDC 2200: Digitálny budík s teplomerom</p> <p>Komplexný návod na použitie digitálneho budíka s teplomerom SENCOR SDC 2200. Získajte informácie o funkciách, nastavení, špecifikáciách a bezpečnostných pokynoch.</p>
 <p>EN * User Manual CZ * Uživatelská příručka SK * Používateľská príručka HU * Felhasználói kézikönyv PL * Podręcznik użytkownika</p> <p>Digital Alarm Clock with Thermometer Digitalni budilnik s toplomerom Digitalni budilnik s toplomerom Digitalni budilnik s toplomerom Digitalni budilnik s toplomerom Digitalni budilnik s toplomerom Digitalni budilnik s toplomerom</p>	<p>SENCOR SDC 2200: Instrukcja Obsługi Cyfrowego Zegara z Budzikiem i Termometrem</p> <p>Niniejsza instrukcja obsługi dla cyfrowego zegara z budzikiem i termometrem SENCOR SDC 2200 zawiera szczegółowe informacje o funkcjach, ustawieniach, bezpieczeństwie i użyciu urządzenia.</p>