



[Manuals.plus](#) /

> [HP](#) /

> HP LaserJet Enterprise Flow MFP M527c User Manual

HP F2A81A#BGJ

HP LaserJet Enterprise Flow MFP M527c (F2A81A) User Manual

Comprehensive Guide for Setup, Operation, and Maintenance

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your HP LaserJet Enterprise Flow MFP M527c. Designed for efficiency and security, this multifunction printer (MFP) offers printing, copying, and scanning capabilities. Please read this guide thoroughly to ensure optimal performance and longevity of your device.

1. SETUP AND INSTALLATION

1.1 Unpacking the Device

Carefully remove the MFP from its packaging. Ensure all packing materials, tapes, and protective films are removed from the exterior and interior of the device. Retain packaging for future transport if necessary.

1.2 Component Overview



Figure 1: Front view of the HP LaserJet Enterprise Flow MFP M527c. This image displays the main unit, the integrated control panel, the automatic document feeder (ADF) on top, and the paper input trays labeled '1' and '2' at the bottom. The HP logo and 'LaserJet Enterprise MFP M527' text are visible on the front panel.

- **Automatic Document Feeder (ADF):** Located on top, for scanning and copying multiple pages.
- **Control Panel:** Interactive touchscreen display for managing device functions.
- **Output Tray:** Where printed pages are collected.
- **Paper Trays (1 & 2):** For loading various paper sizes and types.
- **USB Port:** For direct printing or scanning to/from a USB storage device.

1.3 Connecting Power and Network

1. Connect the power cord to the MFP and then to a grounded electrical outlet.
2. For network connectivity, connect an Ethernet cable from the MFP's Ethernet port to your network router or switch.

3. Alternatively, for direct USB connection, use a USB 2.0 cable to connect the MFP to your computer.

1.4 Loading Paper

Open the desired paper tray (Tray 1 or Tray 2). Adjust the paper guides to fit the paper size. Load the paper stack, ensuring it is flat and within the maximum fill line. Close the tray securely.

2. OPERATING THE DEVICE

2.1 Control Panel Overview



Figure 2: Detailed view of the HP LaserJet Enterprise Flow MFP M527c's touchscreen control panel. The screen displays options such as 'Copy', 'E-mail', 'Save to USB', 'Save to Device Memory', and 'Retrieve from Device Memory', indicating various functions available to the user.

The intuitive touchscreen control panel allows you to access all functions of the MFP. Navigate through menus by tapping icons and swiping. The 'Home' button (house icon) always returns you to the main screen.

2.2 Printing Documents

- **From a Computer:** Install the necessary print drivers from the HP website. Select the HP LaserJet Enterprise Flow MFP M527c as your printer from your application's print dialog. Adjust settings as needed and click 'Print'.
- **From Mobile Devices:** The MFP supports printing from various smartphones and tablets. Ensure your device is connected to the same network as the MFP, or use optional 128-bit encrypted wireless direct printing.
- **Duplex Printing:** This model supports automatic two-sided (duplex) printing. Select the duplex option in your print settings to save paper.

2.3 Copying Documents

1. Place the original document face-up in the Automatic Document Feeder (ADF) or face-down on the scanner glass.
2. On the control panel, tap the 'Copy' icon.
3. Adjust settings such as number of copies, lightness/darkness, and paper size.
4. Tap 'Start' to begin copying.

2.4 Scanning Documents

- **Scan to Email:** Place your document, tap 'E-mail' on the control panel, enter recipient details, and send.
- **Scan to USB:** Insert a USB storage device into the designated port. Tap 'Save to USB' on the control panel, select scan settings, and save the file.
- **Scan to Device Memory:** Tap 'Save to Device Memory' to store scanned jobs directly on the MFP for later retrieval.

3. MAINTENANCE

3.1 Cleaning the Device

- **Exterior:** Use a soft, lint-free cloth dampened with water to clean the exterior surfaces. Avoid abrasive cleaners.
- **Scanner Glass:** Gently wipe the scanner glass with a soft cloth and a non-abrasive glass cleaner.
- **ADF Rollers:** Refer to the online support documentation for detailed instructions on cleaning the ADF rollers to prevent paper feed issues.

3.2 Replacing Toner Cartridges

The MFP will display a message when a toner cartridge is low or empty. Always use genuine HP toner cartridges for optimal performance. Open the toner access door, remove the old cartridge, unpackage the new one, shake it gently, and insert it until it clicks into place. Close the door.

3.3 Firmware Updates

Periodically check the HP support website for firmware updates. Updating the firmware can improve performance, add new features, and enhance security. Follow the instructions provided with the firmware download carefully.

4. TROUBLESHOOTING

4.1 Common Issues and Solutions

- **Paper Jams:** Follow the on-screen instructions or refer to the internal diagrams to locate and carefully remove any jammed paper. Ensure paper is loaded correctly.
- **Connectivity Problems:** Verify network cable connections, check Wi-Fi settings (if applicable), and ensure the MFP

has a valid IP address. Restarting the MFP and router can often resolve temporary issues.

- **Print Quality Issues:** If prints are faded or streaky, check toner levels. Perform a print quality diagnostic from the control panel to identify and resolve issues.
- **Error Messages:** Consult the HP support website or the MFP's internal help system for specific error code explanations and resolutions.

5. SPECIFICATIONS

Feature	Detail
Model Name	HP LaserJet Enterprise Flow MFP M527c
Model Number	F2A81A#BGJ
Functions	Print, Copy, Scan (All-in-One)
Printing Technology	Laser (Monochrome)
Print Speed (Monochrome)	Up to 45 ppm (pages per minute)
First Page Out Time	As fast as 8.5 seconds
Print Resolution	Up to 600 x 600 dpi
Duplex Printing	Automatic
Scanner Type	ADF, Flatbed
Max Copy Speed (B&W)	45 ppm
Max Input Sheet Capacity	250 sheets (standard tray)
Connectivity	USB 2.0, Ethernet (Network-Ready)
Control Method	App, Touchscreen Control Panel
Product Dimensions (W x D x H)	23 x 28 x 24 inches
Item Weight	60 pounds

6. WARRANTY AND SUPPORT

6.1 Warranty Information

This HP LaserJet Enterprise Flow MFP M527c comes with a limited warranty. Please refer to the warranty documentation included with your product or visit the official HP support website for detailed terms and conditions, including warranty duration and coverage.

6.2 Customer Support

For technical assistance, driver downloads, or further information, please visit the official HP support website. You can also find FAQs, troubleshooting guides, and contact options for HP customer service there.

HP Support Website: www.hp.com/support



© 2024 HP Inc. All rights reserved. Information in this document is subject to change without notice.