

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KLEIN TOOLS](#) /

› [Klein Tools CL110KIT 400 Amp True RMS AC Auto-Ranging Digital Clamp Meter Electrical Maintenance and Test Kit User Manual](#)

KLEIN TOOLS CL110KIT

Klein Tools CL110KIT Electrical Maintenance and Test Kit User Manual

Model: CL110KIT

1. INTRODUCTION AND KIT OVERVIEW

The Klein Tools CL110KIT is a comprehensive electrical maintenance and test kit designed for professionals and DIY enthusiasts. This kit provides essential tools for measuring AC current, AC/DC voltage, resistance, and continuity, as well as testing GFCI receptacles and safely measuring current draw. The kit includes the CL110 400A Auto-Ranging Digital Clamp Meter, the RT210 GFCI Receptacle Tester, and the 69409 Line Splitter 10x.

Key Features:

- **CL110 400A Auto-Ranging Digital Clamp Meter:** Measures AC current via the clamp, and AC/DC voltage, resistance, and continuity via test leads. Features a backlit display for clear readings.
- **RT210 GFCI Receptacle Tester:** Detects common wiring problems in standard and GFCI receptacles, including open ground, reverse polarity, open hot, open neutral, and hot/ground reversed.
- **69409 Line Splitter 10x:** Allows for measuring current draw up to 15A without splitting the load's power cord, providing a 10x amplified reading for precise measurement with the clamp meter.

**KLEIN
TOOLS** 

Since 1857

AUTO-RANGING

600V \approx
400A \approx
20M Ω

**CAT III
600V**



Figure 1.1: The Klein Tools CL110KIT, showcasing the CL110 Clamp Meter, RT210 GFCI Receptacle Tester, and 69409 Line Splitter.

2. SAFETY INFORMATION

WARNING: To ensure safe operation, always read, understand, and follow all instructions, cautions, and warnings provided with this kit and all test and measurement devices before each use. Failure to do so may result in serious injury or death.

- Do not attempt to measure resistance or continuity on live circuits.
- Before each use, verify meter operation by measuring a known voltage or current.
- Do not use the meter during electrical storms or in wet weather.
- Do not use the meter or test leads if they appear to be damaged.
- Always wear appropriate personal protective equipment (PPE) when working with electrical circuits.
- The CL110 Clamp Meter is rated for CAT III 600V. Ensure your application falls within these safety ratings.

3. SETUP

3.1 Battery Installation (CL110 Clamp Meter)

The CL110 Clamp Meter requires three (3) AAA batteries (included). To install or replace batteries:

1. Ensure the meter is turned OFF and disconnect all test leads from the meter and any circuit.
2. Locate the battery compartment cover on the back of the meter.
3. Use a screwdriver to loosen the screw securing the battery compartment cover.
4. Remove the cover and insert the AAA batteries, observing correct polarity (+/-).
5. Replace the battery compartment cover and tighten the screw securely.



Figure 3.1: Back view of the CL110 Clamp Meter, indicating the battery compartment location.

3.2 Connecting Test Leads (CL110 Clamp Meter)

For voltage, resistance, and continuity measurements, connect the included test leads to the meter:

1. Insert the black test lead into the 'COM' (common) jack.
2. Insert the red test lead into the 'VΩ' (voltage/resistance) jack.
3. Ensure the leads are fully seated in the jacks before use.



Figure 3.2: Side view of the CL110 Clamp Meter, highlighting the test lead input jacks.

4. OPERATING INSTRUCTIONS

4.1 Using the CL110 400A Auto-Ranging Digital Clamp Meter

The CL110 is an auto-ranging meter, simplifying measurements by automatically selecting the correct range for most functions.

To Measure AC Current (via Clamp):

1. Turn the rotary dial to the 'A~' (AC Current) setting.
2. Open the clamp jaws by pressing the trigger.
3. Encircle a single conductor (not a power cord with multiple conductors) with the clamp jaws. Ensure the jaws are fully closed.
4. Read the AC current value on the backlit display.



Figure 4.1: The CL110 Clamp Meter in use, measuring current on a single conductor.

To Measure AC/DC Voltage, Resistance, or Continuity (via Test Leads):

1. Connect the test leads as described in Section 3.2.
2. Turn the rotary dial to the desired function: 'V~' for AC Voltage, 'V=' for DC Voltage, 'Ω' for Resistance, or '∩' for Continuity.
3. Carefully touch the test probes to the circuit points you wish to measure.
4. Read the measurement on the backlit display. For continuity, an audible tone indicates a continuous circuit.

4.2 Using the RT210 GFCI Receptacle Tester

The RT210 GFCI Receptacle Tester quickly identifies common wiring faults in 120V AC outlets.

1. Plug the RT210 directly into the 120V AC receptacle.

2. Observe the indicator lights on the tester. Refer to the legend on the tester for the meaning of different light patterns (e.g., Open Ground, Reverse Polarity, Correct Wiring).
3. To test a GFCI receptacle, press the 'PUSH TO TEST GFCI' button. A working GFCI should trip, cutting power to the outlet. Reset the GFCI after testing.



Figure 4.2: The RT210 GFCI Receptacle Tester indicating wiring status in an outlet.

4.3 Using the 69409 Line Splitter 10x

The 69409 Line Splitter allows for safe and convenient measurement of AC current draw for appliances up to 15A without needing to separate the conductors of a power cord.

1. Plug the appliance's power cord into the Line Splitter.
2. Plug the Line Splitter into a 120V AC wall outlet.
3. Turn the CL110 Clamp Meter to the 'A~' (AC Current) setting.
4. Clamp the CL110 around the '10x' loop on the Line Splitter. This loop amplifies the current by a factor of 10, providing a more precise reading for low current draws.
5. Turn on the appliance and read the value on the CL110 display. Divide this reading by 10 to get the actual current draw of the appliance.
6. For direct (1x) current measurement, clamp the CL110 around the '1x' loop.

5. MAINTENANCE

5.1 Cleaning

Wipe the meter and accessories with a clean, dry, lint-free cloth. Do not use abrasive cleaners or solvents. Ensure the devices are dry before storage or use.

5.2 Battery Replacement (CL110 Clamp Meter)

Replace the batteries when the low battery indicator appears on the display. Refer to Section 3.1 for battery installation instructions. Always use fresh AAA alkaline batteries.

5.3 Storage

When not in use, store the kit components in the included carrying pouch in a cool, dry place, away from direct sunlight and extreme temperatures. If storing for extended periods, remove the batteries from the CL110 Clamp Meter to prevent leakage.

6. TROUBLESHOOTING

- **Meter does not power on:** Check battery installation and ensure batteries are fresh.
- **No reading or 'OL' (Overload) displayed:** Ensure test leads are properly connected and the rotary dial is set to the correct function. For current measurements, ensure the clamp is fully closed around a single conductor. If 'OL' persists, the measured value may exceed the meter's range.
- **Inaccurate readings:** Verify meter operation with a known voltage or current source. Check for damaged test leads or dirty connections.
- **GFCI Tester shows incorrect wiring:** Consult a qualified electrician to inspect and correct the wiring of the receptacle.
- **GFCI Tester does not trip GFCI:** The GFCI receptacle may be faulty or improperly wired. Consult a qualified electrician.

7. SPECIFICATIONS

Feature	Specification
Brand	KLEIN TOOLS
Model Number	CL110KIT
Measurement Type	Multimeter (Clamp Meter)
AC Current Range	400 Amp (Auto-Ranging)
AC/DC Voltage	Yes
Resistance	Yes
Continuity	Yes
Safety Rating	CAT III 600V

Feature	Specification
Display	Backlit Digital Display
Power Source	3 x AAA Batteries (included)
Item Weight	15 Ounces
Product Dimensions	11.8 x 5.4 x 2.1 inches
Material	Plastic
Included Components	CL110 Clamp Meter, RT210 GFCI Receptacle Tester, 69409 Line Splitter 10x, Test Leads, Batteries, Carrying Case

8. PRODUCT VIDEO OVERVIEW

Your browser does not support the video tag.

Video 8.1: An overview of Klein Tools Test & Measurement products, highlighting features such as durable design, comfortable handling, large backlit displays, and compliance with safety requirements. This video provides general information about the quality and design of Klein Tools meters.

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official Klein Tools website. Keep your purchase receipt as proof of purchase for any warranty claims.