

[Manuals.plus](#) /

> [Henny Penny](#) /

> Henny Penny EF02-104 Fuse Holder Instruction Manual

Henny Penny HENEF02-104

Henny Penny EF02-104 Fuse Holder Instruction Manual

Model: HENEF02-104

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of the Henny Penny EF02-104 Fuse Holder. This component is designed to safely house a 250 Volt, 20 Amp fuse, protecting electrical circuits in various applications, particularly within food service equipment. Adherence to these instructions is crucial for safe and effective use.



Figure 1: The Henny Penny EF02-104 Fuse Holder, shown with its main body and the removable fuse carrier. The main body is black with metal mounting clips, and the carrier is light gray.

SETUP AND INSTALLATION

Installation of the Henny Penny EF02-104 Fuse Holder should only be performed by qualified personnel in accordance with all local and national electrical codes. Ensure power to the circuit is disconnected before beginning installation.

1. **Power Disconnection:** Verify that the main power supply to the equipment or circuit where the fuse holder will be installed is completely turned off and locked out.
2. **Mounting:** The fuse holder is designed for panel mounting. Create an appropriately sized hole in the panel. Insert the fuse holder body through the hole and secure it using the integrated mounting clips or a retaining nut (if supplied).
3. **Wiring:** Connect the electrical wires to the terminals of the fuse holder. Ensure connections are secure and properly insulated. This fuse holder is rated for 250 Volts and 20 Amps.
4. **Fuse Insertion:** Before restoring power, insert the correct type and rating of fuse (250V, 20A) into the removable fuse carrier. Align the carrier with the fuse holder body and push it firmly into place until it clicks or is fully seated.



Figure 2: The fuse holder assembly, showing the main body and the fuse carrier. The carrier is designed to be inserted into the main body to complete the circuit.

OPERATING INSTRUCTIONS

The Henny Penny EF02-104 Fuse Holder functions as a protective device for electrical circuits. Once properly

installed with a compatible fuse, it requires no active "operation" beyond ensuring the fuse is correctly seated.

- **Circuit Protection:** The fuse holder's primary function is to hold a fuse that will interrupt the electrical circuit if an overcurrent condition occurs, preventing damage to equipment.
- **Fuse Replacement:** If a fuse blows (indicating an overcurrent event), the fuse holder allows for easy replacement. Always disconnect power before attempting to remove or insert a fuse.

MAINTENANCE

Regular inspection of the fuse holder can help ensure continued reliable operation.

- **Visual Inspection:** Periodically inspect the fuse holder for any signs of physical damage, discoloration, or loose connections.
- **Cleaning:** If necessary, gently clean the exterior of the fuse holder with a dry, lint-free cloth. Do not use abrasive cleaners or solvents. Ensure power is disconnected before cleaning.
- **Fuse Integrity:** If the fuse holder has been subjected to an overcurrent event, inspect the fuse for breakage. Replace blown fuses with new fuses of the exact same type and rating (250V, 20A).

TROUBLESHOOTING

The primary issue associated with a fuse holder is a blown fuse. If the circuit protected by the fuse holder is not functioning, follow these steps:

1. **Disconnect Power:** Always turn off and lock out the power supply to the circuit before inspecting or replacing the fuse.
2. **Inspect Fuse:** Carefully remove the fuse carrier and inspect the fuse. A blown fuse will typically show a broken filament or discoloration.
3. **Identify Cause:** A blown fuse indicates an overcurrent condition. Before replacing the fuse, investigate and resolve the underlying cause of the overcurrent (e.g., short circuit, overloaded component, faulty wiring). Replacing a fuse without addressing the root cause will likely result in another blown fuse.
4. **Replace Fuse:** Insert a new fuse of the correct rating (250V, 20A) into the carrier and reinsert the carrier into the fuse holder.
5. **Restore Power:** Once the fuse is replaced and the cause of the overcurrent is resolved, restore power to the circuit.

If the fuse holder itself appears damaged (e.g., cracked housing, corroded terminals), it should be replaced immediately by a qualified technician.

SPECIFICATIONS

Attribute	Value
Product Type	Food Service Supply
Model Number	HENEF02-104
Brand	Henny Penny
Voltage Rating	250 Volts
Current Rating	20 Amps

Attribute	Value
Product Dimensions (L x W x H)	1 x 1 x 1 inches
Weight	0.32 ounces
Country of Origin	Mexico
ASIN	B01858YOYG

WARRANTY INFORMATION

Specific warranty details for the Henny Penny EF02-104 Fuse Holder are not provided in this document. For warranty information, please refer to the documentation supplied with your original equipment or contact Henny Penny directly.

SUPPORT AND CONTACT

For technical assistance, replacement parts, or further inquiries regarding the Henny Penny EF02-104 Fuse Holder, please contact Henny Penny customer support or your authorized distributor. Contact information can typically be found on the manufacturer's official website or within the main equipment manual.