

acer KA240H

Acer KA240H 24-inch Full HD Monitor User Manual

Model: KA240H (UM.FX0EE.005)

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Acer KA240H 24-inch Full HD Monitor. Please read this manual thoroughly before operating your monitor and retain it for future reference. This monitor is designed for general computing tasks, offering a 1920x1080 resolution display.

SAFETY INFORMATION

- Always place the monitor on a stable, flat surface to prevent it from falling.
- Do not block ventilation openings. Ensure adequate space around the monitor for proper airflow.
- Use only the power adapter and cables supplied with the monitor or specified by Acer.
- Keep the monitor away from water, moisture, and extreme temperatures.
- If smoke, strange noises, or unusual odors occur, immediately unplug the monitor and contact qualified service personnel.
- Do not attempt to service the monitor yourself. Refer all servicing to qualified service personnel.

PACKAGE CONTENTS

Verify that all items are present and in good condition upon unpacking. If any items are missing or damaged, contact your retailer.

- Acer KA240H Monitor Display Panel
- Monitor Stand Base
- Monitor Stand Neck
- Power Cord
- HDMI Cable (may vary by region)
- User Manual (this document)

SETUP

1. Assembling the Monitor Stand

1. Carefully place the monitor display panel face down on a soft, clean cloth to prevent scratches.
2. Attach the stand neck to the monitor display panel by aligning the tabs and pushing until it clicks into place.
3. Attach the stand base to the stand neck. Secure it with the captive screw located on the underside of the base.



Figure 1: Side view of the Acer KA240H monitor, illustrating the assembled stand and display panel.

2. Connecting Cables

Ensure the monitor and your computer are powered off before making any connections.

- **Power Connection:** Connect the power cord to the monitor's power input and then to a grounded electrical outlet.
- **Video Connection:**
 - **HDMI:** Connect one end of the HDMI cable to the HDMI port on your monitor and the other end to the HDMI port on your computer.
 - **VGA:** Connect one end of the VGA cable to the VGA port on your monitor and the other end to the VGA port on your computer. Tighten the screws on the VGA connector.
 - **DVI:** Connect one end of the DVI cable to the DVI port on your monitor and the other end to the DVI port on your computer.

Note: The monitor supports HDMI, VGA, and DVI inputs. Use only one video connection at a time.



Figure 2: Rear view of the Acer KA240H monitor, highlighting the various input ports for power and video connections.

3. Initial Power On

After connecting all cables, power on your computer, then press the power button on the monitor. The monitor should automatically detect the input signal. If no image appears, refer to the Troubleshooting section.

OPERATING THE MONITOR

Power Button and OSD Controls

The power button and On-Screen Display (OSD) control buttons are typically located on the bottom right bezel of the monitor. Refer to the diagram below for button identification.



Figure 3: Front view of the Acer KA240H monitor, showing the location of the power button and OSD controls on the bottom right bezel.

- **Power On/Off:** Press the power button to turn the monitor on or off.
- **OSD Menu:** Press any OSD button (usually indicated by icons) to bring up the On-Screen Display menu.
- **Navigation:** Use the arrow buttons to navigate through menu options.
- **Selection:** Press the 'Menu' or 'Enter' button to select an option or confirm a setting.
- **Exit:** Press the 'Exit' button to close the OSD menu.

Common OSD Settings

- **Picture:** Adjust brightness, contrast, sharpness, and color temperature.
- **Color:** Fine-tune color settings, including gamma and color space.
- **Input:** Manually select the input source (HDMI, VGA, DVI) if auto-detection fails.
- **OSD:** Adjust OSD language, transparency, and timeout.
- **Management:** Access information about the monitor, reset settings to factory defaults.

MAINTENANCE

Cleaning the Monitor

- Always unplug the monitor from the power outlet before cleaning.
- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a specialized screen cleaner. Do not spray cleaner directly onto the screen.
- **Exterior:** Use a soft, dry cloth to wipe the monitor casing. Avoid using abrasive cleaners or solvents.

Storage

If storing the monitor for an extended period, unplug it, disconnect all cables, and store it in a cool, dry place, preferably in its original packaging.

TROUBLESHOOTING

Problem	Possible Solution
No image on screen	<ul style="list-style-type: none">• Ensure the power cord is securely connected and the monitor is powered on.• Check that the video cable (HDMI, VGA, DVI) is securely connected to both the monitor and the computer.• Verify the correct input source is selected in the OSD menu.• Restart the computer.
Image is blurry or distorted	<ul style="list-style-type: none">• Ensure the display resolution on your computer is set to 1920 x 1080 pixels.• Adjust the monitor's auto-adjust function (for VGA input) or sharpness setting in the OSD menu.• Check the video cable for damage.
Monitor flickers	<ul style="list-style-type: none">• Check the video cable connection.• Ensure the refresh rate is set to 60 Hz in your computer's display settings.• Test with a different video cable or port.
No power indicator light	<ul style="list-style-type: none">• Verify the power cord is firmly connected to both the monitor and the power outlet.• Test the power outlet with another device.

SPECIFICATIONS

Feature	Detail
Model Number	UM.FX0EE.005
Screen Size	24 inches (61 cm)
Resolution	FHD 1080p (1920 x 1080 Pixels)
Aspect Ratio	16:9
Refresh Rate	60 Hz
Response Time	5 Milliseconds
Display Type	LED
Connectivity Technology	HDMI, VGA, DVI
Mounting Type	Wall Mount (VESA compatible)

Feature	Detail
Color	Black
Item Dimensions (D x W x H)	18"D x 0.78"W x 12"H (approximate, without stand)
Item Weight	3.74 Kilograms
Manufacturer	Acer

WARRANTY INFORMATION

Your Acer KA240H monitor comes with a standard warranty. The warranty covers **1 Year Parts and Labor** from the date of purchase. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included with your product or visit the official Acer support website.

This warranty does not cover damage caused by accident, misuse, abuse, improper installation or operation, natural disaster, or unauthorized modifications or repairs.

SUPPORT

If you encounter issues that cannot be resolved using the troubleshooting guide, or if you require further assistance, please contact Acer customer support. You can typically find support contact information, FAQs, and driver downloads on the official Acer website.

For the most up-to-date support resources, please visit: www.acer.com/support