

Manuals.plus /

› [Ferm](#) /

› FERM CSM1039 Circular Saw User Manual

Ferm CSM1039

FERM CSM1039 Circular Saw User Manual

Model: CSM1039 | Brand: FERM

1. PRODUCT OVERVIEW

The FERM CSM1039 circular saw is a compact and lightweight machine designed for efficient and precise cutting of various wood panels and materials. Equipped with a powerful 1200-watt motor, it accommodates 185mm saw blades, making it suitable for a wide range of sawing tasks. Its ergonomic design and adjustable features ensure optimal comfort and versatility for both professional and DIY users.

Key Features:

- Powerful 1200W motor for efficient cutting.
- 185mm blade diameter for versatile applications.
- Spindle lock for quick and easy blade changes.
- Adjustable base plate for cutting angles between 45 and 90 degrees.
- Parallel guide for precise and straight cuts.
- Ergonomic handle for comfortable operation.
- 3-meter rubber cable for extended reach and freedom of movement.

2. SAFETY INSTRUCTIONS

Always read and understand all safety warnings and instructions before operating this power tool. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

General Power Tool Safety Warnings:

- **Work Area Safety:** Keep work area clean and well lit. Cluttered or dark areas invite accidents. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.

- **Electrical Safety:** Power tool plugs must match the outlet. Never modify the plug in any way. Do not expose power tools to rain or wet conditions.
- **Personal Safety:** Stay alert, watch what you are doing, and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol, or medication. Always wear appropriate personal protective equipment (PPE), including eye protection, hearing protection, and dust masks.
- **Power Tool Use and Care:** Do not force the power tool. Use the correct power tool for your application. Disconnect the plug from the power source before making any adjustments, changing accessories, or storing power tools.
- **Kickback and Related Warnings:** Kickback is a sudden reaction to a pinched, bound, or misaligned saw blade. Always maintain a firm grip with both hands on the saw and position your body and arm to allow you to resist kickback forces.

3. PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are present and in good condition:

- FERM CSM1039 Circular Saw
- TCT Saw Blade (185mm diameter)
- Hex Key
- Parallel Guide

If any items are missing or damaged, please contact your retailer or FERM customer support immediately.

4. SETUP

4.1. Installing the Saw Blade

1. Ensure the saw is unplugged from the power source.
2. Press and hold the spindle lock button to prevent the blade from rotating.
3. Using the provided hex key, loosen the blade retaining screw.
4. Carefully lift the lower blade guard and remove the old blade (if applicable).
5. Place the new 185mm TCT saw blade onto the spindle, ensuring the rotation arrow on the blade matches the arrow on the saw's guard.
6. Tighten the blade retaining screw firmly with the hex key while holding the spindle lock.



Figure 1: Side view of the circular saw, highlighting the blade and guard assembly.

4.2. Adjusting Cutting Depth

The cutting depth can be adjusted to suit the thickness of your workpiece. Loosen the depth adjustment lever, move the base plate up or down to the desired depth, and then securely tighten the lever.

4.3. Adjusting Bevel Angle (45-90 degrees)

The base plate can be tilted for bevel cuts between 0 and 45 degrees. Loosen the bevel adjustment knob, tilt the base plate to the desired angle indicated on the scale, and then tighten the knob firmly.



Figure 2: The adjustable base plate allows for precise angle cuts.




Figure 3: Detailed view of the angle adjustment scale for accurate bevel settings.

4.4. Attaching the Parallel Guide

For straight and consistent cuts, insert the parallel guide into the slot on the front of the base plate. Adjust its position to the desired cutting width and secure it with the locking screw.



Figure 4: The parallel guide assists in making straight cuts.

5. OPERATING

5.1. Before Starting

- Ensure the workpiece is securely clamped to prevent movement during cutting.
- Verify that the blade is sharp and free from damage.

- Check that all adjustments (depth, angle, parallel guide) are securely tightened.
- Wear appropriate safety gear, including eye protection, hearing protection, and gloves.

5.2. Making a Cut

1. Plug the saw into a suitable power outlet.
2. Hold the saw firmly with both hands, ensuring a stable grip on the ergonomic handle.



Figure 5: The ergonomic handle provides a comfortable and secure grip.

3. Align the saw blade with your cutting line.
4. Press the trigger to start the motor and allow the blade to reach full speed before engaging the workpiece.
5. Slowly and steadily push the saw through the material, maintaining constant pressure. Do not force the saw.
6. Once the cut is complete, release the trigger and allow the blade to stop completely before lifting the saw from the workpiece.



Figure 6: The FERM CSM1039 Circular Saw in its primary configuration.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your FERM circular saw.

6.1. Cleaning

- Always unplug the tool before cleaning.
- Use a soft brush or compressed air to remove dust and debris from the ventilation openings and around the blade guard.
- Wipe down the exterior with a damp cloth. Do not use harsh chemicals or abrasive cleaners.

6.2. Blade Care

- Inspect the saw blade regularly for sharpness and damage. A dull or damaged blade can cause kickback and poor cuts.
- Replace worn or damaged blades promptly.
- Clean resin and pitch buildup from the blade using a suitable blade cleaner.

6.3. Storage

Store the circular saw in a dry, secure location, out of reach of children and away from direct sunlight or extreme temperatures.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your circular saw.

Problem	Possible Cause	Solution
Saw does not start	No power supply Faulty switch	Check power outlet and cable Contact qualified service personnel
Poor cutting performance / Rough cuts	Dull or damaged blade Incorrect blade for material Forcing the saw	Replace blade Use appropriate blade Apply steady, even pressure
Excessive vibration	Loose blade Damaged blade Motor issue	Tighten blade retaining screw Replace blade Contact qualified service personnel
Saw overheats	Blocked ventilation Overloading the motor	Clean ventilation openings Reduce cutting load, allow tool to cool

For issues not listed here or if solutions do not resolve the problem, please contact FERM customer support or a qualified service technician.

8. SPECIFICATIONS

Specification	Value
Manufacturer	FERM
Model Number	CSM1039
Power	1200 Watts
Voltage	230 V (240 Volts listed in specs)
Frequency	50 Hz
No-load Speed	5500/min (5500 rpm)
Max. Sawing Capacity at 900	65 mm
Max. Sawing Capacity at 450	43 mm
Blade Bore	20 mm
Blade Diameter	185 mm
Sawing Angle Adjustment	0-45 °

Specification	Value
Machine Weight	3.8 kg (3.7 Kilograms listed in specs)
Product Dimensions (L x W x H)	35 x 24 x 24.8 cm
Color	Black/Blue
Power Source	Corded Electric
Handle Material	Plastic
Blade Material	TCT
Special Feature	Spindle Lock
Country of Origin	China

9. WARRANTY AND SUPPORT

For information regarding the warranty period and terms for your FERM CSM1039 Circular Saw, please refer to the warranty card included with your purchase or visit the official FERM website. Warranty claims and technical support inquiries should be directed to your retailer or the FERM customer service department.

FERM is a renowned Dutch tool brand, designing and developing high-quality power tools and accessories for the international market since 1965. They are committed to quality, performance, and ergonomic design.

© 2024 FERM. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01H3G8Z3M>

More documents and user manuals: <https://manuals.plus/>