

[Manuals.plus](#) /

› [TAYAMA](#) /

› Tayama TMC-60XL 6 Quart 8-in-1 Multi-Function Pressure Cooker Instruction Manual

TAYAMA TMC-60XL

Tayama TMC-60XL 6 Quart 8-in-1 Multi-Function Pressure Cooker

Model: TMC-60XL

INTRODUCTION

The Tayama TMC-60XL is a versatile 6-quart 8-in-1 multi-function pressure cooker designed to simplify your cooking process. This appliance combines the functions of a pressure cooker, slow cooker, rice cooker, porridge maker, steamer, canning device, and warmer. It features flavor infusion technology to lock in nutrients and taste, ensuring delicious and healthy meals.

Key features include one-touch preset buttons, a non-stick inner pot, a safety locking lid with manual steam release, a digital display panel, automatic keep-warm mode, and built-in safety mechanisms. The cooker offers 12 micro-processor controlled programs for various dishes like soup, meat/stew, beans/chili, poultry, steam, rice (white, brown, wild), porridge, multi-grain, slow cook (0.5 to 20 hours), and canning. A manual setting allows for custom adjustment of pressure, temperature, and time.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the Tayama TMC-60XL pressure cooker to ensure safe operation and prevent injury or damage. Keep this manual for future reference.

- Always ensure the lid is properly closed and locked before operating the pressure cooker.
- Do not immerse the appliance body, cord, or plug in water or other liquids.
- Keep hands and face away from the pressure release valve when releasing steam.
- Ensure the floating valve has dropped before attempting to open the lid after cooking.
- Use the carry handles when moving the pressure cooker. Do not use the lid handle for this purpose.
- Always use at least 1 1/2 cups of liquid in the inner pot to prevent burning and ensure proper pressure buildup.
- Thick liquids generate less steam; adjust liquid amounts accordingly.
- Do not overfill the inner pot. Refer to the MAX fill line.
- Supervise children closely when the appliance is in use.

COMPONENTS AND PARTS



Figure 1: Front view of the Tayama TMC-60XL pressure cooker, showing the control panel and digital display.



Figure 2: Back view of the pressure cooker, illustrating the power cord connection and condensation collector.



Figure 3: Top view of the pressure cooker with the lid open and the non-stick inner pot removed, showing the heating element.



Figure 4: Close-up view of the lid, highlighting the pressure release valve and safety caution label.

Included Accessories:

- Non-stick inner pot
- Steam rack
- Measuring cup
- Ladle

SETUP

1. **Unpacking:** Carefully remove all packaging materials and accessories from the box.
2. **Initial Cleaning:** Before first use, wash the inner pot, lid, and all accessories (steam rack, measuring cup, ladle) with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the pressure cooker on a stable, level, heat-resistant surface, away from heat sources and water. Ensure adequate ventilation around the unit.
4. **Inner Pot Installation:** Place the non-stick inner pot into the main unit. Ensure it sits correctly and is not tilted.
5. **Lid Placement:** Align the lid with the main unit and turn it clockwise until it locks securely into place. The lid handle should align with the main unit's handles.
6. **Power Connection:** Plug the power cord into the designated port on the back of the pressure cooker, then into a grounded electrical outlet. The digital display will illuminate.

OPERATING INSTRUCTIONS

The Tayama TMC-60XL offers 12 pre-set programs and a manual setting for diverse cooking needs. Always ensure the lid is properly sealed and the pressure release valve is in the 'Seal' position for pressure cooking functions.

General Operation:

1. Add ingredients and the required amount of liquid to the inner pot. Ensure liquid is at least 1 1/2 cups for pressure cooking.

2. Close the lid securely and turn the pressure release valve to the 'Seal' position.
3. Select your desired cooking program using the one-touch preset buttons (e.g., SOUP/STEW, CHICKEN/MEAT, RICE).
4. The display will show the default cooking time. You can adjust the time using the 'Time Adjustment' buttons if needed.
5. The cooker will automatically begin the preheating phase, then start the cooking cycle once pressure is reached.
6. Once cooking is complete, the unit will beep and automatically switch to 'Keep Warm' mode.
7. **Pressure Release:** For natural release, allow the pressure to dissipate naturally. For quick release, carefully turn the pressure release valve to the 'Vent' position, keeping hands and face away from the steam.
8. Open the lid only after the floating valve has dropped completely.

Specific Functions:

- **Pressure Cooking:** Use programs like SOUP/STEW, CHICKEN/MEAT, BEANS/CHILI, POULTRY. Adjust pressure levels (Low, Medium, High) using the 'Pressure Adjustment' button if available for the selected program.
- **Rice Cooking:** Dedicated settings for White Rice, Brown Rice, and Wild Rice.
- **Slow Cook:** Allows cooking for 0.5 to 20 hours. Ensure the lid is properly placed but the pressure valve can be in 'Vent' position for slow cooking.
- **Steam:** Use with the provided steam rack for vegetables, fish, etc.
- **Canning:** Suitable for canning fruits and vegetables. Refer to specific canning guidelines for safe practices.
- **Keep Warm:** Automatically activates after most cooking programs. Can also be selected manually.
- **Manual Setting:** For custom recipes, use the 'Manual' button to set desired pressure, temperature, and time.

Your browser does not support the video tag.

Video 1: Demonstration of preparing ingredients, loading the inner pot, closing the lid, and selecting the SOUP/STEW function on the Tayama TMC-60XL pressure cooker. The video shows the cooking process and the final result.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Tayama TMC-60XL pressure cooker.

1. **Unplug:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Inner Pot:** The non-stick inner pot is dishwasher safe. For hand washing, use warm, soapy water and a non-abrasive sponge.
3. **Lid:** Wash the lid with warm, soapy water. Pay attention to the sealing ring and float valve. Ensure the float valve and sealing ring do not fall out during cleaning. Remove the sealing ring for thorough cleaning if necessary, and reinsert it correctly before next use.
4. **Exterior:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
5. **Accessories:** Wash the steam rack, measuring cup, and ladle with warm, soapy water.
6. **Storage:** Store the cleaned and dried pressure cooker in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your Tayama TMC-60XL, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not power on / Digital display is off.	Power cord not properly connected or no power from outlet.	Ensure the power cord is securely plugged into both the unit and a working electrical outlet. Check the circuit breaker.
Function buttons do not respond or engage.	Lid not properly closed or locked; unit not in standby mode.	Ensure the lid is fully closed and locked. Unplug the unit, wait a few seconds, then plug it back in to reset. If the issue persists, contact customer support.
Pressure does not build up / Steam leaks from lid.	Pressure release valve in 'Vent' position; sealing ring improperly installed or damaged; insufficient liquid.	Turn the pressure release valve to 'Seal'. Check the sealing ring for proper placement and damage. Ensure at least 1 1/2 cups of liquid are in the pot.
Food is not cooking properly or burning.	Insufficient liquid; incorrect cooking time/pressure setting.	Add more liquid. Adjust cooking time and pressure according to recipe and food type.
Lid cannot be opened after cooking.	Pressure still inside the cooker.	Do not force open. Allow pressure to release naturally or use the quick release method until the floating valve drops.

SPECIFICATIONS

- **Brand:** TAYAMA
- **Model:** TMC-60XL
- **Capacity:** 6 Quarts
- **Material:** Stainless steel
- **Color:** Black
- **Finish Type:** Glossy
- **Special Feature:** Keep Warm Setting, Locking Lid
- **Wattage:** 1000 watts
- **Control Method:** Touch
- **Operation Mode:** Automatic
- **Dishwasher Safe:** Yes (Inner Pot)
- **Product Dimensions:** 13 x 14 x 13 inches
- **Item Weight:** 13.72 pounds
- **Manufacturer:** Tayama
- **Date First Available:** July 14, 2016

WARRANTY AND SUPPORT

For warranty information or technical support regarding your Tayama TMC-60XL Multi-Function Pressure Cooker, please refer to the contact details provided with your purchase documentation or visit the official Tayama website. Keep your proof of purchase for any warranty claims.

