



Manuals.plus /

› **Lenovo** /

› Lenovo Yoga Tab 3 Pro User Manual

Lenovo ZA0F0099US

Lenovo Yoga Tab 3 Pro User Manual

Model: ZA0F0099US

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Lenovo Yoga Tab 3 Pro tablet. Designed for entertainment, this tablet features a QHD 10.1-inch display, powerful JBL speakers, and an integrated projector, offering a unique multimedia experience.

Please read this manual thoroughly before using your device to ensure proper functionality and to maximize your user experience.

PACKAGE CONTENTS

Upon opening the package, verify that all items are present:

- Lenovo Yoga Tab 3 Pro Tablet
- Power Adapter
- Micro-USB Cable
- Quick Start Guide

SETUP

1. Initial Charging

Before first use, fully charge the tablet. Connect the micro-USB cable to the tablet's charging port and the power adapter to a wall outlet. The charging indicator will illuminate.

2. Powering On/Off

To power on, press and hold the power button located on the side of the tablet until the Lenovo logo appears. To power off, press and hold the power button, then select "Power off" from the options.

3. Initial Setup Wizard

Upon first power-on, follow the on-screen instructions to complete the initial setup. This includes selecting your language, connecting to a Wi-Fi network, and signing in with your Google account.

4. Inserting a microSD Card (Optional)

The tablet supports expandable storage via a microSD card. Locate the card slot, gently insert the microSD card until it clicks into place. Ensure the tablet is powered off before inserting or removing the card.

OPERATING THE TABLET

Tablet Orientation and Stand

The Yoga Tab 3 Pro features a unique cylindrical battery and an integrated kickstand, allowing for multiple usage modes:

- **Hold Mode:** The cylindrical side provides a comfortable grip for reading or browsing.
- **Stand Mode:** Rotate the kickstand to prop the tablet upright for viewing videos or presentations.
- **Tilt Mode:** Position the kickstand to create a slight incline for comfortable typing or drawing.
- **Hang Mode:** The cutout in the kickstand allows the tablet to be hung on a hook for hands-free viewing, for example, in a kitchen.



Image: The Lenovo Yoga Tab 3 Pro shown in its stand mode, highlighting the integrated kickstand and cylindrical battery design.

Using the Integrated Projector

The Yoga Tab 3 Pro includes a built-in projector for displaying content on a larger surface. The projector is located on the cylindrical hinge.

1. **Activate Projector:** Locate the projector button or icon in the quick settings panel (swipe down from the top of the screen) or within the display settings.
2. **Focus Adjustment:** Use the focus wheel or on-screen controls to adjust the image clarity.
3. **Keystone Correction:** The tablet automatically adjusts for image distortion when projected at an angle. Manual adjustment options may also be available in settings.
4. **Optimal Viewing:** For best results, use the projector in a dark environment. The projected image quality is dependent on ambient light conditions.



Image: A user operating the Lenovo Yoga Tab 3 Pro, demonstrating its integrated projector casting an image onto a surface in a dimly lit room.

Audio and Display

The tablet features a 10.1-inch QHD (2560 x 1600) IPS display and JBL 4-speaker sound bar with Dolby Atmos for an immersive audio-visual experience.

- **Volume Control:** Use the physical volume buttons on the side of the tablet or the on-screen volume slider.
- **Display Settings:** Adjust brightness, color mode, and font size through the display settings menu.

MAINTENANCE

Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner solution. Avoid using harsh chemicals or abrasive materials.

Battery Care

To prolong battery life, avoid exposing the tablet to extreme temperatures. It is recommended to keep the battery charge between 20% and 80% for optimal longevity. The tablet offers up to 15 hours of battery life during typical use and up to 49 days standby time.

Software Updates

Regularly check for and install system updates to ensure your tablet has the latest features, security patches, and performance improvements. Navigate to *Settings > About tablet > System updates*

TROUBLESHOOTING

Problem	Possible Solution
Tablet does not power on.	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, perform a forced restart by holding the power button for 10-15 seconds.
Wi-Fi connection issues.	Restart the tablet and your Wi-Fi router. Forget the network in Wi-Fi settings and reconnect. Ensure you are within range of the Wi-Fi signal.
Projector image is blurry.	Adjust the focus wheel on the projector lens. Ensure the projection surface is flat and the tablet is stable. Check for any obstructions in front of the projector lens.
Slow performance.	Close unused applications. Clear cache and data for frequently used apps. Consider uninstalling unnecessary applications. Perform a factory reset as a last resort (backup data first).

SPECIFICATIONS

Feature	Detail
Model Name	Yoga Tab 3 Pro
Item Model Number	ZA0F0099US
Screen Size	10.1 Inches
Screen Resolution	2560 x 1600 pixels (QHD)
Processor	Intel Atom x5-Z8550 (2.24 GHz)
RAM	4 GB DDR3
Storage	64 GB Flash Memory Solid State (expandable via microSD)
Operating System	Android 6.0 Marshmallow
Rear Camera	13 MP Auto Focus
Front Camera	5 MP Fixed Focus
Battery Life	Up to 18 Hours (Average), Up to 49 Days (Standby)
Wireless Connectivity	802.11a/b/g/n/ac Wi-Fi, Bluetooth 4.0
Weight	1.47 pounds (667g)
Dimensions (LxWxH)	15 x 15 x 2 inches

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Lenovo website or the warranty card included

with your product. You can also visit the [Lenovo Store on Amazon](#) for additional resources.
Keep your purchase receipt as proof of purchase for warranty claims.