

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [JETBeam](#) /

› [JETBeam SF-R26 Rechargeable Flashlight User Manual](#)

JETBeam SF-R26

JETBeam SF-R26 Rechargeable Flashlight User Manual

Model: SF-R26 (9005721) | Brand: JETBeam

INTRODUCTION

The JETBeam SF-R26 is a high-performance, rechargeable LED flashlight designed for a wide range of lighting needs. Built with military-grade quality, it offers exceptional brightness and durability, making it suitable for various applications. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your SF-R26 flashlight.



Figure 1: JETBeam SF-R26 Rechargeable Flashlight, showcasing its compact and robust design.

SAFETY INFORMATION

- **Eye Safety:** Do not shine the flashlight directly into eyes. The powerful beam can cause temporary vision impairment or permanent eye damage.
- **Heat:** The flashlight may become warm during prolonged use, especially on higher output modes. Handle with care.
- **Battery Safety:**
 - Use only recommended battery types (1x 18650 or 2x CR123A).
 - Do not mix old and new batteries, or different types of batteries.
 - Ensure correct battery polarity during installation.
 - Do not dispose of batteries in fire. They may explode.
 - If the flashlight will not be used for an extended period, remove the batteries to prevent leakage.
- **Water Resistance:** While the SF-R26 is resistant to strong water jets, it is not designed for prolonged submersion. Ensure the USB port cover is securely closed when exposed to water.
- **Children:** Keep out of reach of children.

PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are included:

- JETBeam SF-R26 Flashlight
- Micro USB Charging Cable
- 18650 Rechargeable Battery (if included with specific package)
- Lanyard
- Spare O-rings
- User Manual (this document)



Figure 2: Contents typically included with the JETBeam SF-R26 flashlight, including the flashlight, battery, USB cable, and accessories.

SETUP

1. Battery Installation

The SF-R26 can be powered by one 18650 rechargeable Li-ion battery or two CR123A batteries. Ensure the battery is inserted with the positive (+) end facing towards the head of the flashlight.

1. Unscrew the tail cap of the flashlight.
2. Insert the battery(ies) according to the polarity markings. For 18650, the positive end goes towards the head. For CR123A, both positive ends go towards the head.
3. Screw the tail cap back on tightly to ensure proper contact and water resistance.

2. Charging (for 18650 battery)

The SF-R26 features a convenient micro USB charging port for internal recharging of an 18650 battery. CR123A batteries are NOT rechargeable via the flashlight's USB port.

1. Locate the micro USB charging port on the side of the flashlight. It is usually covered by a rubber flap.
2. Gently lift the rubber flap to expose the port.
3. Connect the micro USB cable to the flashlight's port and the other end to a USB power source (e.g., computer, wall adapter).
4. The side switch LED indicator will show charging status (e.g., red for charging, green for fully charged).
5. Once charging is complete, disconnect the cable and firmly press the rubber flap back into place to maintain water resistance.



Figure 3: The micro USB charging port on the side of the SF-R26, shown with a charging cable connected.

OPERATING INSTRUCTIONS

1. Power On/Off (Tail Switch)

The tactical tail cap switch controls the main power of the flashlight.

- **Momentary On:** Half-press the tail switch to momentarily turn on the light. Release to turn off.
- **Constant On/Off:** Fully press the tail switch until it clicks to turn the light on or off.



Figure 4: The tactical tail switch of the SF-R26, used for power control.

2. Mode Selection (Side Switch)

With the flashlight turned on, use the side switch to cycle through different brightness levels and special modes.

- **Brightness Levels:** Short press the side switch to cycle through the available brightness modes (e.g., Low, Medium, High, Turbo). The SF-R26 offers 3 dimming outputs (10 lumens, 250 lumens) and a maximum output of 1200 lumens.
- **Strobe Mode:** Press and hold the side switch for approximately 1-2 seconds to activate the Strobe mode. Short press again to return to the previous brightness level.



Figure 5: The side switch of the SF-R26, used for cycling through brightness modes and activating strobe.

3. Power Indicator

The side switch also functions as an LED power indicator. It will flash slowly and then quickly to indicate when the battery charge is low and needs replacement or recharging.

MAINTENANCE

- Cleaning:** Clean the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Threads and O-rings:** Periodically lubricate the threads and O-rings with silicone grease to maintain water resistance and smooth operation. Replace O-rings if they appear damaged or worn.
- Battery Care:**
 - Store batteries in a cool, dry place.
 - If using rechargeable 18650 batteries, recharge them regularly, even if not fully depleted, to prolong battery life.
 - Remove batteries from the flashlight if it will not be used for an extended period to prevent potential leakage and damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery inserted incorrectly. Batteries are depleted. Loose tail cap. Dirty contacts.	Check battery polarity and reinsert correctly. Replace or recharge batteries. Tighten the tail cap. Clean battery contacts and flashlight contact points with a clean cloth.

Problem	Possible Cause	Solution
Light is dim or flickers.	Low battery charge. Loose connections.	Recharge or replace batteries. Ensure tail cap and head are tightly screwed on.
Flashlight does not charge.	Using CR123A batteries (not rechargeable internally). USB cable or power source issue. Charging port obstruction.	Ensure an 18650 battery is installed. Try a different USB cable or power adapter. Check the charging port for debris.

SPECIFICATIONS

Feature	Detail
Model	SF-R26 (9005721)
LED	CREE XP-L HI LED
Max Output	1200 Lumens
Brightness Levels	10 Lumens, 250 Lumens, 1200 Lumens + Strobe
Peak Beam Distance	373 meters (1250 feet)
Peak Beam Intensity	34796 cd
Power Source	1 x 18650 rechargeable Li-ion battery OR 2 x CR123A batteries
Charging	Micro USB (for 18650 only)
Material	Aerospace-grade aluminum alloy with military-grade Type III hard-anodized finish
Dimensions	14.2 x 2.54 x 3.4 cm (5.59 x 1.0 x 1.34 inches)
Weight	108.86 grams (3.84 oz)
Color	Black
Water Resistance	Resistant to strong water jets (USB port cover must be closed)



Figure 6: Close-up view of the CREE XP-L HI LED emitter, highlighting the light source.

WARRANTY AND SUPPORT

JETBeam products are manufactured to high quality standards. For specific warranty details, please refer to the warranty card included with your product or visit the official JETBeam website. If you encounter any issues or require technical assistance, please contact JETBeam customer support or your authorized dealer.

Manufacturer: Sportsman Supply Inc.

Date First Available: February 24, 2017

Related Documents - SF-R26

	<p>JETBEAM E26 KUNAI UV Version Tactical Flashlight User Manual</p> <p>Comprehensive user manual for the JETBEAM E26 KUNAI UV Version tactical flashlight, featuring Luminus SST40 LED, UV and green laser, multiple lighting modes, USB-C charging, and durable aviation aluminum construction. Learn about its features, operation, battery indicators, and warranty.</p>
	<p>JETBeam RRT-M1X White Laser Flashlight User Manual</p> <p>User manual for the JETBeam RRT-M1X White Laser Flashlight, covering features, specifications, operation, maintenance, and warranty. Includes details on its 480-lumen output, 2300m beam throw, and use of 21700/18650 batteries.</p>
	<p>JETBeam RRT-M2S White Laser Flashlight User Manual Features, Specs, Operation, Warranty</p> <p>Comprehensive user manual for the JETBeam RRT-M2S White Laser Flashlight. Details features, specifications, battery compatibility, output modes, operation, protection functions, maintenance, and warranty information.</p>
	<p>JETBEAM E26 KUNAI UV Version Multi-Light Tactical Flashlight User Manual</p> <p>Comprehensive user manual for the JETBEAM E26 KUNAI UV Version tactical flashlight, featuring 1800 lumens, UV and green light modes, USB-C charging, and durable aviation aluminum construction. Includes specifications, operation instructions, battery indicators, and warranty information.</p>
	<p>Spider Farmer Leaf Bowl Trimmer User Manual</p> <p>Comprehensive user manual for the Spider Farmer Leaf Bowl Trimmer, detailing product size, accessories, and assembly instructions.</p>
	<p>AllyNav R26 Geodetic GNSS Receiver User Manual</p> <p>This user manual provides detailed information on the AllyNav R26 Geodetic GNSS Receiver, covering its product description, technical parameters, appearance, functions, operating modes, parameter configuration, precautions, and after-sales service.</p>