

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [JOYOUNG](#) /

› [Joyoung Multifunctional Slow Juicer JYZ-E6M User Manual](#)

## JOYOUNG JYZ-E6M

# Joyoung Multifunctional Slow Juicer JYZ-E6M User Manual

Model: JYZ-E6M

## INTRODUCTION

---

This manual provides essential information for the safe and efficient operation, maintenance, and care of your Joyoung Multifunctional Slow Juicer, model JYZ-E6M. Please read these instructions thoroughly before first use and retain for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the appliance.
- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is properly assembled and all parts are securely locked before operation.
- Keep hands and utensils out of the feed chute during operation to prevent injury. Always use the food pusher provided.
- Unplug the juicer from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for assistance.
- This appliance is designed for household use only. Do not use outdoors or for commercial purposes.
- Close supervision is necessary when any appliance is used by or near children.

## PARTS AND COMPONENTS

---

Familiarize yourself with the various parts of your slow juicer for proper assembly and operation.



Image showing the Joyoung Slow Juicer with its main components laid out, including the motor base, juicing screw, filter, and collection cups, ready for assembly.

- **Motor Base:** The main unit containing the motor and control panel.
- **Feeding Chute:** The opening where ingredients are inserted.
- **Juicing Screw (Auger):** The component that slowly presses ingredients to extract juice.
- **Filter Screen:** Separates pulp from juice.
- **Juice Outlet:** The spout from which extracted juice flows.
- **Pulp Outlet:** The opening from which dry pulp is expelled.
- **Juice Collection Cup:** For collecting the extracted juice.
- **Pulp Collection Cup:** For collecting the expelled pulp.
- **Food Pusher:** Used to guide ingredients into the feeding chute.

## SETUP AND ASSEMBLY

---

Follow these steps to assemble your juicer before first use and after cleaning.

1. Place the motor base on a stable, flat, and dry surface.
2. Insert the juicing bowl onto the motor base, aligning the arrows and twisting until it locks into place.
3. Place the filter screen into the juicing bowl.
4. Insert the juicing screw (auger) into the center of the filter screen.
5. Attach the hopper/feeding chute assembly, twisting it clockwise until it locks securely onto the juicing bowl.
6. Position the juice collection cup under the juice outlet and the pulp collection cup under the pulp outlet.



Image showing the Joyoung Slow Juicer fully assembled with the juice and pulp collection cups in place, ready for operation.

## OPERATING INSTRUCTIONS

---

### Ingredient Preparation

- Wash all fruits and vegetables thoroughly before juicing.
- Remove large seeds, pits, and hard skins (e.g., pineapple, melon, citrus).
- Cut ingredients into pieces small enough to fit easily into the feeding chute.

### Juicing Process

1. Ensure the juicer is properly assembled and the collection cups are correctly positioned.
2. Plug the power cord into a suitable electrical outlet (110V 60Hz).
3. Turn on the juicer. The DC motor operates at 75 revolutions per minute (r/m) for quiet operation.
4. Slowly feed prepared ingredients into the feeding chute. Use the food pusher gently if necessary, but do not force ingredients.
5. The spiral-squeezing technology will extract juice, which flows into the juice cup, while pulp is expelled into the pulp cup.
6. The juicer is designed for continuous operation for up to 20 minutes. If juicing for longer periods, allow the appliance to cool down for 30 minutes before resuming.
7. After juicing, turn off the appliance and unplug it from the power outlet.



Image depicting the Joyoung Slow Juicer actively extracting juice from fruits, with juice flowing into a glass, highlighting its efficient operation.

## Key Features

- **Anti-Oxidation Function:** The slow juicing process minimizes oxidation, preserving the original taste, color, and nutrients of the fruit and vegetable juice.
- **High Juice Yield:** Advanced spiral-squeezing technology improves juice yield by approximately 55% compared to traditional juicers, extracting more from your produce.
- **Quiet Operation:** The efficient DC motor significantly reduces noise during juicing, providing a more pleasant user experience.

## MAINTENANCE AND CLEANING

---

Regular and proper cleaning ensures optimal performance and extends the life of your juicer.

1. **Disassembly:** After unplugging the juicer, disassemble it in the reverse order of assembly.
2. **Rinsing:** Rinse all removable parts under running water immediately after use to prevent pulp from drying and sticking.
3. **Washing:** Wash removable parts with warm, soapy water. Use a cleaning brush (if provided) to thoroughly clean the filter screen and remove any trapped pulp.
4. **Dishwasher Safe:** Most removable parts are dishwasher safe. Refer to the product care instructions for specific details.
5. **Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
6. **Drying and Storage:** Dry all parts completely before reassembling or storing. Store the juicer in a clean, dry place away from direct sunlight.

## TROUBLESHOOTING

Refer to this table for common issues and their solutions.

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; not assembled correctly; power outage.	Check power connection; ensure all parts are locked into place; check household circuit breaker.
Low juice yield or excessive wet pulp.	Ingredients too large; filter clogged; feeding ingredients too quickly.	Cut ingredients smaller; clean the filter screen thoroughly; feed ingredients slowly and steadily.
Juicer stops during operation.	Overload protection activated; continuous operation exceeded; blockage.	Turn off, unplug, clear any blockages, and let cool for 30 minutes before restarting. Avoid exceeding 20 minutes of continuous use.
Loud noise or vibration.	Improper assembly; hard ingredients causing strain.	Disassemble and reassemble correctly; ensure ingredients are cut appropriately and not forced.

## SPECIFICATIONS

- **Model Number:** JYZ-E6M
- **Rated Power:** 1500W
- **Rated Voltage:** 110V
- **Frequency:** 60Hz
- **Rotating Speed:** 75 r/m
- **Dimensions:** 377 x 225 x 256 mm
- **Blade Material:** Stainless Steel
- **Color:** White
- **Product Care:** Dishwasher Safe (removable parts)

## WARRANTY AND SUPPORT

This Joyoung JYZ-E6M Slow Juicer comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects under normal household use. It does not cover damage resulting from misuse, accident, alteration, or commercial use.

For warranty claims, technical support, or any questions regarding your product, please contact Joyoung customer service. Please retain your proof of purchase for warranty validation.

