

Wonderchef 63152285

Wonderchef Snacks Maker Instruction Manual

Model: 63152285

1. INTRODUCTION

Thank you for choosing the Wonderchef Snacks Maker. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read these instructions thoroughly before first use and keep them for future reference.

2. SAFETY INSTRUCTIONS

- Always handle the sharp jalis (plates) with care to prevent injury.
- Keep the appliance out of reach of children.
- Ensure all parts are securely assembled before use.
- Do not use abrasive cleaners or harsh chemicals on any part of the snack maker.
- When pressing dough, apply steady pressure. Avoid excessive force that could damage the mechanism.
- Always clean the appliance immediately after use to prevent dough from hardening and becoming difficult to remove.

3. PRODUCT OVERVIEW

The Wonderchef Snacks Maker is designed to simplify the process of making various traditional Indian snacks (namkeens) and pasta at home. It features a robust stainless steel construction and an ergonomic design for ease of use.



Figure 1: Wonderchef Snacks Maker with its components.

Components:

- **Main Unit:** The body of the snack maker with a press mechanism.
- **Dough Container:** Where the dough is loaded.
- **12 Stainless Steel Jalis:** Interchangeable plates for different snack shapes.
- **Plunger:** Used to press the dough through the jali.

Robust Build, for Long-Lasting Performance



Figure 2: The 12 varied shaped jalis included for different types of snacks.

Key Features:

- **High-Grade Stainless Steel Plates:** Ensures durability and efficient functioning.
- **Multi-Purpose Use:** Create chakli, murukku, sev, gathiya, bhujiya, pasta, papdi, and more.
- **Ergonomic Design:** Easy press mechanism with a locking system for comfortable and safe operation.
- **Safe to Use:** Designed with safety measures to prevent accidents.
- **Easy to Store:** Includes a special container for storing all jalis, keeping them organized and minimizing kitchen space.

4. SETUP

Follow these steps to prepare your Wonderchef Snacks Maker for use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Wash:** Before first use, wash all parts that will come into contact with food (dough container, jalis, plunger) with warm soapy water. Rinse thoroughly and dry completely.
3. **Select Jali:** Choose the desired jali (plate) for the snack you wish to make.
4. **Insert Jali:** Unscrew the bottom cap of the dough container. Place the selected jali inside the cap and screw the cap back onto the container securely.
5. **Assemble Plunger:** Ensure the plunger is correctly inserted into the main unit.




Figure 3: Visual guide for assembling the snack maker.

5. OPERATING INSTRUCTIONS

Once assembled, your snack maker is ready for use. Ensure your dough is of the correct consistency for

optimal results.

1. **Prepare Dough:** Make sure your dough is soft and pliable, suitable for pressing.
2. **Load Dough:** Fill the dough container with your prepared dough. Do not overfill.
3. **Position:** Hold the snack maker over a plate, parchment paper, or directly over hot oil (if frying immediately).
4. **Press:** Press the handle gently and steadily to extrude the dough through the chosen jali. The ergonomic design allows for easy pressing without manual knob turning.
5. **Shape/Cut:** Guide the extruded dough to form desired shapes (e.g., chakli spirals) or cut to length for sev, pasta, etc.
6. **Cook:** Proceed with cooking your snacks (frying, boiling, baking) as per your recipe.



Figure 4: The snack maker in action, creating various shapes.

Your browser does not support the video tag. Please update your browser to view this content.

Video 1: Demonstration of the Wonderchef Snacks Maker in use, showing how to assemble, load dough, and create different snacks.

6. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your Wonderchef Snacks Maker.

1. **Disassemble:** After each use, fully disassemble the snack maker, separating the main unit, dough container, plunger, and jali.
2. **Remove Excess Dough:** Scrape off any remaining dough from all parts.
3. **Wash:** Wash all parts with warm, soapy water. Use a small brush or sponge to clean the intricate patterns of the jalis.
4. **Rinse and Dry:** Rinse all components thoroughly under running water and dry them completely to prevent water spots or rust.
5. **Storage:** Store the clean and dry snack maker and its jalis in the provided container in a dry place.




Figure 5: Cleaning the Wonderchef Snacks Maker after use.

7. TROUBLESHOOTING

If you encounter any issues with your Wonderchef Snacks Maker, refer to the following common problems and solutions:

- **Dough not extruding:**

- Check if the dough is too stiff. Add a little liquid and knead until pliable.
- Ensure the jali is not clogged. Clean it thoroughly.
- Verify that the plunger is correctly aligned and fully engaged.

- **Dough oozing from sides:**

- Ensure the bottom cap with the jali is screwed on tightly.
- Check if the dough container is overloaded.

- **Difficulty pressing the handle:**

- The dough might be too firm. Adjust its consistency.
- Ensure the internal mechanism is clean and free of dried dough.

8. SPECIFICATIONS

Feature	Detail
Model Number	63152285
Material	High-grade Stainless Steel (Jalis)
Included Components	Snacks Maker with 12 Different Jalis
Item Weight	740 g
Item Dimensions (LxWxH)	20 x 24 x 5.5 Centimeters
Country of Origin	India

9. WARRANTY AND SUPPORT

The Wonderchef Snacks Maker comes with a reliable **1-year Wonderchef warranty** from the date of purchase. Please retain your purchase receipt as proof of warranty.

For any product-related queries, assistance, or warranty claims, please contact Wonderchef customer support:

- **Phone:** 18602660788
- **WhatsApp:** 7070595959

For further information, you may also visit the official Wonderchef website or refer to the product detail page on Amazon.in.

